Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY CG43-P3, CG43-C3

ALLIMITY Replacement Voice Remote Control User Manual

For FPD Smart TVs: Palette-Series CG43-P3, Canvas-Series CG43-C3

1. Introduction

1.1 Product Overview

This manual provides comprehensive instructions for the ALLIMITY Replacement Voice Remote Control. This remote is designed to be compatible with specific FPD 43-inch 4K 1080p UHD FHD Smart TV models, offering a seamless replacement experience with voice control functionality.

1.2 Package Contents

- 1 x ALLIMITY Replacement Voice Remote Control

1.3 Compatibility

This replacement remote control is compatible with the following FPD Smart TV models:

- FPD Palette-Series CG43-P3
- FPD Canvas-Series CG43-C3

If your TV model is not listed, please contact customer support for assistance.

2. Setup

2.1 Battery Installation

The remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.





Figure 2.1: Battery compartment with batteries inserted.

2.2 Pairing Instructions

This replacement remote control needs to be paired with your FPD Smart TV before use. The specific pairing process may vary slightly depending on your TV's software version. Generally, the steps involve:

1. Ensure your TV is powered on.
2. Point the remote control towards the TV's remote control sensor.
3. Press and hold the **OK** button and the **Back** button (left arrow) simultaneously for a few seconds until a pairing message appears on your TV screen.
4. Follow any on-screen prompts to complete the pairing process.

If pairing is unsuccessful, try replacing the batteries or moving closer to the TV. Refer to your TV's original user manual for detailed pairing instructions if needed.

3. Operating Instructions

To ensure proper function, aim the remote control directly at the TV's remote control sensor, avoiding any obstructions.





Figure 3.1: ALLIMITY Replacement Voice Remote Control Layout.

3.1 Basic Remote Usage

The remote control features standard buttons for TV operation:

- **Power Button** (▌): Turns the TV on or off.
- **Mute Button** (▌): Mutes or unmutes the TV audio.
- **Volume Up/Down** (**VOL +/-**): Adjusts the TV volume.
- **Channel Up/Down** (**P +/-**): Changes TV channels.
- **Navigation Pad (Up, Down, Left, Right)**: Navigates through menus and options.
- **OK Button**: Confirms selections.
- **Back Button** (▌): Returns to the previous screen or menu.
- **Home Button** (▌): Accesses the TV's home screen.
- **Input/Source Button** (▌): Selects input sources.
- **Number Buttons (0-9)**: Directly enter channel numbers.

3.2 Voice Control Function

The remote features a dedicated voice control button for convenient command input:

1. Press the **Microphone Button** (🎙) located on the remote.
2. Speak clearly into the microphone located at the top of the remote control.
3. Release the button once you have finished speaking.

Use voice commands to search for content, open applications, change settings, and more. Ensure your TV is connected to the internet for full voice control functionality.







Figure 3.2: Microphone button for voice control.

3.3 Quick Access Buttons

The remote includes dedicated buttons for popular streaming services:

- **Netflix**: Launches the Netflix application.
- **YouTube**: Launches the YouTube application.
- **Prime Video**: Launches the Prime Video application.
- **YouTube Music**: Launches the YouTube Music application.

4. Maintenance

4.1 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent leakage.

5. Troubleshooting

Issue	Possible Solution
Remote is not responding.	Check battery orientation and charge. Replace batteries if necessary. Ensure the remote is aimed directly at the TV sensor without obstructions. Re-pair the remote with the TV.
Voice control is not working.	Ensure the remote is properly paired. Check if the TV has an active internet connection. Speak clearly and close to the microphone.
Buttons are sticky or unresponsive.	Clean the remote control with a dry cloth. Avoid spilling liquids on the remote.
Remote only works intermittently.	Replace batteries. Ensure no strong light sources are interfering with the IR signal.

6. Specifications

Feature	Detail
Product Dimensions	5 x 1 x 0.5 inches (12.7 x 2.54 x 1.27 cm)
Item Weight	1 ounce (28.35 grams)
Material	Plastic
Color	Black
Special Feature	Voice Search
Power Source	2 x AAA Batteries (not included)
Compatible Devices	FPD 43 Inch 4K 1080p UHD FHD Smart TV (Palette-Series CG43-P3, Canvas-Series CG43-C3)





Figure 6.1: Remote control dimensions.

7. Support

If you encounter any issues not covered in this manual or require further assistance, please contact ALLIMITY customer support. When contacting support, please provide your TV model number for efficient service.
Contact information can typically be found on the product packaging or the seller's platform where the remote was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DXPD1BLJ

More documents and user manuals: **https://manuals.plus/**