Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

REWARD RD83046M-H

REWARD Analog Green Dial Men's Watch RD83046M-H User Manual

Model: RD83046M-H

1. Introduction

Thank you for choosing the REWARD Analog Green Dial Men's Watch, model RD83046M-H. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your new timepiece. Please read it carefully to ensure optimal performance and longevity of your watch.



Image 1.1: Front view of the REWARD Analog Green Dial Men's Watch RD83046M-H, showcasing its green dial, silver case, and green silicone band.

2. Setup

2.1 Setting the Time

1. Pull the crown (the knob on the right side of the watch case) out to the second click position.
2. Turn the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its normal position to start the watch movement.

2.2 Setting the Date

1. Pull the crown out to the first click position.
2. Turn the crown clockwise to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.

3. Once the date is set, push the crown back into its normal position.

2.3 Adjusting the Band

The watch features a silicone band with a buckle clasp. To adjust the fit, locate the buckle and adjust the pin to the desired hole on the strap for a comfortable and secure fit on your wrist.



Image 2.1: The REWARD watch worn on a wrist, demonstrating the fit of the silicone band.

3. Operating the Watch

3.1 Basic Timekeeping

Your REWARD watch is an analog timepiece powered by a Quartz movement, providing accurate time display with hour, minute, and second hands.

3.2 Chronograph and Sub-dials

This watch features functional sub-dials and a tachymeter scale. The sub-dials typically indicate:

- **24-Hour Display:** One sub-dial shows the time in a 24-hour format.
- **Chronograph Minutes/Seconds:** Other sub-dials function as part of the chronograph to measure elapsed time in minutes and seconds.

The pushers located above and below the crown are used to start, stop, and reset the chronograph functions. Refer to the specific chronograph instructions if provided with your watch packaging for detailed usage.

3.3 Glow in the Dark Feature

The watch hands and/or markers are treated with a luminous material that glows in the dark after exposure to light, allowing for readability in low-light conditions.



Image 3.1: Close-up view of the watch dial, highlighting the sub-dials, date window, and luminous markers.

4. Maintenance

4.1 Cleaning

- Wipe the watch case and band regularly with a soft, dry cloth to remove dust and dirt.
- For the silicone band, you can use a slightly damp cloth with mild soap, then rinse and dry thoroughly.
- Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish.

4.2 Water Resistance (3 ATM)

Your REWARD watch is water-resistant up to 3 ATM (30 meters). This means it is suitable for daily use and can withstand splashes or brief immersion in water, such as hand washing or rain. It is **not** suitable for showering, swimming, diving, or any water sports. Do not operate the crown or pushers when the watch is wet or submerged.

4.3 Battery Replacement

The Quartz movement is powered by a watch battery. When the watch stops running, it indicates that the battery needs replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

4.4 Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. Keeping it in its original box or a watch case can help protect it from scratches and dust.

5. Troubleshooting

5.1 Watch Not Running

- **Check the crown:** Ensure the crown is fully pushed in to the normal operating position.
- **Battery:** If the watch has stopped completely, the battery may need to be replaced.

5.2 Incorrect Time or Date

- **Resetting:** Follow the instructions in Section 2.1 and 2.2 to reset the time and date.
- **Crown position:** Ensure the crown is fully pushed in after setting.

5.3 Condensation Under Crystal

If you notice condensation under the watch crystal, it indicates that moisture has entered the watch. This can lead to internal damage. Immediately take the watch to a qualified technician for inspection and repair.

6. Specifications

Feature	Specification
Model Number	RD83046M-H
Brand	REWARD
Display Type	Analog
Movement	Quartz
Dial Color	Green
Case Color	Silver
Case Material	Alloy Case / Metal
Case Shape	Round
Case Diameter	48 mm
Case Thickness	12 mm
Band Color	Green
Band Material	Silicone
Band Width	27 mm
Band Length	255 mm (Men's Standard Size)
Clasp Type	Buckle
Glass Material	Mineral Glass
Water Resistance Depth	3 ATM (30 Meters)
Special Features	Glow In The Dark, Date Display, Chronograph (sub-dials)
Item Weight	126 Grams
Product Dimensions	17 x 12 x 3 cm
Country of Origin	China

7. Warranty

This REWARD watch comes with a**1-year Manufacturer Warranty**. The warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear.
For warranty claims, please retain your proof of purchase. If this product was sold by Amazon, please review the manufacturer’s website for warranty information. If this product was sold by another party, please contact the seller directly for warranty information.

8. Support

For further assistance, technical support, or inquiries regarding your REWARD watch, please refer to the contact information provided with your purchase or visit the official REWARD brand website.

© 2025 REWARD. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DXQD7RNT

More documents and user manuals: **https://manuals.plus/**