Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Skullcandy SCCRW

Skullcandy Crusher Wireless Headphones User Manual

Model: SCCRW

Introduction



Image: The Skullcandy Crusher Wireless Over-Ear Bluetooth Headphones in black, showcasing their sleek design.

The Skullcandy Crusher Wireless Over-Ear Bluetooth Headphones deliver an immersive audio experience with custom-tuned 40mm drivers and stereo haptic bass, allowing you to feel the music like never before. With up to 40 hours of battery life and rapid charge technology providing 3 hours of use from a quick 10-minute charge, your listening sessions can extend all day. The built-in microphone and on-ear controls offer seamless call and music management, while the foldable design ensures easy portability. Whether you're at home or on the go, these headphones provide exceptional sound quality and convenience.



Image: Official User Guide cover for Skullcandy Crusher Wireless headphones.

What's in the Box

Upon unboxing your Skullcandy Crusher Wireless Headphones, you should find the following items:

- Skullcandy Crusher Wireless Over-Ear Bluetooth Headphones
- User Manual
- USB-C Charging Cable
- Auxiliary Audio Cable (3.5mm)
- Travel Pouch



Image: The Skullcandy Crusher Wireless headphones, along with the included travel pouch, USB-C charging cable, and auxiliary audio cable.

Setup

Charging Your Headphones

Before initial use, fully charge your Skullcandy Crusher Wireless headphones. Connect the provided USB-C charging cable to the charging port on the left earcup and the other end to a compatible USB power source. The LED indicator will show charging status and turn off when fully charged.

- **Rapid Charge:** A 10-minute charge provides up to 3 hours of playback.
- **Full Charge:** Provides up to 40 hours of continuous playback.



Image: Illustration highlighting the rapid charge capability of the headphones.

Bluetooth Pairing

1. Ensure your headphones are powered off.
2. Press and hold the power button (located on the right earcup) for 3-5 seconds until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for "Crusher Wireless" in the list of available devices.
4. Select "Crusher Wireless" to connect. The LED indicator will turn solid blue when successfully paired.



Image: Marketing graphic showing key features including Bluetooth Wireless connectivity.

Operating Instructions

Power On/Off

- **Power On:** Press and hold the power button for 1-2 seconds.
- **Power Off:** Press and hold the power button for 3-5 seconds.

Music Controls

- **Play/Pause:** Press the center button once.
- **Volume Up:** Press the "+" button.
- **Volume Down:** Press the "-" button.
- **Track Forward:** Press and hold the "+" button for 2 seconds.
- **Track Back:** Press and hold the "-" button for 2 seconds.

Call Controls

- **Answer/End Call:** Press the center button once.
- **Reject Call:** Press and hold the center button for 2 seconds.

Crusher Bass Slider

The Crusher Wireless headphones feature an adjustable bass slider on the left earcup. Slide it up to increase the haptic bass intensity and down to decrease it. This allows for personalized audio feedback.



Image: Controls visible on the earcups, including the bass slider.

Key Features

- **Immersive Sensory Bass:** Experience powerful, directional bass with custom-tuned 40mm audio drivers and stereo haptics in each earcup.
- **Extended Battery Life:** Enjoy up to 40 hours of continuous playback on a single charge, perfect for all-day listening.
- **Rapid Charge Technology:** Get back to your music quickly with 3 hours of playback from just a 10-minute charge.

- **Built-in Microphone and Controls:** Easily manage calls, adjust volume, and control playback directly from the earcup.
- **Comfortable and Portable Design:** Over-ear design provides passive noise isolation, and the foldable structure makes it convenient for travel.



Image: A user experiencing the immersive bass of the Skullcandy Crusher Wireless headphones.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the earcups and headband. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the headphones in the provided travel pouch to protect them from dust and scratches.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in constant use.
- **Avoid Moisture:** Do not expose the headphones to water or excessive moisture.

Troubleshooting

Problem	Solution
Headphones not powering on	Ensure the headphones are fully charged. Press and hold the power button for 3-5 seconds.
Cannot pair via Bluetooth	Make sure headphones are in pairing mode (flashing blue/red LED). Turn off and on Bluetooth on your device. Forget the device in your Bluetooth settings and try pairing again. Ensure headphones are within range.
No sound or low volume	Check volume levels on both headphones and connected device. Ensure headphones are properly paired. Try playing different audio sources.
Bass is too strong/weak	Adjust the Crusher Bass slider on the left earcup to your preferred level.

Specifications

- **Model Name:** S6CRW-K591-Pouch
- **Item Model Number:** SCCRW
- **Connectivity Technology:** Wireless (Bluetooth)
- **Audio Driver Type:** Dynamic Driver (40mm)
- **Frequency Range:** 20 Hz - 20,000 Hz
- **Battery Life:** Up to 40 Hours
- **Rapid Charge:** 10 minutes charge for 3 hours playback
- **Control Method:** Touch (On-ear controls)
- **Microphone:** Built-in
- **Noise Control:** Passive Noise Cancellation
- **Form Factor:** Over Ear
- **Color:** Black
- **Item Weight:** 15.1 ounces (429 Grams)
- **Product Dimensions:** 8.46 x 3.35 x 5.51 inches
- **UPC:** 810045689128

Warranty and Support

For detailed warranty information and customer support, please refer to the official Skullcandy website or the warranty card included with your product. You can also contact Skullcandy customer service directly for assistance with product registration, troubleshooting, or repair services.
Manufacturer: Skullcandy
Website: www.skullcandy.com

© 2025 Skullcandy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DXQFK3YY

More documents and user manuals: **https://manuals.plus/**