Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RC-406

XINFUTE RC-406 Remote Control User Manual

For Kenwood CD Receiver Models: KDC-X304, KDC-X704, KMR-D358

1. Introduction

This manual provides instructions for the proper setup, operation, and maintenance of your XINFUTE RC-406 replacement remote control. This remote is designed to be compatible with specific Kenwood CD Receiver models, including KDC-X304, KDC-X704, and KMR-D358.
Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.

2. Setup: Battery Installation

The RC-406 remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Back of the RC-406 remote control, illustrating the battery compartment. The cover is shown detached, revealing the space for two AAA batteries.

Important: Ensure batteries are inserted with correct polarity. Remove batteries if the remote will not be used for an extended period to prevent leakage.

3. Operating Instructions

The RC-406 remote control provides full functionality for your compatible Kenwood CD Receiver. Point the remote directly at the receiver's infrared sensor for optimal response.




REMOTE CONTROL UNIT
RC-406
SRC
OFF
VOL
ATT
ENT
DIRECT
/OK
AUD
*AM−
FM+
1
2
3
4
5
6
7
8
9
0



Image: Front view of the RC-406 remote control, displaying its ergonomic design and all control buttons.

Button Functions:

- **SRC (Source):** Selects the audio input source (e.g., CD, Tuner, USB, AUX).
- **OFF:** Turns the CD Receiver power off.
- **VOL ▲ / ▼ (Volume Up/Down):** Adjusts the audio output volume.
- **ATT (Attenuate):** Mutes or significantly reduces the audio volume.
- **AUD (Audio):** Accesses audio settings such as bass, treble, balance, and fader.
- **Navigation Pad (▲ ▼ ◀ ▶):** Navigates through menus, tracks, or radio presets.
- **ENT / ▶▶ (Enter / Play/Pause):** Confirms selections in menus or plays/pauses media.
- **◀◀ / ▶▶ (Previous/Next Track):** Skips to the previous or next track/file.
- **DIRECT / OK:** Used for direct input or confirmation in certain functions.
- **↶ (Return/Back):** Returns to the previous menu or function.
- ***AM- / #FM+:** Selects AM/FM radio bands and navigates presets.
- **Numeric Keypad (0-9):** Used for direct track selection, radio preset recall, or inputting numbers.
- **Green Call Button:** (If applicable to your receiver) Initiates a call or answers an incoming call for Bluetooth-enabled receivers.
- **Red End Call Button:** (If applicable to your receiver) Ends a call or rejects an incoming call for Bluetooth-enabled receivers.

4. Maintenance

To ensure the longevity and proper functioning of your RC-406 remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or solvents.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Battery Care:** Replace batteries when the remote's response becomes sluggish or inconsistent. Always dispose of used batteries responsibly according to local regulations.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

5. Troubleshooting

If you experience issues with your RC-406 remote control, try the following troubleshooting steps:

- **Remote Not Responding:**
  - Check if the batteries are correctly installed with the proper polarity.
  - Replace the batteries with new ones.
  - Ensure there are no obstructions between the remote control and the Kenwood CD Receiver's infrared sensor.

- Make sure you are within the effective operating range of the remote control.

- **Intermittent Operation:**
  - This often indicates low battery power. Replace the batteries.
  - Ensure the remote's infrared emitter is clean and free from dust or debris.

6. Specifications

Feature	Detail
Model Number	RC-406
Compatible Devices	Kenwood CD Receivers: KDC-X304, KDC-X704, KMR-D358
Power Source	2 x AAA Batteries (not included)
Material	ABS Material
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Special Feature	Ergonomic Design

7. Warranty and Support

Warranty: This XINFUTE RC-406 remote control comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.
Customer Support: If you encounter any issues or have questions regarding your RC-406 remote control, please contact the seller or manufacturer directly. It is recommended to reach out within 24 hours of receiving your product if you are not satisfied with your purchase. Please refer to your purchase documentation for specific contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DXTVQ6FN

More documents and user manuals: **https://manuals.plus/**