Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UNINELL HOME UV1

UNINELL HOME UV1 Combination Brush Accessory Instruction Manual

Model: UV1

Introduction

Thank you for choosing the UNINELL HOME UV1 Combination Brush Accessory. This manual provides essential information for the proper setup, operation, and maintenance of your new vacuum cleaner attachment. Please read these instructions carefully before use to ensure optimal performance and longevity of the product.

Product Overview

The UNINELL HOME UV1 Combination Brush is a versatile accessory designed to enhance the cleaning capabilities of your UNINELL HOME vacuum cleaner. It features a dual-purpose design, allowing for effective cleaning on various surfaces.



An image showing the UNINELL HOME UV1 Combination Brush Accessory. The brush features a dark gray body with red accents for release buttons, and black bristles at the end, designed for attaching to a vacuum cleaner.

Key Components:

- **Connection Port:** Designed for secure attachment to your UNINELL HOME vacuum cleaner's wand or hose.

- **Brush Head:** Features soft bristles for delicate surfaces and a wider opening for general debris.
- **Release Button:** A red button for detaching the accessory from the vacuum.

Setup

Follow these steps to attach the combination brush to your vacuum cleaner:

1. Ensure your UNINELL HOME vacuum cleaner is turned off and unplugged from the power source for safety.
2. Align the connection port of the UV1 Combination Brush with the end of your vacuum cleaner's wand or hose.
3. Push the brush firmly onto the wand/hose until it clicks securely into place. A secure connection is crucial for effective suction.
4. To remove, press the red release button on the brush and pull it away from the wand/hose.

Operating Instructions

The UV1 Combination Brush is designed for versatile cleaning. Its retractable brush feature allows you to switch between different cleaning modes:

- **Brush Extended:** For cleaning delicate surfaces such as upholstery, curtains, keyboards, or car interiors. The soft bristles gently dislodge dust and debris without scratching.
- **Brush Retracted:** For general vacuuming of hard surfaces, crevices, or larger debris. This mode provides direct suction for more powerful cleaning.

To extend or retract the brush, simply slide the brush head mechanism up or down until it locks into the desired position.

Maintenance

Regular maintenance ensures the optimal performance of your combination brush accessory.

- **Cleaning the Bristles:** Periodically inspect the brush bristles for tangled hair, lint, or debris. Use scissors to carefully cut away any tangled material, then pull it out.
- **Washing:** The brush head can be gently washed with mild soap and water if heavily soiled. Ensure it is completely dry before reattaching it to the vacuum cleaner. Do not immerse the entire accessory in water.
- **Storage:** Store the accessory in a clean, dry place when not in use to prevent dust accumulation and damage.

Troubleshooting

If you encounter issues with your UNINELL HOME UV1 Combination Brush, consider the following:

- **Poor Suction:** Check if the brush is securely attached to the vacuum wand/hose. Ensure the vacuum cleaner's dustbin is not full and its filters are clean.
- **Brush Not Extending/Retracting Smoothly:** Inspect for any debris lodged in the sliding mechanism. Clean as described in the Maintenance section.

Specifications

Brand	UNINELL HOME
Model Number	UV1

Color	Black
Product Dimensions	5"L x 3"W x 2"H
Item Weight	3.2 ounces
Batteries Required	No

Warranty and Support

For information regarding warranty coverage or technical support for your UNINELL HOME UV1 Combination Brush Accessory, please refer to the documentation provided with your UNINELL HOME vacuum cleaner or visit the official UNINELL HOME website. You may also contact customer service through the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DXVH47TN

More documents and user manuals: **https://manuals.plus/**