Domo DO745MF

DOMO DO745MF Milk Frother User Manual

Model: DO745MF

1. Introduction

Thank you for purchasing the DOMO DO745MF Milk Frother. This appliance is designed to quickly and efficiently prepare perfect milk foam for your coffee and other beverages, or simply heat milk. It offers versatility with options for hot froth, cold froth, or heating milk without frothing. Please read this manual carefully before first use to ensure safe and optimal operation of your device.



Image: The DOMO DO745MF Milk Frother in matte grey, shown next to a glass of frothed milk, highlighting its primary function.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.

- Do not immerse the power base, cord, or plug in water or other liquids.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Close supervision is necessary when any appliance is used by or near children.
- Avoid contact with moving parts.
- Do not use outdoors.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Exercise extreme caution when disposing of hot steam.
- The appliance is equipped with non-slip feet for stability. Ensure it is placed on a stable, level surface.

3. Parts and Components

Familiarize yourself with the components of your DOMO DO745MF Milk Frother:

1. Frother Jug (double-walled with non-stick coating)
2. Transparent Lid
3. Frothing Whisk (for dense foam)
4. Stirring Whisk (for heating without frothing)
5. Power Base with Cord Storage
6. Control Button with Indicator Light



Image: An exploded view of the milk frother, illustrating its main components: the transparent lid, two types of whisks, the main frother jug, and the detachable power base with its cord.

4. Setup

Before first use, follow these steps:

- **Unpack:** Carefully remove all packaging materials and dispose of them responsibly.
- **Inspect:** Check the appliance for any signs of damage. Do not use if damaged.
- **Clean:** Wash the frother jug and whisks with warm soapy water. Rinse thoroughly and dry. Wipe the exterior of the power base with a damp cloth. Do not immerse the power base in water.
- **Placement:** Place the power base on a dry, stable, and level surface, away from heat sources and water.
- **Power Connection:** Plug the power cord into a suitable wall outlet. The cable storage at the bottom of the base helps keep your counter tidy.

5. Operating Instructions

The DOMO DO745MF offers three functions: hot froth, cold froth, and heating milk without frothing.



Image: An interior view of the frother jug, clearly showing the 'MAX' fill line for frothing (150 ml) and the 'MAX' fill line for heating (300 ml), along with the 'MIN' line.

1. **Add Milk:** Pour cold milk into the frother jug. Observe the internal markings:
    - For **milk foam**: Do not exceed the lower 'MAX' line (approx. 150 ml).
    - For **hot milk without frothing**: Do not exceed the upper 'MAX' line (approx. 300 ml).
    - Always ensure milk is above the 'MIN' line.
2. **Insert Whisk:** Place the desired whisk onto the pin at the bottom of the jug. Use the frothing whisk for foam, and the stirring whisk for heating without foam.
3. **Secure Lid:** Place the transparent lid firmly on the jug.

4. **Place on Base:** Position the frother jug onto the power base. The 360° rotating jug allows for easy placement from any angle.
5. **Select Function:**



Image: A close-up of the main control button on the frother, showing its illuminated ring, which indicates operation status.

- **Hot Froth:** Press the control button once. The indicator light will illuminate, and the frother will begin heating and frothing. The process takes approximately 2 minutes, reaching a perfect temperature of 60°C.
- **Cold Froth:** Press and hold the control button for approximately 2 seconds. The indicator light will illuminate, and the frother will begin frothing without heating.
- **Heat without Frothing:** Use the stirring whisk. Press the control button once. The indicator light will illuminate, and the frother will heat the milk without creating foam.

6. **Automatic Shut-off:** The frother will automatically switch off once the program is complete or the desired temperature is reached.
7. **Serve:** Carefully remove the jug from the base and pour the frothed or heated milk.





Image: A hand pouring freshly frothed milk from the DOMO DO745MF Milk Frother into a glass, demonstrating the ease of serving.

6. Maintenance and Cleaning

Regular cleaning ensures the longevity and hygiene of your milk frother.

- **Always unplug** the appliance from the power outlet and allow it to cool down completely before cleaning.
- **Frother Jug:** The double-walled jug has a non-stick coating, making it easy to clean. Rinse the inside of the jug immediately after use with warm water. For thorough cleaning, use a soft sponge and mild dish soap. Do not use abrasive cleaners or scouring pads, as these can damage the non-stick coating.
- **Whisps:** Remove the whisks and wash them with warm soapy water. Rinse and dry thoroughly.
- **Lid:** Wash the transparent lid with warm soapy water and rinse.
- **Power Base:** Wipe the exterior of the power base with a soft, damp cloth. Never immerse the power base, cord, or plug in water or any other liquid.
- **Storage:** Store the cleaned and dried frother in a cool, dry place.

7. Troubleshooting

If you encounter issues with your DOMO DO745MF Milk Frother, consult the following common problems and solutions:

Problem	Possible Cause	Solution
Frother does not turn on.	No power supply.	Ensure the power cord is securely plugged into a working outlet and the frother base.
Milk is not frothing or frothing poorly.	Incorrect whisk used; too much or too little milk; type of milk.	Ensure the frothing whisk is correctly inserted. Check milk levels against MIN/MAX lines. Use cold, fresh milk (full-fat milk generally froths best).
Milk is not heating.	Incorrect function selected; too much milk.	Ensure you have pressed the button for hot froth/heating. Check milk level does not exceed the 'MAX' line for heating.
Burnt smell or residue.	Milk residue left in jug; jug not cleaned properly.	Clean the jug thoroughly after each use, especially the bottom surface, to prevent milk from burning on.

8. Specifications

Feature	Detail
Brand	Domo
Model Number	DO745MF
Color	Matt grey
Product Dimensions	16 x 16 x 19.3 cm
Item Weight	600 g
Capacity (Milk Foam)	Max 150 ml
Capacity (Hot Milk)	Max 300 ml
Power / Wattage	500 watts
Material	Metal
Optimal Temperature	60°C
Features	Automatic shut-off, Non-slip feet, 360° rotating jug, Cable storage

9. Warranty and Support

Your DOMO DO745MF Milk Frother comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including the warranty period and coverage details.

For technical support, service, or questions regarding your product, please contact DOMO customer service through the contact information provided on the official DOMO website or your purchase documentation. When contacting support, please have your model number (DO745MF) and proof of purchase ready.

© 2024 Domo. All rights reserved.