Sunseeker V3 Plus

Sunseeker V3 Plus Robotic Lawn Mower User Manual

Model: V3 Plus

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Sunseeker V3 Plus Robotic Lawn Mower. Please read this manual thoroughly before using the product and keep it for future reference.



Figure 1: Sunseeker V3 Plus Robotic Lawn Mower. This image shows the top-down view of the robotic lawn mower, highlighting its sleek design and integrated controls.

Safety Information

Always adhere to the following safety guidelines to prevent injury or damage to the product and property:

- Read all instructions before operation.
- Keep hands and feet away from the cutting blades.
- Do not operate the mower in wet conditions or during rain. The mower is IPX5 water-resistant for cleaning, but not for operation in heavy rain.
- Ensure the charging station is placed on a level surface with good Wi-Fi reception.
- Keep children and pets away from the mowing area during operation. The mower's quiet operation (55 dB) makes it less disruptive, but supervision is still advised.
- Regularly inspect the mower for damage, especially the blades. Replace worn or damaged parts immediately.
- Disconnect power before performing any maintenance or cleaning.

Product Overview

The Sunseeker V3 Plus is an advanced robotic lawn mower designed for efficient and autonomous lawn care. Key features include:

- **One-Button Operation:** Effortless start with a single press.
- **AI Vision System:** Dual-eye AI for 3D obstacle detection (over 160 types) and intelligent navigation.
- **Slope Handling:** Capable of climbing slopes up to 22° (42% incline).
- **Precise Edge Cutting:** Visual AI technology ensures accurate boundary detection for clean edges.
- **Quiet Operation:** Operates at a low noise level of 55 dB, making it pet-friendly.
- **Multi-Zone Navigation:** Navigates multiple garden zones using magnetic panels or virtual boundaries.
- **Automatic Charging & Rain Detection:** Returns to the charging station when battery is low or rain is detected.
- **Smart App Control:** Intuitive app for scheduling, settings adjustment, and over-the-air (OTA) updates.
- **IPX5 Water Protection:** Allows for easy cleaning.



Figure 2: AI Vision for obstacle avoidance. This image illustrates the mower's AI vision system detecting and avoiding obstacles like flowers, ensuring precise mowing without damage.




Figure 3: Mower demonstrating slope capability and cutting dimensions. This image shows the mower operating on an incline, alongside diagrams indicating its 18cm cutting width and adjustable cutting height from 20mm to 60mm.

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Verify all parts are present according to the packing list.
2. **Charging Station Placement:**
   Place the charging station on a flat, level surface in an area with reliable Wi-Fi signal. Ensure there is sufficient clear space around the station for the mower to dock easily.



Figure 4: Front view of the Sunseeker V3 Plus. This image provides a clear view of the mower's front, useful for understanding its orientation during charging station setup.

3. **Initial Charging:** Connect the charging station to a power outlet. Place the mower onto the charging station. Allow the mower to fully charge before its first operation.

4. **App Installation & Pairing:**
   Download the "Sunseeker Robot" app from your device's app store. Follow the in-app instructions to pair your mower. This typically involves connecting to the mower's Wi-Fi network and then to your home Wi-Fi.



Figure 5: Smartphone displaying the Sunseeker app. This image shows a hand holding a smartphone with the Sunseeker app interface, demonstrating the ease of one-click setup and control.

5. **Defining Boundaries (Optional):** While the mower uses AI vision for navigation, magnetic strips can be used to define virtual boundaries for specific areas where visual identification might be difficult. Place these strips as needed to guide the mower.

Operating Instructions

1. **Starting Mowing:**
   Press the "Start" button on the mower or initiate mowing via the "Sunseeker Robot" app. The mower will begin its operation, mapping and navigating your lawn.
2. **Scheduling Mowing:**
   Use the app to set a regular mowing schedule. You can customize mowing times and days to suit your preferences. The mower will automatically start and return to its charging station as scheduled.



Figure 6: Sunseeker app interface for scheduling. This image displays the app's control panel, showing options for remote operation, cutting distance, and a weekly mowing schedule, along with rain delay settings.

3. **Obstacle Avoidance:**
   The mower's AI Vision system continuously scans its environment to detect and avoid obstacles. It learns and adapts to new objects in your garden for a smooth and safe mowing experience.
4. **Multi-Zone Management:**
   If your garden has multiple distinct zones, the mower can navigate between them. Use the app to define these zones for comprehensive coverage.
5. **Automatic Return:**
   The mower will automatically return to its charging station when its battery is low or if rain is detected. This ensures continuous operation and protects the device from adverse weather.



Figure 7: Mower demonstrating rain detection and IPX5 water resistance. This image shows the mower's sensors detecting rain and its ability to withstand water for cleaning, highlighting its durability and automatic return feature.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your Sunseeker V3 Plus.

- **Cleaning:**
  The mower has an IPX5 water protection rating, allowing for easy cleaning. Use a hose to rinse the underside and remove grass clippings. Ensure the mower is powered off and disconnected from the charging station before cleaning.




Figure 8: Underside view of the mower, showing the cutting blades. This image provides a clear view of the mower's blades, essential for understanding how to clean and replace them.

- **Blade Replacement:**
  Inspect the blades regularly for wear and tear. Dull or damaged blades can affect cutting performance. Replace blades as needed using the provided spare blades and screws. Always wear protective gloves when handling blades.
- **Software Updates:**
  Ensure your mower's software is up-to-date through the app's over-the-air (OTA) update feature. This provides performance improvements and new functionalities.

Troubleshooting

If you encounter issues with your Sunseeker V3 Plus, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Mower not starting	Low battery; Not on charging station; Safety switch off.	Ensure battery is charged; Place on charging station; Check safety switch.
Poor cutting performance	Dull or damaged blades; Excessive grass height; Clogged cutting deck.	Replace blades; Mow more frequently or adjust cutting height; Clean underside of mower.
Mower gets stuck frequently	Obstacles not detected; Uneven terrain; Boundary issues.	Clear mowing area of small obstacles; Ensure AI vision sensors are clean; Adjust magnetic boundaries if used.
Cannot connect to app	Poor Wi-Fi signal; Incorrect pairing; App outdated.	Relocate charging station for better Wi-Fi; Re-pair device via app; Update app to latest version.

For more complex issues, please contact customer support.

Specifications

Feature	Detail
Model Number	V3 Plus (16800205-01)
Dimensions (L x W x H)	62 x 37 x 30 cm
Weight	9.4 Kilograms
Cutting Width	18 cm
Cutting Height	20 - 60 mm (Adjustable)
Max. Slope Incline	22° (42%)
Noise Level	55 dB
Water Protection	IPX5
Power Source	Battery Powered
Material	Polypropylene Plastic

Warranty

The Sunseeker V3 Plus Robotic Lawn Mower comes with a**3-year warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, refer to the warranty card included with your product or contact customer support.

Support

For any questions, technical assistance, or service requests, please contact our local customer support team. Our team is available to provide expert advice, troubleshooting, and instructions.

Contact Information:

Refer to your product packaging or the official Sunseeker website for the most up-to-date contact details for your region.

© 2025 Sunseeker. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question