**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Disney RE003000

# Disney Chatty Angel Deluxe Puppetronic User Manual

Model: RE003000

### Introduction

The Disney Chatty Angel Deluxe Puppetronic is an interactive plush toy designed to bring the character of Angel from Lilo & Stitch to life. This plush features puppet operation, allowing users to control its mouth and ears, and responds with over 50 unique sounds and movements.

Key features include:

- Interactive sounds and movements, including laughter, melodies, and sound effects.
- Touch-sensitive responses from various body parts.
- Puppet functionality for controlling mouth and ears.
- Soft, realistic design with iconic character details.




Image: The Chatty Angel Puppetronic plush toy, both inside its packaging and standing freely, showcasing its design and size.

## What's in the Box

Your Disney Chatty Angel Deluxe Puppetronic package includes:

- 1 x Chatty Angel Puppetronic Plush
- Accessories (as included by manufacturer)

## Setup

To begin using your Chatty Angel Puppetronic, follow these steps:

1. **Unboxing:** Carefully remove the Chatty Angel Puppetronic from its packaging. Retain packaging for future storage or reference.
2. **Battery Installation:** Locate the battery compartment, typically on the back or bottom of the plush. Open the compartment

using a small Phillips head screwdriver if necessary. Insert the required batteries (type and quantity usually specified on the compartment cover or packaging, generally AA or AAA). Ensure correct polarity (+/-). Close the compartment securely.

3. **Power On:** Locate the power switch, usually near the battery compartment. Switch it to the "ON" position. The toy may emit an initial sound or movement to indicate it is powered on.




Image: A detailed view of the back of the Angel Puppetronic, illustrating the opening where a hand can be inserted for puppet operation, and potentially the battery compartment.

## Operating Instructions

The Chatty Angel Puppetronic offers multiple ways to interact and play:

1. **Puppet Operation:** Insert your hand into the opening at the back of the plush. You can control Angel's mouth by moving your fingers or thumb inside. Some models also allow for movement of the ears or other features through internal mechanisms. This allows for interactive storytelling and character voice simulation.
2. **Touch Interaction:** Gently touch or squeeze different body parts of the Angel Puppetronic. The toy is designed to respond with various sounds and movements based on where it is touched. Experiment with different areas to discover all its

reactions.

3. **Sound and Movement Activation:** The toy features over 50 unique sounds and reactions. These are activated through a combination of puppet movements and touch interactions. Continue to interact with the plush to trigger new responses and keep the play engaging.




Image: The Angel Puppetronic demonstrating its ability to move its mouth and ears, highlighting its puppet functionality.



Image: The Angel Puppetronic with overlaid graphics indicating it has over 50 sounds and reactions, and responds to touch with sounds from the series.

## Maintenance

Proper care will extend the life of your Chatty Angel Puppetronic:

- **Cleaning:** Surface clean only. Use a damp cloth with mild soap to gently wipe soiled areas. Do not immerse the toy in water, as this can damage the electronic components. Allow to air dry completely.
- **Storage:** When not in use for extended periods, store the toy in a clean, dry place away from direct sunlight and extreme temperatures. Remove batteries if storing for a long time to prevent leakage.
- **Battery Replacement:** Replace batteries when sounds become distorted or movements slow down. Always use new batteries of the specified type.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| No sound or movement. | Batteries are dead or incorrectly installed. Power switch is off. | Check battery polarity and replace with new batteries. Ensure power switch is in the "ON" position. |
| Sounds are distorted or weak. | Low battery power. | Replace batteries with new ones. |
| Puppet mouth/ears not moving. | Hand not positioned correctly inside. Internal mechanism obstruction. | Ensure your hand is fully inserted and correctly manipulating the internal controls. Check for any visible obstructions. |

## Specifications

| Feature | Detail |
|---|---|
| Product Dimensions | 17.32 x 12.99 x 8.94 inches |
| Item Weight | 14.1 ounces |
| Model Number | RE003000 |
| Manufacturer Recommended Age | 6 years and up |
| Manufacturer | Famosa |




Image: The Angel Puppetronic shown alongside its approximate dimensions (34cm height, 16cm width) for reference.

## Safety Information

Please read and adhere to the following safety guidelines:

- **Small Parts Warning:** This product contains small parts that can be swallowed or inhaled. Not suitable for children under 3 years due to choking hazard.
- **Battery Safety:** Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Insert batteries with correct polarity. Remove exhausted batteries from the product. Do not short-circuit the supply terminals.
- **Supervision:** Adult supervision is recommended during play, especially for younger children.
- **Usage Environment:** Use the toy on a flat, stable surface. Avoid using near water or in excessively humid environments.

## Warranty and Support

For information regarding warranty coverage, please refer to the documentation provided with your purchase or contact the manufacturer directly. The manufacturer is Famosa.

For technical support or inquiries, please visit the official Disney or Famosa customer support website, or contact their customer service line. Keep your proof of purchase handy when contacting support.

You can often find contact information on the product packaging or the manufacturer's official website.

© 2025 Disney. All rights reserved. Manufactured by Famosa.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question



**Open the live page**

**https://manuals.plus/asin/B0DY8B6MX4**

More documents and user manuals: **https://manuals.plus/**