Mitoart DC07

Mitoart 7-inch Digital Alarm Clock (Model DC07)

Instruction Manual

Introduction

Thank you for choosing the Mitoart 7-inch Digital Alarm Clock. This device is designed to provide clear and easy-to-read time, date, and day information, along with customizable alarms and reminders. Its features are particularly beneficial for individuals who may experience memory challenges or require assistance with daily scheduling.

Product Overview

The Mitoart Digital Alarm Clock features a 7-inch display, offering various display modes and adjustable brightness. It includes a remote control for convenient adjustments and multiple ports for connectivity.



Figure 1: Front view of the Mitoart Digital Alarm Clock displaying time and date.

Setup Instructions

1. **Power Connection:** Connect the provided power adapter to the DC Power Port on the back of the clock and plug it into a standard electrical outlet. The clock will power on automatically.
2. **Stand/Mounting:** The clock includes a removable bracket for tabletop use. For wall mounting, utilize the wall-mounted hole on the back of the unit.
3. **Initial Time and Date Setting:** Upon first power-on, the clock may display default settings. Use the included remote control or the buttons on the back of the clock to navigate the menu and set the correct time and date.



Figure 2: Rear view of the clock with power input and control buttons.

Your browser does not support the video tag.

Video 1: An overview of the Mitoart Digital Alarm Clock, demonstrating its features and ease of use.

Operating Instructions

1. Setting Time and Date

- Press the **MENU** button on the remote or the back of the clock to access the settings menu.
- Use the arrow buttons (Up/Down/Left/Right) to navigate to 'Set Time' and 'Set Date'.
- Press **OK/ENTER** to select and adjust the values. Press **OK/ENTER** again to confirm.
- You can also select 'Time Mode' (12-hour or 24-hour) and 'Date Mode' (Month-Day-Year, Day-Month-Year, or Year-Month-Day).

2. Display Settings

- **Brightness Adjustment:** Navigate to 'Auto Dimming' in the menu. The display automatically darkens at 7:00 PM (50cd/) and brightens at 7:00 AM (250cd/). This feature is designed for visual comfort.
- **Language Selection:** Navigate to 'Language' to choose your preferred language.

- **Voice Announcement:** Lightly press the **OK** button on the remote or the back of the clock to hear the time announced. Supports 9 languages.



Figure 3: Menu interface for adjusting clock settings.

3. Alarm and Reminder Functions

- **Setting Alarms:** Navigate to 'Alarm' in the menu. You can set multiple alarms with options for daily, weekday, or weekend repeats.
- **Medication Reminders:** The clock supports dedicated medication reminders (Morning, Afternoon, Evening) to assist with daily medication schedules.
- **Volume Adjustment:** Adjust the alarm volume through the menu settings.

Features

- **Large Font Display:** 7-inch screen with clear, bold letters for easy readability of week, month, and date.
- **Voice Timing Function:** Press the 'OK' button for an audible time announcement in 9 supported languages.
- **Intelligent Alarm and Reminder System:** Supports multiple alarms and dedicated medication reminders for

improved daily routine management.

- **Automatic Dimming:** Display brightness adjusts automatically (darkens at 7:00 PM, brightens at 7:00 AM) for optimal viewing comfort.
- **Simple Operation:** Intuitive interface and easy setup, suitable for all users.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the display and exterior. Avoid abrasive cleaners or solvents.
- **Power:** Ensure the clock is connected to a stable power source. In case of a power outage, the internal battery memory function retains settings.
- **Placement:** Place the clock on a stable surface or mount it securely on a wall. Avoid extreme temperatures or direct sunlight.

Troubleshooting

- **Clock Not Turning On:** Ensure the power adapter is securely connected to both the clock and the power outlet.
- **Display Issues:** If the display is unclear or unresponsive, try unplugging the clock for a few seconds and then plugging it back in.
- **Remote Control Not Working:** Check the battery in the remote control. Ensure there are no obstructions between the remote and the clock.
- **Incorrect Time/Date:** Follow the 'Setting Time and Date' instructions to manually adjust the settings.

Specifications

Specification	Detail
Brand	Mitoart
Model Number	DC07
Display Type	Digital
Screen Size	7 Inches
Product Dimensions	5.6"W x 7.8"H
Power Source	Corded Electric
Special Features	Alarm, Auto Dimmable, Day Mode, LED Display, Voice Announcement Time
Item Weight	15.5 ounces (0.44 Kilograms)
Mounting Type	Tabletop

Warranty and Support

For warranty information and customer support, please refer to the product packaging or contact the manufacturer directly. Keep your purchase receipt for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question