Bosch MAF671B0

Bosch Series 6 Air Fryer MAF671B0 User Manual

Model: MAF671B0 | Brand: Bosch

1. Introduction

Welcome to the user manual for your new Bosch Series 6 Air Fryer, model MAF671B0. This appliance is designed to provide efficient and healthy cooking results using rapid hot air circulation. Please read this manual thoroughly before first use to ensure safe operation and optimal performance.
For additional support and product information, visit the official Bosch website:Bosch Home Appliances.

2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

3. Product Components

Familiarize yourself with the parts of your Bosch Air Fryer MAF671B0.



Figure 3.1: Front view of the Bosch Series 6 Air Fryer MAF671B0, showcasing its sleek black design and digital control panel.

1. **Main Unit:** The primary housing containing heating elements and fan.
2. **Control Panel:** Digital display with touch controls for temperature, time, and preset programs.
3. **Frying Basket (7.2 L capacity):** Removable basket for holding food during cooking.
4. **Crisper Plate:** Inserted into the frying basket for optimal air circulation and crisping.
5. **Viewing Window:** Illuminated window on the basket to monitor cooking progress without opening.
6. **Handle:** Ergonomic handle for safely pulling out the frying basket.



Figure 3.2: The air fryer in use, showing the illuminated viewing window on the basket, allowing users to monitor food without interruption.

4. Initial Setup and First Use

4.1 Unpacking

1. Carefully remove all packaging materials from the air fryer.
2. Check that all components are present and undamaged.
3. Keep packaging materials out of reach of children.

4.2 Cleaning Before First Use

1. Wipe the exterior of the appliance with a damp cloth.
2. Remove the frying basket and crisper plate. Wash them in warm, soapy water or place them in a dishwasher.
3. Rinse thoroughly and dry all parts completely before reassembling.



Figure 4.1: The removable frying basket and crisper plate are shown, highlighting their ease of cleaning under running water and suitability for dishwashers.

4.3 Placement

- Place the air fryer on a stable, heat-resistant surface.
- Ensure there is adequate space (at least 10 cm) around the appliance for proper ventilation.
- Do not place the appliance near walls or other appliances that are sensitive to heat.

5. Operating Instructions

5.1 Basic Operation

1. Plug the power cord into a grounded wall outlet. The appliance will beep, and the display will illuminate briefly.
2. Pull the handle to open the frying basket. Place the crisper plate inside the basket, ensuring it is properly seated.
3. Place your food onto the crisper plate in the frying basket. Do not overfill the basket.

4. Slide the frying basket back into the appliance until it clicks into place.
5. Press the power button ( ) to turn on the appliance.
6. Use the temperature (**TEMP**) and time (**TIME**) controls to set your desired cooking parameters. Use the **+** and **-** buttons to adjust values.
7. Alternatively, select one of the 7 preset programs by pressing the program selection button.
8. Press the start/pause button ( ) to begin cooking.
9. During cooking, the illuminated viewing window allows you to monitor food. The "Shake" signal will alert you when it's time to shake or turn food for even cooking.
10. Once cooking is complete, the appliance will beep. Carefully pull out the basket and remove food.



Figure 5.1: Cooked chicken and vegetables prepared in the air fryer, demonstrating the appliance's ability to cook various foods evenly.

5.2 Preset Programs

The Bosch Series 6 Air Fryer MAF671B0 features 7 preset programs for common dishes. These programs automatically set optimal time and temperature.



Figure 5.2: The digital control panel displaying various preset icons for different food types, simplifying cooking selection.

Table 5.1: Preset Program Guide

Icon	Food Type	Approx. Temperature	Approx. Time
	Fries	180°C	15-20 min
	Chicken	190°C	20-25 min
	Fish	170°C	10-15 min
	Vegetables	160°C	12-18 min
	Cake/Bake	160°C	20-30 min
	Sausages	180°C	10-15 min

Icon	Food Type	Approx. Temperature	Approx. Time
	Steak	200°C	8-12 min

Note: Cooking times and temperatures are approximate and may vary based on food quantity, size, and desired crispness. Always ensure food is cooked thoroughly.

5.3 Keep Warm Function

The air fryer includes a 'Keep Warm' function to maintain food temperature after cooking. Activate this function via the control panel after a cooking cycle is complete.

6. Cleaning and Maintenance

Regular cleaning ensures the longevity and optimal performance of your air fryer.

6.1 Cleaning the Frying Basket and Crisper Plate

- Always unplug the appliance and allow it to cool completely before cleaning.
- Remove the frying basket and crisper plate.
- These parts are dishwasher-safe. Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge.
- For stubborn food residue, soak the basket and plate in hot water with dish soap for about 10 minutes.
- Ensure all parts are thoroughly dry before reassembling or storing.

6.2 Cleaning the Interior and Exterior

- Wipe the exterior of the appliance with a damp cloth. Do not use abrasive cleaners.
- Clean the interior of the appliance with a damp cloth. For the heating element, use a cleaning brush to remove any food residue.
- Never immerse the main unit in water or any other liquid.

7. Troubleshooting Guide

If you encounter issues with your air fryer, consult the table below before contacting customer service.

Table 7.1: Common Issues and Solutions

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; power outlet malfunction; basket not fully inserted.	Ensure power cord is securely plugged in. Check the power outlet. Push the frying basket completely into the appliance.
Food is not cooked evenly.	Basket is overfilled; food not shaken/turned.	Do not overfill the basket. Shake or turn food halfway through cooking (the "Shake" signal will remind you).
White smoke coming from the appliance.	Grease residue from previous use; fatty food being cooked.	Clean the basket and crisper plate thoroughly after each use. For fatty foods, add a small amount of water to the bottom of the basket to prevent smoke.

Problem	Possible Cause	Solution
Food is not crispy.	Too much moisture in food; insufficient cooking time/temperature.	Pat food dry before air frying. Increase cooking time or temperature slightly. Ensure crisper plate is used.

8. Technical Specifications

Detailed specifications for the Bosch Series 6 Air Fryer MAF671B0.

Model: MAF671B0

Brand: Bosch

Capacity: 7.2 Liters

Power: 1800 Watts

Voltage: 230 Volts (AC)

Material: Plastic, Aluminum

Color: Black

Product Dimensions (L x W x H): 30.9 x 38.8 x 31.4 cm

Item Weight: 5.7 Kilograms

Special Feature: Dishwasher Safe parts (basket, crisper plate)

Country of Origin: China



Figure 8.1: Diagram illustrating the dimensions of the Bosch Air Fryer, including length, width, and height.

9. Warranty Information

Bosch appliances are manufactured with high-quality materials and undergo strict quality control. This product is covered by a manufacturer's warranty against defects in materials and workmanship.

- **Warranty Period:** Please refer to your purchase documentation or the official Bosch website for specific warranty duration in your region.
- **Coverage:** The warranty covers manufacturing defects under normal household use. It does not cover damage resulting from misuse, neglect, accident, alteration, or unauthorized repair.
- **Claim Process:** To make a warranty claim, retain your proof of purchase and contact Bosch customer service.

For detailed warranty terms and conditions, please visit:Bosch Warranty Information.

10. Customer Support

For further assistance, product registration, or to purchase accessories, please contact Bosch customer support.

Online Support: Visit the Bosch support page for FAQs, manuals, and service requests:Bosch Owner Support

Telephone Support: Refer to your regional Bosch website for local contact numbers.

Product Registration: Register your product to receive updates and facilitate warranty service:Register Your Bosch Product

© 2025 Bosch Home Appliances. All rights reserved.
This manual is for informational purposes only. Bosch reserves the right to make changes to products without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question