Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RM-L1313

XINFUTE HUAYU RM-L1313 Universal TV Remote Control Instruction Manual

1. Introduction

This manual provides instructions for the setup, operation, maintenance, and troubleshooting of the XINFUTE HUAYU RM-L1313 Universal TV Remote Control. This remote is designed to be compatible with various Haier TV models, including HTR-A18EN, HTR-A10, and A18E, and can be used directly for most compatible models without complex setup procedures.

2. Product Overview

The RM-L1313 is a universal replacement remote control for Haier LCD/LED TVs. It features a standard layout for TV functions, designed for ease of use. The remote control is constructed from ABS material.



Figure 2.1: Front view of the RM-L1313 remote control, showing all buttons including power, source, number pad, volume, channel, menu, and navigation controls.

Key Features:

- Universal compatibility with specified Haier TV models.
- Direct use for most models without requiring complex programming.
- Ergonomic design for comfortable handling.
- Standard TV remote functions including power, channel, volume, menu, and input selection.

3. Setup

3.1. Battery Installation

The remote control requires 2 AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 3.1: View of the remote control with the battery compartment open, illustrating correct battery placement.

3.2. Initial Use and Auto Search Function

This universal remote control is designed to work directly with most compatible Haier TV models. If the remote does not function immediately, use the Auto Search feature to configure it:

1. Ensure your TV is powered on and in playing status.
2. For LCD/LED TVs, press and hold the 'SET' key (or '1', '2', '3', '4', '5', '6' keys, depending on the remote version) until the indicator light illuminates.
3. Release the key. The remote will begin searching for the correct code.
4. Once the TV responds (e.g., volume changes, channel changes), immediately press any key to confirm the setting and stop the search.



Figure 3.2: Product packaging detailing the Auto Search function and compatible Haier TV models.

4. Operating Instructions

The RM-L1313 remote control provides standard functions for operating your Haier TV. Refer to the button layout in Figure 2.1 for specific button locations.

- **Power Button:** Press to turn the TV on or off.
- **Source/Input Button:** Selects the input source (e.g., HDMI, AV, TV).
- **Number Pad (0-9):** Directly enter channel numbers.
- **Channel Up/Down (CH+/CH-):** Changes the TV channel sequentially.
- **Volume Up/Down (VOL+/VOL-):** Adjusts the TV's volume level.
- **Mute Button:** Silences the TV audio.
- **Menu Button:** Accesses the TV's main menu for settings and options.
- **Navigation Buttons (Up, Down, Left, Right) and OK:**Used to navigate through menus and confirm selections.
- **Back/Exit Button:** Returns to the previous screen or exits the current menu.

5. Maintenance

5.1. Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's surface or internal components.

5.2. Battery Replacement

Replace batteries when the remote control's response becomes sluggish or it stops functioning. Always replace both AAA batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries, as this can lead to leakage or malfunction.

6. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly installed with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Try the Auto Search function again (refer to Section 3.2).
- **Specific buttons not working:**
  - This may indicate a compatibility issue or a need for the Auto Search function.
  - Perform a factory reset if the remote is not functioning as expected after Auto Search.

6.1. Factory Reset Function

If the remote control is not working correctly after attempting the Auto Search, a factory reset can restore it to its default settings. To perform a factory reset:

1. Press and hold the 'POWER' button and the '0' button simultaneously.
2. Hold until the indicator light flashes or confirms the reset.

3. All settings will revert to factory initial mode. You may need to perform the Auto Search again after a factory reset.

7. Specifications

Feature	Detail
Model Number	RM-L1313
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Material	ABS Material
Batteries Required	2 AAA batteries (not included)
Compatible Devices	Television (Haier HTR-A18EN, HTR-A10, A18E)
Max Number of Supported Devices	1

8. Warranty and Support

8.1. Warranty Information

This product comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.

8.2. Customer Support

All products are inspected before shipment. If you are not satisfied with your purchase or encounter any issues, please contact the seller within 24 hours of receipt. For further assistance or warranty claims, please refer to the contact information provided by your retailer or the XINFUTE brand's official support channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DYP1JTSR

More documents and user manuals: **https://manuals.plus/**