VUHIGIB ZDXYJ88

VUHIGIB 15L Collapsible Portable Washing Machine Instruction Manual

Model: ZDXYJ88

Introduction

Thank you for choosing the VUHIGIB 15L Collapsible Portable Washing Machine. This compact and efficient appliance is designed for small-volume laundry, making it ideal for travel, camping, dorms, RVs, apartments, and washing delicate items. Please read this manual thoroughly before operation to ensure safe and optimal use.

What's in the Box

Upon unpacking, please ensure all the following components are present:

- Portable Folding Laundry Machine
- Drain Hose
- Power Cord
- Drain Basket



Image: The portable washing machine, drain hose, power cord, and drain basket laid out after unboxing.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Expand the Washer:** Place the folded washing machine on a flat, stable surface. Gently pull the top rim upwards until the silicone body fully expands and locks into place. The handle can be used to assist in expanding.
3. **Connect Drain Hose:** Locate the drain outlet at the bottom of the machine. Connect the provided drain hose securely. Ensure the drain plug is inserted into the hose opening on the machine's underside to prevent water leakage during washing.
4. **Power Connection:** Plug the power cord into the designated port on the machine and then into a suitable power outlet. A blue indicator light will illuminate, signifying the machine is powered on.



Image: The VUHIGIB portable washing machine in its fully expanded state, ready for use.



Image: Underside of the washing machine, highlighting the drain hose attachment and suction feet for stability.

Operating Instructions

1. **Add Water and Detergent:** Fill the washer with water up to the "MAX" fill line indicated on the inside. Add a suitable amount of laundry detergent.
2. **Load Laundry:** Place your clothes into the washer. The 15L capacity is suitable for small items like underwear, socks, baby clothes, and delicates. Avoid overloading the machine.
3. **Select Wash Mode:** Use the intuitive one-touch control panel to select your desired cleaning mode:
    - **Spinning (3 minutes):** For removing excess moisture after washing.
    - **Speed Washing (5 minutes):** For efficient cleaning of lightly soiled items.
    - **Standard Washing (10 minutes):** For powerful stain removal and thorough cleaning.

    Press the corresponding button to start the washing program.
4. **Draining Water:** Once the wash cycle is complete, remove the drain plug from the bottom of the machine and direct the drain hose towards a sink or bucket to empty the water.

5. **Spin-Drying (Optional):** For enhanced moisture removal, insert the drain basket into the washer after draining the wash water. Place the washed clothes into the drain basket. Select the "Spinning" mode (3 minutes) on the control panel. This will spin the clothes to remove most of the moisture, speeding up air-drying. *Note: This function does not completely dry clothes; they will remain damp and require air-drying. This is not a tumble dryer.*



Image: The 15L portable washing machine actively washing clothes, demonstrating the powerful vortex action.



Image: Close-up of the control panel, showing the three cleaning mode buttons and power indicator.



Image: The separate drain basket used for spin-drying clothes.

Your browser does not support the video tag.

Video: Demonstration of the portable washing machine's operation, including filling, washing, and draining.

Maintenance

- **Cleaning:** After each use, rinse the interior of the washer and the drain basket with clean water. Wipe down the exterior with a soft, damp cloth.

- **Storage:** Ensure the machine is completely dry before collapsing for storage. Push the top rim downwards to collapse the silicone body. Wrap the drain hose around the designated area at the bottom. Store in a cool, dry place away from direct sunlight.
- **Blue Light Protection:** The blue light feature aids in deep washing protection and can improve cleanliness.



Image: The portable washing machine fully collapsed for compact storage, ideal for small spaces.

Troubleshooting

Problem	Possible Cause	Solution
Machine does not turn on.	No power supply.	Check if the power cord is securely plugged into both the machine and the power outlet. Ensure the outlet is functional.

Problem	Possible Cause	Solution
Water leaks from the bottom.	Drain plug not properly inserted or drain hose not connected.	Ensure the drain plug is firmly in place and the drain hose is correctly attached to the outlet.
Washing action is weak.	Overloaded with clothes or insufficient water.	Reduce the amount of laundry. Ensure water level is at or below the "MAX" line.
Spin-drying is ineffective.	Drain basket not properly installed or clothes are too heavy/unevenly distributed.	Ensure the drain basket is correctly seated. Distribute clothes evenly and avoid overloading. Remember, it removes moisture, not fully dries.

Specifications

Feature	Detail
Product Dimensions	12.6"D x 13"W x 13.2"H
Brand	VUHIGIB
Capacity	15 Liters
Special Features	Drum Clean, High Efficiency, Vibration Reduction
Access Location	Top Load
Color	Grey
Cycle Options	Delicates, Drain, Eco, Sanitary, Spin
Item Weight	2.86 Kilograms
Material	Silicone, TPE
Controls Type	Touch
Operation Mode	Fully Automatic
Noise Level	50 Decibels
Installation Type	Countertop
Model Name	Portable Washing Machine
Model Number	ZDXYJ88
UPC	751753653028

Warranty & Support

This product comes with a **30 Days Manufacturer Warranty**. For any support inquiries or warranty claims, please contact VUHIGIB customer service through your purchase platform.

© 2026 VUHIGIB. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question