Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Funwee W555

Funwee Electric Water Gun Instruction Manual

Model: W555

1. Introduction

Thank you for choosing the Funwee Electric Water Gun. This high-capacity, automatic water toy is designed for engaging outdoor water play. Please read this manual carefully before use to ensure proper operation and safety.

2. Safety Information

- **Choking Hazard - Small Parts:** This product contains small parts and is not suitable for children under 3 years of age.
- Do not aim at anyone's face or eyes.
- Ensure all battery compartments are securely closed to maintain water resistance.
- Use only the provided charging cable and battery.
- Adult supervision is recommended during use.

3. Package Contents

Verify that all items are present in your package:

- 1 x Electric Water Gun
- 1 x USB Charger
- 1 x Battery (Nonstandard Battery)
- 1 x Screwdriver
- 1 x Instruction Manual



Figure 1: Included components of the Funwee Electric Water Gun package.

4. Setup

Follow these steps to prepare your electric water gun for use:

4.1. Battery Installation and Charging

1. Use the provided screwdriver to open the battery compartment.
2. Insert the battery, ensuring the wires are placed correctly to the right side.
3. Close the battery compartment securely.
4. Connect the battery to the USB charger. The charger's indicator light will show charging status.
5. Once fully charged, disconnect the battery from the charger.



Figure 2: Visual guide for battery installation, water filling, and water tank attachment.

4.2. Filling the Water Tank

1. Open the lid of the water tank/clip.
2. Fill the tank with clean water.
3. Close the lid securely to prevent leaks.

4.3. Attaching the Water Tank

- Align the filled water tank with the designated slot on the water gun.
- Push the water tank firmly into place until it clicks, ensuring a secure connection.

5. Operating Instructions

Once assembled and filled, your Funwee Electric Water Gun is ready for action.

5.1. Firing the Water Gun

- Point the water gun towards your target, ensuring it is not aimed at anyone's face or eyes.
- Pull the trigger to initiate single or burst water blasts. The gun features realistic mechanical motion and sound.
- The water gun has a shooting range of approximately 26-30 feet.



Figure 3: The Funwee Electric Water Gun demonstrating its shooting range.

[redacted]

Video 1: Official Funwee video demonstrating the electric water gun in action, including firing and water tank changes.

5.2. Changing Water Tanks

- To quickly change water tanks, press the release button located near the tank connection point.
- Remove the empty tank and replace it with a pre-filled one for continuous play.

6. Maintenance

- **Cleaning:** After use, empty any remaining water from the tank and the gun. Wipe the exterior with a damp cloth. Do

not submerge the entire gun in water for cleaning.

- **Storage:** Store the water gun in a cool, dry place away from direct sunlight. Remove the battery if storing for extended periods.
- **Waterproof Design:** The water gun features an updated waterproof design to protect internal electronic components. However, avoid intentional submersion or exposing the battery compartment to excessive water.



Figure 4: Key features including the waterproof design and durable construction.

7. Troubleshooting

Problem	Possible Cause	Solution
Water gun does not fire.	Battery is low or not installed correctly.	Ensure the battery is fully charged and correctly inserted into the compartment. Check wire connections.

Problem	Possible Cause	Solution
Weak water stream.	Low water level in tank or air in the system.	Refill the water tank. Ensure the tank is securely attached and there are no air bubbles.
Water leaks from the gun.	Water tank not properly sealed or damaged.	Ensure the water tank lid is tightly closed and the tank is securely attached to the gun. Inspect for any visible damage.

If you encounter any issues not listed here, please contact Funwee customer support.

8. Specifications

Feature	Detail
Brand	Funwee
Model Number	W555
Operation Mode	Automatic
Shooting Range	26-30 feet
Water Tank Capacity	500 ml
Battery Life	Over 5000 water blasts per charge
Material	High-quality ABS Plastic
Dimensions (L x W x H)	10.5" x 12.5" x 4.5"
Recommended Age	8 - 20 years
Color	Light Black

9. Warranty & Support

Funwee is committed to providing high-quality products. If you are not 100% satisfied or find any items to be defective, damaged, or incorrect, we offer a fast replacement service.
For any questions or concerns, our customer support team is available 24/7. Please refer to the contact information provided on the product packaging or the official Funwee website for assistance.
Return Policy: This product is eligible for return/replacement within 30 days of purchase, subject to Amazon's return policy.

© 2025 Funwee. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DYXJ9WSX

More documents and user manuals: **https://manuals.plus/**