GOURMIA 70113

GOURMIA Compatible Coffee Machine

Model: 70113

1. Introduction

This manual provides detailed instructions for the safe and efficient operation of your GOURMIA Multi-Capsule Compatible Coffee Machine. This versatile 4-in-1 coffee maker is designed to brew a variety of coffee types using K-Cup, Nespresso, Dolce Gusto capsules, and ground coffee. It features automatic adapter detection and brewing volume adjustment, along with an integrated milk frother for preparing Espresso, Latte, Cappuccino, and Lungo beverages. The machine also includes convenient automatic cleaning functions for easy maintenance.

2. Important Safety Instructions

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always connect the appliance to a grounded power outlet.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep hands and cords away from hot surfaces.
- Unplug the machine from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only manufacturer-recommended accessories.
- This appliance is for household use only. Do not use outdoors.
- Exercise extreme caution when handling hot liquids and steam.

3. Package Contents

Verify that all items are present in the package:

- GOURMIA Coffee Machine Main Unit

- Water Tank (1.4L capacity)
- Milk Frother Container
- K-Cup Adapter
- Nespresso Adapter
- Dolce Gusto Adapter
- Ground Coffee Adapter
- Drip Tray



Image: The GOURMIA coffee machine with its detachable water tank and the four included adapters (K-Cup, Nespresso, Dolce Gusto, and ground coffee) displayed separately. The milk frother container is also visible on the left.

4. Product Overview

Familiarize yourself with the components of your coffee machine:



Image: The GOURMIA coffee machine in operation, brewing a latte into a clear glass mug. The control panel with illuminated buttons is visible on top, and the milk frother is attached to the side, dispensing frothed milk.

Key Components:

- **Control Panel:** Located on top, with buttons for various coffee types and functions.
- **Water Tank:** Detachable, located at the back of the machine, with a 1.4L capacity.

- **Adapter Tray:** Front-loading tray where different coffee adapters are inserted.
- **Milk Frother:** Detachable container with a dispensing tube, located on the right side of the machine.
- **Drip Tray:** Removable tray at the base to catch spills and drips.



Image: A composite image showing the four distinct coffee adapters included with the machine: one for Nespresso capsules, one for ground coffee, one for Dolce Gusto capsules, and one for K-Cup pods. Each adapter is shown with its corresponding coffee type.

5. Setup

1. **Unpacking:** Remove all packaging materials and ensure all components are present.
2. **Initial Cleaning:** Wash the water tank, milk frother, and all adapters with warm, soapy water. Rinse thoroughly and dry.
3. **Positioning:** Place the machine on a stable, level surface, away from heat sources and direct sunlight.
4. **Fill Water Tank:** Fill the water tank with fresh, cold water up to the MAX line. Reattach it securely to the machine.
5. **First Use Cycle (Priming):** Before first use, perform a rinse cycle without any coffee. Fill the water tank, place a large cup on the drip tray, and run a Lungo cycle (or longest coffee cycle) to flush the system. Repeat this process 2-3 times.

6. Operating Instructions

General Operation:

1. Ensure the water tank is filled with fresh water.

2. Plug the machine into a power outlet. The power indicator light will illuminate.
3. Wait for the machine to heat up (indicator light will stop blinking or turn solid).

Using Coffee Adapters:

The machine automatically detects the inserted adapter and adjusts brewing parameters.

1. Pull out the adapter tray from the front of the machine.
2. Insert the desired adapter:
    - **K-Cup Adapter:** Place a K-Cup pod into the adapter.
    - **Nespresso Adapter:** Insert a Nespresso-compatible capsule into the adapter.
    - **Dolce Gusto Adapter:** Insert a Dolce Gusto-compatible capsule into the adapter.
    - **Ground Coffee Adapter:** Fill the adapter with your preferred ground coffee, ensuring it is not overfilled or tamped too tightly.
3. Push the adapter tray back into the machine until it clicks into place.
4. Place your cup on the drip tray.
5. Select your desired coffee type (e.g., Espresso, Lungo) from the control panel. The machine will begin brewing.

Making Latte or Cappuccino:

1. Fill the milk frother container with cold milk (dairy or non-dairy) up to the MAX line.
2. Attach the milk frother to the side of the machine, ensuring the dispensing tube is positioned over your cup.
3. Insert your coffee adapter with the desired coffee (as described above).
4. Place your cup on the drip tray.
5. Select 'Latte' or 'Cappuccino' from the control panel. The machine will first brew the coffee, then automatically dispense frothed milk into your cup.
6. After use, perform the automatic cleaning cycle for the milk frother (see Maintenance section).

7. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your coffee machine.

Daily Cleaning:

- **Drip Tray:** Empty and rinse the drip tray after each use or when the indicator floats up.
- **Water Tank:** Empty any remaining water and rinse the tank daily. Refill with fresh water before each use.
- **Adapters:** Remove and rinse the used adapter after each brew.

Milk Frother Automatic Cleaning:

1. After making a milk-based drink, place an empty cup under the milk dispensing tube.
2. Press the dedicated milk frother cleaning button (refer to your control panel for the specific icon).
3. The machine will flush hot water through the milk tube to clean it.
4. For thorough cleaning, detach the milk frother container and wash all parts with warm, soapy water.

Descaling:

Descaling is essential to remove mineral buildup and maintain machine efficiency. Perform descaling every 2-3 months, or more frequently if you have hard water.

1. Empty the water tank and fill it with a descaling solution mixed according to the manufacturer's instructions, or use a mixture of white vinegar and water (1:1 ratio).
2. Place a large container under the coffee spout.
3. Run several Lungo cycles until the water tank is empty.
4. Rinse the water tank thoroughly and refill with fresh water.
5. Run several more Lungo cycles with fresh water to flush out any remaining descaling solution.

8. Troubleshooting

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Machine does not turn on	Not plugged in; Power outlet malfunction	Check power cord connection; Try a different outlet
No coffee dispenses	Water tank empty; Adapter not inserted correctly; Machine not primed	Fill water tank; Reinsert adapter; Perform priming cycle
Coffee is weak or watery	Insufficient coffee in adapter; Incorrect grind size (for ground coffee); Descaling needed	Ensure proper coffee amount; Use finer grind; Descale machine
Milk not frothing properly	Milk frother dirty; Insufficient milk; Cold milk not used	Clean milk frother thoroughly; Ensure milk is above MIN line; Use cold milk
Machine leaks	Water tank not seated correctly; Drip tray full	Ensure water tank is secure; Empty drip tray

9. Specifications

- **Brand:** No Brand (GOURMIA)
- **Model Number:** 70113
- **Color:** Black
- **Product Dimensions:** 11 Depth x 26 Width x 29 Height cm
- **Included Components:** Adapter for ground coffee (and other capsule adapters)
- **Number of Items:** 1
- **Date First Available on Amazon.co.jp:** March 2, 2025

10. Warranty and Support

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the

documentation included with your purchase or contact the retailer. For technical support or service inquiries, please contact the customer service department of your place of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question