Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Eureka W0007

Eureka NEW730BK Cordless Wet Dry Vacuum Cleaner Roller Brush Combo User Manual

Model: W0007

1. Product Overview

This document provides instructions for the Eureka NEW730BK Cordless Wet Dry Vacuum Cleaner Specialized Roller Brush Combo. This roller brush is designed exclusively for the Eureka NEW730BK cordless wet dry vacuum, serving as a replacement or spare part to maintain optimal cleaning performance.

The specialized roller brush is engineered to effectively clean various floor types, including hardwood, by efficiently picking up both wet and dry debris.

2. Components

The Eureka NEW730BK Roller Brush Combo includes the following components:

- One (1) Specialized Roller Brush for the Eureka NEW730BK Cordless Wet Dry Vacuum.





Image 1: The Eureka NEW730BK Specialized Roller Brush Combo, showing the main brush and a smaller brush component.

3. Installation Instructions

Follow these steps to install or replace the roller brush in your Eureka NEW730BK Cordless Wet Dry Vacuum Cleaner:

1. **Power Off:** Ensure the vacuum cleaner is turned off and unplugged from its charging base before beginning any installation or maintenance.
2. **Access Brush Head:** Place the vacuum on a flat surface. Locate the brush head cover on the bottom of the

vacuum's cleaning head.

3. **Open Brush Cover:** Depending on your specific NEW730BK model, there may be latches or a release button to open the brush cover. Refer to your main vacuum manual for precise instructions on opening the brush head compartment.
4. **Remove Old Brush:** Carefully lift out the existing roller brush from its compartment. Note its orientation for correct installation of the new brush.
5. **Insert New Brush:** Align the new Eureka NEW730BK Specialized Roller Brush with the designated slots in the brush head compartment. Ensure the ends of the brush fit securely into their respective holders.
6. **Close Brush Cover:** Securely close the brush head cover until it clicks into place. Verify that the cover is properly sealed to prevent debris from entering the motor housing.



Image 2: The Eureka NEW730BK Roller Brush installed in the vacuum's cleaning head, demonstrating its function on various wet and dry debris.

4. Operating Instructions

Once the roller brush is correctly installed, the Eureka NEW730BK Cordless Wet Dry Vacuum is ready for operation. The specialized roller brush is designed to work seamlessly with the vacuum's wet and dry cleaning functions.

- **Wet Cleaning:** For wet messes, ensure the clean water tank is filled and the dirty water tank is empty. The roller brush will effectively scrub and absorb liquids and debris.
- **Dry Cleaning:** For dry debris, the roller brush efficiently sweeps particles into the vacuum's suction path.
- **Optimal Performance:** For best results, move the vacuum at a steady pace across the floor. Avoid excessive pressure, allowing the brush and suction to do the work.

5. Maintenance

Regular maintenance of the roller brush is essential for maintaining the cleaning efficiency and longevity of your Eureka NEW730BK vacuum.

1. **Daily Cleaning (After Each Use):**
    - Remove the roller brush from the vacuum (refer to Installation Instructions).
    - Rinse the roller brush under running water to remove any trapped hair, debris, or residue.
    - Use a soft brush or your fingers to dislodge stubborn particles.
    - Allow the roller brush to air dry completely in an upright position before reinstalling it into the vacuum. Do not expose to direct sunlight or high heat.
2. **Monthly Inspection:**
    - Inspect the roller brush for any signs of wear, damage, or excessive fraying.
    - Check the brush ends for any hair or string entanglement that might impede rotation. Remove any such obstructions.
3. **Replacement:** The roller brush should be replaced every 3-6 months, or sooner if significant wear or damage is observed, to ensure optimal cleaning performance.

6. Troubleshooting

If you experience issues related to the roller brush, consider the following:

- **Reduced Cleaning Performance:**
    - **Cause:** Clogged or dirty roller brush, worn-out brush.
    - **Solution:** Clean the roller brush thoroughly as per maintenance instructions. If the brush is visibly worn, replace it with a new Eureka NEW730BK Specialized Roller Brush.
- **Brush Not Rotating:**
    - **Cause:** Hair or debris entangled around the brush ends, improper installation, or a foreign object obstructing rotation.
    - **Solution:** Remove the brush and clear any obstructions. Ensure the brush is correctly installed and seated in its compartment. Check the vacuum's brush motor area for any blockages.
- **Unusual Noise from Brush Head:**
    - **Cause:** Debris caught in the brush, damaged brush, or improper installation.
    - **Solution:** Inspect the brush for foreign objects. If the brush appears damaged, replace it. Reinstall the brush to ensure it is properly seated.

7. Specifications

Feature	Detail
Brand	Eureka
Model Name	Eureka NEW730BK Roller Brush
Item Model Number	W0007
UPC	840296515716
Product Dimensions	10"L x 3"W x 15"H (Approximate, for packaging)
Color	Gray
Recommended Uses	Hardwood floors
Special Feature	Specialized for Wet/Dry vacuuming
Included Components	Accessory Kit (1 Roller Brush)
Manufacturer	Eureka

8. Warranty and Support

Specific warranty information for this accessory is typically provided with the main Eureka NEW730BK Cordless Wet Dry Vacuum Cleaner or can be found on the official Eureka website. For detailed warranty terms, product registration, or customer support, please visit the Eureka official website or contact their customer service department.

Online Support: Visit the Eureka Store on Amazon

© 2025 Eureka. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZ1V1KR7

More documents and user manuals: **https://manuals.plus/**