advwin HF-02

advwin HF-02 Oscillating Tower Fan and Heater Combo with Humidification

User Manual

1. INTRODUCTION

Thank you for purchasing the advwin HF-02 Oscillating Tower Fan and Heater Combo with Humidification. This appliance is designed to provide year-round comfort, offering powerful cooling, efficient heating, and effective humidification. Please read this manual thoroughly before operation to ensure safe and optimal performance.

Figure 1: advwin HF-02 Multi-functional Appliance Overview. This image illustrates the unit's capabilities including humidification, cooling, and heating, highlighting its 4-in-1 design.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this appliance.

- This appliance is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap.
- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas, and similar indoor locations.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect the heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always unplug the heater when not in use.
- Keep the water tank clean and refill with clean water only.
- Do not operate the humidification function without water in the tank.
- Ensure the appliance is placed on a stable, level surface to prevent tipping.

Figure 2: Multiple Protection Features. This image highlights the built-in safety mechanisms such as overheat protection (113°F), tip-over protection (15°), water shortage alert, and UL certification, ensuring safe operation.

3. PRODUCT FEATURES

- **Multi-Functional Design:** Combines fan, heater, and humidifier functions for year-round climate control.
- **Rapid Heating:** Advanced PTC ceramic heating technology provides instant warmth in approximately 1 second.
- **Efficient Cooling:** Offers 3 fan speed settings for refreshing cool air.

- **Wide Oscillation:** 120° wide-angle oscillation ensures even distribution of airflow across a room.
- **Quiet Operation:** Operates at less than 25dB, suitable for bedrooms and offices.
- **Smart Humidification:** Features a 4L water tank for up to 16 hours of continuous humidification, with a low-water reminder.
- **Safety Protections:** Includes tip-over protection, overheating protection, and water shortage alert. UL certified.
- **Convenient Control:** Intuitive touch panel and remote control for easy adjustment of settings.
- **12-Hour Timer:** Allows for scheduled operation and automatic shutdown.

Figure 3: Fan and Heater Modes. This image illustrates the appliance's dual functionality as a cooler fan (3 modes, 60W) and a space heater (2 modes, 1500W).

Figure 4: 120° Wide-Angle Oscillation. This image visually compares the wide coverage of the advwin HF-02's oscillation feature against a static unit, showing efficient air distribution.

Figure 5: Upgraded Powerful Motor. This image provides an internal view of the motor, highlighting its high airflow (620L/s) and air speed (25ft/s) capabilities for strong and cooling wind.

Figure 6: Efficient PTC Heating. This image displays the PTC heating elements, emphasizing ultra-quiet operation (30dB) and rapid 1-second warm-up time for a restful room.

4. SETUP AND ASSEMBLY

1. **Unpacking:** Carefully remove the appliance from its packaging. Retain packaging materials for future storage or transport.
2. **Placement:** Place the tower fan on a firm, level surface. Ensure there is at least 1 foot (30 cm) of clear space around the unit for proper airflow. Do not place near curtains or other objects that could block air intake or exhaust.

3. **Power Connection:** Ensure the appliance is switched off before plugging it into a standard 120V, 60Hz electrical outlet.

4. **Humidification Setup:**

   - Locate the water tank at the bottom rear of the unit.
   - Remove the water tank and fill it with clean, distilled water. Do not exceed the maximum fill line.
   - Optional: Place the provided ice packs (if applicable) into the water tank for enhanced cooling.
   - Securely reinsert the water tank into the unit.

Figure 7: Water Tank and Ice Packs. This image demonstrates the 4L water tank and the optional use of ice packs, illustrating the process of filling the tank from a tap and placing ice packs inside.

5. OPERATING INSTRUCTIONS

The advwin HF-02 can be operated using the touch control panel on the unit or the included remote control.

5.1 Control Panel and Remote Control

Familiarize yourself with the buttons on the control panel and remote control. Common functions include Power, Mode (Fan/Heat/Humidify), Speed, Oscillation, and Timer.

5.2 Power On/Off

- Press the **Power** button once to turn the unit on.
- Press the **Power** button again to turn the unit off.

5.3 Mode Selection

Press the **Mode** button to cycle through the available modes:

- **Fan Mode:** Provides cooling air. There are 3 fan speed settings (Low, Medium, High).
- **Heating Mode:** Provides warm air. There are 2 heating speed settings.
- **Humidification Mode:** Disperses mist to increase humidity. Can be used independently or with fan/heating modes.

5.4 Speed Adjustment

- In Fan Mode, press the **Speed** button to select between Low, Medium, and High fan speeds.
- In Heating Mode, press the **Speed** button to select between the two heating levels.

5.5 Oscillation Function

- Press the **Oscillation** button to activate the 120° wide-angle oscillation.
- Press the button again to stop oscillation at the current position.

5.6 Timer Setting

- Press the **Timer** button to set the desired operating duration.
- Each press typically increases the timer by 1 hour, up to a maximum of 12 hours.
- The unit will automatically turn off once the set time has elapsed.

Figure 8: Intelligent 12H Timer. This image illustrates the 12-hour timer function, allowing users to set the device to run automatically for a specified duration, promoting undisturbed sleep.

6. MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your appliance.

- **Cleaning the Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure the unit is unplugged before cleaning.

- **Cleaning the Air Filter:** The unit may have an air filter. Refer to the diagram in the manual (if provided) to locate and clean it. A clogged filter can reduce efficiency.
- **Water Tank Cleaning:**

    - Empty and rinse the water tank regularly, especially if using the humidification function frequently.
    - To prevent mineral buildup and mold, clean the tank with a mild detergent and water, then rinse thoroughly.
    - Allow the tank to air dry completely before reinserting.

- **Storage:** When not in use for extended periods, unplug the unit, clean it, and store it in a cool, dry place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on.	No power, power cord not plugged in, tip-over switch activated, overheat protection activated.	Check power outlet. Ensure cord is securely plugged in. Place unit on a flat, stable surface. Allow unit to cool down if overheat protection was triggered.
No heat/cool air.	Incorrect mode selected, fan speed too low, air intake/exhaust blocked.	Select appropriate mode (Heating/Fan). Increase fan/heating speed. Clear any obstructions from air inlets/outlets.
No mist from humidifier.	Water tank empty, water tank not properly installed, humidifier function not activated.	Refill water tank. Ensure water tank is correctly seated. Activate humidification mode.
Unit makes unusual noise.	Foreign object inside, unit not on a level surface.	Unplug and check for foreign objects. Ensure unit is on a stable, level surface.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Model Number	HF-02
Power Supply	120V, 60Hz
Heating Power	1800W
Fan Speeds	3 (Low, Medium, High)
Heating Speeds	2
Oscillation Angle	120°
Humidifier Water Tank Capacity	4L
Max Humidification Time	Up to 16 hours
Noise Level	<25dB (Fan Mode), ~30dB (Heating Mode)
Timer	12-hour

Coverage Area	Up to 400 sq. ft.
Product Dimensions	11.4"D x 9.4"W x 33.2"H
Item Weight	13.5 pounds
Material	Acrylonitrile Butadiene Styrene
Safety Certifications	UL listed

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact advwin customer service. Please have your model number (HF-02) and purchase details ready when contacting support.

You can typically find contact information on the advwin official website or through your purchase platform.