Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE 22/207FD

User Manual for XINFUTE Replacement Remote Control

Models: 22/207FD, 22/207F, 24/207DVDB

1. Introduction

This manual provides instructions for the XINFUTE replacement remote control, designed for compatibility with various Alba LCD TV, DVD, and USB models, including 22/207FD, 22/207F, and 24/207DVDB. This remote offers a direct replacement solution, requiring no complex programming or pairing.

Key Features:

- Direct replacement, no pairing required.
- Compatible with specified Alba LCD TV/DVD/USB models.
- Durable ABS material construction.

2. Package Contents

Upon opening the package, you should find the following item:

- 1 x XINFUTE Replacement Remote Control (batteries are not included)

3. Setup

3.1 Battery Installation

The remote control requires two (2) AAA batteries for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Rear view of the remote control showing the open battery compartment with two AAA batteries correctly inserted. The battery cover is shown detached.

Note: Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.

4. Operating Instructions

This remote control is designed to function immediately with compatible Alba LCD TV, DVD, and USB models without any programming. Simply point the remote at your device and press the desired button.



Image: Front view of the XINFUTE replacement remote control, displaying the layout of all buttons including power, number pad, navigation, volume, channel, and media controls.

4.1 Basic Functions

- **Power Button ( ):** Turns the TV/device on or off.
- **Number Buttons (0-9):** Select channels directly.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the channel up or down.
- **MENU:** Accesses the main menu of your TV/device.
- **OK:** Confirms selections within menus.
- **Navigation Arrows (▲▼◀▶):** Navigate through menus and options.

- **SOURCE:** Changes the input source (e.g., HDMI, AV, USB).
- **EXIT:** Exits the current menu or function.
- **DTV/RADIO/USB/DVD:** Dedicated buttons for specific modes or inputs.
- **Media Control Buttons (Play, Pause, Stop, Fast Forward, Rewind, Next, Previous):**Control playback for DVD or USB media.

5. Maintenance

Proper care will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and corrosion. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote, expose it to extreme temperatures, or immerse it in water.

6. Troubleshooting

If you experience issues with your remote control, try the following troubleshooting steps:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with new ones.
  - Ensure there are no obstructions between the remote control and the TV/device's infrared receiver.
  - Make sure you are within the effective range of the TV/device.
- **Specific Buttons Not Working:**
  - This may indicate a dirty or worn button contact. Try pressing the button firmly. If the issue persists, the remote may require replacement.
- **Interference:**
  - Bright light sources (like direct sunlight or strong fluorescent lights) can sometimes interfere with infrared signals. Try operating the remote in a different lighting condition.

If these steps do not resolve the issue, please refer to the Warranty and Support section for further assistance.

7. Specifications

Feature	Detail
Product Dimensions	6 x 3 x 1 inches (approximately)
Item Weight	2.82 ounces (approximately)
Material	ABS Material
Power Source	2 x AAA batteries (not included)

Connectivity Technology	Infrared
Compatible Devices	Alba LCD TV, DVD, USB (models 22/207FD, 22/207F, 24/207DVDB)

8. Warranty and Support

8.1 Warranty Information

This XINFUTE remote control comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.
The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or improper battery installation.

8.2 Customer Support

All products are inspected before shipment. If you are not satisfied with your purchase or encounter any issues, please contact the seller within 24 hours of receipt of your purchase for assistance.
For further inquiries or support, please refer to the contact information provided by your retailer or the XINFUTE official store page on Amazon.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZ5GYMCV

More documents and user manuals: **https://manuals.plus/**