Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Uetmulik DN-34A

Uetmulik 9 Button 5 Pin Massage Remote Model DN-34A User Manual

For Massage Recliner Sofa Chairs

Introduction

This manual provides instructions for the proper installation, operation, and maintenance of your Uetmulik 9 Button 5 Pin Female Massage Remote, Model DN-34A. This remote is designed as a replacement for specific massage recliner and sofa chair systems, offering control over chair movement, heat, and massage functions. Please read this manual thoroughly before use to ensure correct operation and to prevent damage.

Important Safety Information

- Ensure the power to the recliner or sofa chair is disconnected before attempting installation or replacement of the remote control.
- Do not expose the remote control to water or excessive moisture.
- Do not attempt to open or repair the remote control yourself. Refer to qualified personnel for service.
- Verify compatibility before connecting. This remote is specifically designed for systems requiring a DN-34A model with a 5-pin female connector.

Package Contents

- 1 x Uetmulik 9 Button 5 Pin Massage Remote Model DN-34A

Product Overview

The Uetmulik DN-34A remote control features 9 buttons and a 5-pin female connector, along with a USB port for charging compatible devices. It is designed to control the open/close, heat, and massage systems of your recliner or sofa chair.



Image: Front view of the Uetmulik DN-34A remote, showing the power button, heat settings (H, M, L), time settings (10, 20, 30), intensity (INT), heat mode (HEAT MODE), massage modes (M1, M2, M3), and chair movement buttons (LIFT, RECLINE).

Setup

1. **Verify Compatibility:** Ensure your original remote's circuit board has the code DN-34A and that its design and button layout are identical to this replacement remote. This remote cannot replace model DN-34C.
2. **Disconnect Power:** Unplug your massage recliner or sofa chair from the wall outlet to prevent electrical hazards.
3. **Locate Connector:** Find the existing remote control's connection point on your chair. This is typically a 5-pin male connector.
4. **Connect New Remote:** Carefully align the 5-pin female connector of the new Uetmulik DN-34A remote with the male connector on your chair. Push firmly until it clicks into place.
5. **Restore Power:** Plug your massage recliner or sofa chair back into the wall outlet.
6. **Test Functionality:** Test all buttons on the remote to ensure proper operation.



Image: Side view of the Uetmulik DN-34A remote, highlighting the integrated USB port for charging.

Operating Instructions

Familiarize yourself with the buttons on your Uetmulik DN-34A remote:

- **Power Button ( ):** Press to turn the massage and heat functions ON or OFF.
- **Heat Settings (H, M, L):** Adjust the heat intensity to High (H), Medium (M), or Low (L).
- **Time Settings (10, 20, 30):** Set the operating time for massage and heat functions in minutes.
- **INT (Intensity):** Adjust the intensity level of the massage.
- **HEAT MODE:** Cycle through different heat modes or patterns.
- **M1, M2, M3 (Massage Modes):** Select different massage programs or patterns.

- **LIFT:** Press to raise the chair or footrest.
- **RECLINE:** Press to lower the chair or footrest.
- **USB Port:** Located on the side of the remote, this port can be used to charge compatible USB devices. Ensure the chair is powered on for the USB port to function.



Image: Angled view of the Uetmulik DN-34A remote, providing a clear perspective of all control buttons and their labels.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the remote in a dry place, away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or twisting the cable excessively to prevent internal damage.







Image: Back view of the Uetmulik DN-34A remote, showing the smooth casing and cable exit point.

Troubleshooting

- **Remote not responding:**
  - Ensure the chair is properly plugged into a working power outlet.
  - Check that the 5-pin connector is securely attached to the chair's port.
  - Verify that the remote's model code (DN-34A) matches your original remote's internal circuit board code.
- **USB port not charging:**
  - Confirm the chair's main power is ON.
  - Ensure the USB cable and device are functioning correctly.
- **Chair functions (lift/recline) not working:**
  - Check all power connections to the chair.
  - Ensure no obstructions are preventing chair movement.

Specifications

Model Number	DN-34A
Connectivity	5-Pin Female Connector, USB Port
Number of Buttons	9
Item Weight	4.8 ounces
Package Dimensions	9 x 7 x 1.5 inches
Special Feature	No Programming Required

Warranty and Support

For warranty information or technical support, please refer to the purchase documentation or contact the seller directly through the platform where the product was purchased. Ensure you have your order details and product model number (DN-34A) available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZ5RS9GC

More documents and user manuals: **https://manuals.plus/**