Dreo DR-HTF017 Black

Dreo Tower Fan TF117 User Manual

Model: DR-HTF017 Black
Brand: Dreo

1. Introduction

Welcome to the user manual for your new Dreo Tower Fan TF117. This fan is designed to provide powerful, quiet, and efficient cooling for your home or office. Please read this manual thoroughly before operation to ensure proper use, maintenance, and safety.

2. Important Safety Instructions

- Read all instructions before using this fan.
- Always unplug the fan before cleaning or servicing.
- Do not operate any fan with a damaged cord or plug.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the fan.
- Do not use outdoors.
- This fan is intended for household use only.

3. Product Overview

Familiarize yourself with the components of your Dreo Tower Fan TF117.

3.1 Package Contents

- Dreo Tower Fan TF117
- Remote Control

- User Manual

3.2 Fan Components





Image: Dreo Tower Fan TF117 and its remote control.

The image above shows the main unit of the Dreo Tower Fan TF117 along with its remote control. The fan features a sleek black design with a digital display on the top.

3.3 Control Panel & Remote Control



Image: Close-up of the fan's control panel and remote control buttons.

The fan can be controlled via the touch panel on top of the unit or the included remote control. The control panel features buttons for power, speed, mode, timer, and oscillation.

4. Setup

The Dreo Tower Fan TF117 requires minimal assembly.

4.1 Assembly Instructions

1. Carefully remove all parts from the packaging.
2. Attach the base to the main fan body. Ensure it clicks securely into place.
3. Place the fan on a firm, level surface.
4. Plug the power cord into a standard electrical outlet.

5. Operating Instructions

Your Dreo Tower Fan TF117 offers various settings to customize your cooling experience.

5.1 Power On/Off

- Press the Power button on the control panel or remote control to turn the fan on or off.

5.2 Speed Settings

The fan features 4 speed settings.

- Press the Speed button to cycle through the available fan speeds (1-4).

5.3 Modes

Choose from 3 distinct modes: Normal, Sleep, and Natural.

- Press the Mode button to switch between Normal, Sleep, and Natural modes.
- **Normal Mode:** Provides a consistent airflow at the selected speed.
- **Sleep Mode:** Operates at an ultra-quiet 28dB, gradually decreasing fan speed to promote restful sleep. The display will auto-dim after 60 seconds.
- **Natural Mode:** Simulates natural breezes by varying fan speed intermittently.

5.4 Oscillation

The fan offers 90° of smooth oscillation to cover a wider area.

- Press the Oscillation (Swing) button to start or stop the fan's oscillation feature.

5.5 Timer Function

Set the fan to automatically turn off after a specified period, up to 8 hours.

- Press the Timer button repeatedly to set the desired operating time in 1-hour increments. The display will show the remaining time.

5.6 Remote Control Usage

The remote control allows for convenient operation from a distance. Ensure the remote control has a C battery installed (included).

Your browser does not support the video tag.

Video: This video demonstrates the remote control functionality of the Dreo Tower Fan TF117, showing how to power on/off, adjust speed, change modes, and activate oscillation.

6. Maintenance

6.1 Cleaning

- Always unplug the fan before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the fan.
- Do not use abrasive cleaners or solvents.
- For internal dust, use a vacuum cleaner with a brush attachment to gently clean the air inlet and outlet grilles.

6.2 Storage

- If storing the fan for an extended period, clean it thoroughly.
- Store the fan in its original packaging or a dust-free, dry place.

7. Troubleshooting

Problem	Possible Cause	Solution
Fan does not turn on	Not plugged in; Power outlet not working; Remote control battery low	Ensure power cord is securely plugged in; Test outlet with another device; Replace remote control battery (C battery)
Weak airflow	Fan speed too low; Air inlets/outlets blocked	Increase fan speed; Clean air inlets/outlets
Fan is noisy	Fan not on a level surface; Internal dust buildup	Place fan on a flat, stable surface; Clean internal components (refer to cleaning section)
Oscillation not working	Oscillation function not activated	Press the Oscillation (Swing) button on the control panel or remote

8. Specifications

Feature	Detail
Brand	Dreo
Model Name	DR-HTF017 Black
Product Dimensions	8.03"D x 8.03"W x 36.26"H
Item Weight	6.01 pounds (2.73 Kilograms)

Feature	Detail
Power Source	Corded Electric
Noise Level	28 dB
Number of Power Levels	3 (Modes: Normal, Sleep, Natural)
Control Method	Remote, Touch
Oscillation	90°
Timer	8 Hours
Air Velocity	25ft/s
Max Airflow Coverage	29ft
Batteries Required	1 C battery (included for remote)

9. Warranty & Support

Dreo provides a warranty for this product. For detailed warranty information and to register your product for an extended warranty, please visit the official Dreo website or refer to the warranty card included in your package.

For technical support, troubleshooting assistance, or replacement parts, please contact Dreo Customer Service.

- **Official Website:** www.dreo.com
- **User Manual (PDF):** Download PDF

© 2025 Dreo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question