**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**ZdalaMit RC-824**

# ZdalaMit RC-824 Replacement Remote Control

Instruction Manual

## Introduction

This manual provides comprehensive instructions for the ZdalaMit RC-824 Replacement Remote Control, designed for seamless compatibility with the Denon TU-1500RD Audiophile FM AM Stereo Tuner. This remote offers a direct replacement solution, requiring no complex programming for immediate use.

## Package Contents

- 1 x ZdalaMit RC-824 Replacement Remote Control

*Note: 2 x AA size alkaline batteries are required and are not included in the package.*

## Setup

### Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two (2) AA size alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.




Figure 1: Angled view of the RC-824 remote control, highlighting the button layout and ergonomic design.

Once batteries are installed, the remote control is ready for use. No programming or pairing is required for operation with compatible Denon TU-1500RD tuners.

## Operating Instructions

The ZdalaMit RC-824 remote control is pre-programmed to function with the Denon TU-1500RD Audiophile FM AM Stereo Tuner. Simply point the remote control towards your tuner and press the desired function button.




CHANNEL
1
2
3
4
5
6
7
8
TUNING
UP
DOWN
SEARCH/
CHARACTER
DISPLAY
SHIFT/PTY
MEMORY
AUTO/
MANU
BAND

Figure 2: Front view of the RC-824 remote control, showing the POWER button, CHANNEL number buttons (1-8), TUNING UP/DOWN, SEARCH/CHARACTER, DISPLAY, SHIFT/PTY, MEMORY, AUTO/MANU, and BAND buttons.

## Key Functions:

- **POWER:** Turns the Denon tuner on or off.
- **CHANNEL (1-8):** Directly selects preset channels.
- **TUNING UP/DOWN:** Adjusts the tuning frequency up or down.
- **SEARCH/CHARACTER:** Initiates station search or character input for naming.
- **DISPLAY:** Toggles display information on the tuner.
- **SHIFT/PTY:** Accesses secondary functions or Program Type (PTY) modes.
- **MEMORY:** Stores current station as a preset.
- **AUTO/MANU:** Switches between automatic and manual tuning modes.
- **BAND:** Switches between FM and AM bands.



Figure 3: The RC-824 remote control positioned in a typical home entertainment environment, demonstrating its intended use with audio equipment.

*Important: This remote control is specifically designed for the Denon TU-1500RD tuner and cannot be programmed to work with televisions or other devices.*

## Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the surface of the remote. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new alkaline batteries.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Remote not working. | Dead or incorrectly inserted batteries. | Replace batteries with new AA alkaline batteries, ensuring correct polarity (+/-). |
| Remote works intermittently. | Low battery power or obstruction between remote and tuner. | Replace batteries. Ensure a clear line of sight to the Denon tuner's IR receiver. |
| Remote does not control TV. | Remote is not designed for TV control. | This remote is specifically for the Denon TU-1500RD tuner and cannot be programmed for other devices. |

## Specifications






Figure 4: Dimensions of the RC-824 remote control, indicating its compact size.

| Feature | Detail |
|---|---|
| Model | RC-824 (Replacement) |
| Compatibility | Denon TU-1500RD Audiophile FM AM Stereo Tuner |
| Power Source | 2 x AA Alkaline Batteries (not included) |

| Feature | Detail |
| --- | --- |
| Color | Black |
| Product Dimensions | 6 x 2 x 0.5 inches (approximately) |
| Item Weight | 2 ounces |
| Special Feature | Pre-Programmed (No setup required) |

## Warranty and Support

This product is a replacement remote control. For specific warranty information, please refer to the terms and conditions provided by the retailer at the time of purchase. For technical support or inquiries, please contact the seller directly through the platform where the purchase was made.

© 2025 ZdalaMit. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0DZBHZLLC**

More documents and user manuals: **https://manuals.plus/**