ALLIMITY RM-C3295-NYPY-MIC

ALLIMITY RM-C3295 Voice Remote Control User Manual

Model: RM-C3295-NYPY-MIC

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your new ALLIMITY RM-C3295 Replacement Voice Remote Control. This remote is designed to be compatible with JVC TVs and features voice control functionality for enhanced user experience.
Please read this manual carefully before using the remote control to ensure proper functionality and to avoid any issues. Keep this manual for future reference.

Product Overview





Figure 1: Front view of the ALLIMITY RM-C3295 Voice Remote Control, showing all buttons including number pad, navigation, volume, channel, and dedicated app buttons.

The RM-C3295 is a replacement voice remote control specifically designed for JVC televisions. It includes standard remote functions as well as an integrated microphone for voice commands. Key features include:

- Voice control functionality for hands-free operation.
- Dedicated buttons for popular streaming services like Netflix, YouTube, Prime Video, and YouTube Music.
- Standard TV control buttons including power, volume, channel, and navigation.
- Requires 2x AAA batteries (not included).

Setup

1. Installing Batteries

The remote control requires two AAA batteries for operation. Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Figure 2: Back view of the remote control with the battery compartment open, illustrating correct battery insertion.

2. Pairing the Remote Control

This voice replacement remote control requires pairing with your JVC TV before its voice function can be used. The exact pairing procedure may vary slightly depending on your specific JVC TV model. Please refer to your TV's user manual for detailed pairing instructions. Generally, the process involves:

- Ensuring your TV is powered on.
- Navigating to the TV's settings menu (often under "Remotes & Accessories" or "Bluetooth Settings").
- Selecting the option to "Add new device" or "Pair remote control".
- Following the on-screen prompts, which may involve pressing and holding specific buttons on the new remote (e.g., the "Home" and "Back" buttons simultaneously) until a pairing confirmation appears on the TV screen.

Important Notice: Ensure there is nothing blocking the path between your device and the remote during operation and pairing.

Operating Instructions

Once paired, your RM-C3295 remote control provides full control over your JVC TV. Below are the primary functions:

Standard TV Control

- **Power Button** ( ): Turns the TV on or off.
- **Number Pad (0-9)**: Directly input channel numbers or other numerical selections.
- **Volume Up/Down (+/-)**: Adjusts the TV's volume level.
- **Mute Button** ( ): Mutes or unmutes the TV audio.
- **Channel Up/Down (∧ / ∨)**: Changes the TV channel.
- **Navigation Pad (Up, Down, Left, Right, OK)**: Used to navigate menus and select options on the TV screen.
- **Back Button** ( ): Returns to the previous screen or menu.
- **Home Button** ( ): Accesses the TV's home screen or main menu.
- **Input/Source Button** ( ): Changes the input source (HDMI, AV, etc.).

Voice Control Function

The voice control feature allows you to issue commands to your TV using your voice. To use this function:

1. Press the **Voice Button** ( ) located near the center of the remote.

2. Hold the remote approximately 6-12 inches from your mouth.
3. Speak clearly into the microphone. Examples of commands include:
    - "Open Netflix"
    - "Search for action movies"
    - "Switch to HDMI 1"
    - "Volume up"
4. Release the Voice Button when you have finished speaking.







Figure 3: The Voice Button (microphone icon) on the RM-C3295 remote control.

Dedicated App Buttons

The remote features dedicated buttons for quick access to popular streaming applications:

- **Netflix**: Launches the Netflix application.
- **YouTube**: Launches the YouTube application.
- **Prime Video**: Launches the Amazon Prime Video application.
- **YouTube Music**: Launches the YouTube Music application.

Maintenance

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Storage

When not in use for extended periods, it is recommended to remove the batteries to prevent leakage, which can damage the remote control. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	• Low or dead batteries. • Obstruction between remote and TV. • Remote not paired (for voice functions).	• Replace batteries with new AAA batteries. • Ensure clear line of sight to the TV's IR receiver. • Re-pair the remote control with your TV (refer to TV manual).

Problem	Possible Cause	Solution
Voice function not working.	• Remote not properly paired for voice. • Microphone blocked or damaged. • TV's voice assistant settings.	• Ensure the remote is successfully paired for voice control. • Check if anything is covering the microphone hole. • Verify TV's voice assistant is enabled and configured correctly.
Buttons are sticky or unresponsive.	• Dirt or debris under buttons. • Internal damage.	• Clean the remote surface with a dry cloth. • If problem persists, consider replacing the remote.

SPECIFICATIONS

Feature	Detail
Model Number	RM-C3295-NYPY-MIC
Compatible Devices	JVC Television
Special Feature	Voice Search
Power Source	2x AAA Batteries (not included)
Color	Black
Product Dimensions	5 x 1 x 0.5 inches (12.7 x 2.54 x 1.27 cm)
Item Weight	2.61 ounces (74 grams)





Figure 4: Dimensions of the ALLIMITY RM-C3295 Voice Remote Control.

Warranty and Support

This product is a replacement remote control. For specific warranty information, please refer to the terms provided by the seller at the time of purchase. Warranty coverage, if any, is typically provided by the seller or manufacturer.
For technical support or inquiries regarding your ALLIMITY RM-C3295 remote control, please contact the seller directly through the platform where the purchase was made. Provide your order details and a clear description of the issue for prompt assistance.

© 2025 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question