oneisall H1

oneisall H1 Automatic Cat Feeder Instruction Manual

Model: H1 (Standard) | Brand: oneisall

1. Important Safety Instructions

- Read all instructions before operating the feeder.
- Keep the feeder away from children and pets during assembly and setup.
- Use only dry pet food. Do not use wet, canned, or moist pet food.
- Ensure the power adapter is securely connected and placed in a dry area.
- Install D batteries for backup power to prevent feeding interruptions during power outages.
- Do not immerse the main unit in water. Only detachable parts are washable.
- Regularly inspect the power cord for damage. If damaged, discontinue use.

2. Package Contents

Verify that all items are present in the package:

- oneisall H1 Automatic Cat Feeder Main Unit
- Food Storage Container (pre-attached)
- Dual Feeding Bowls (2 units)
- Stainless Steel Inner Bowls (2 units)
- Power Adapter (5V/1A)
- Desiccant Bag (pre-installed in lid)
- Instruction Manual

3. Product Overview

The oneisall H1 Automatic Cat Feeder is designed to provide scheduled meals for two cats, promoting harmonious feeding with its dual-bowl design.



Image: The oneisall H1 Automatic Cat Feeder, showing the main unit, food reservoir, control knob, and dual feeding bowls with food being dispensed.

Key Features:

- **Dual Bowl Design:** 16-inch separation between bowls to prevent competition between cats.
- **Large Capacity:** 5 liters (approximately 20 cups) food storage, suitable for multiple days of feeding.
- **Kibble Compatibility:** Accommodates dry food and snacks up to 0.7 inches (18 mm) in diameter.
- **Intuitive Control:** Features a simple dial/knob for programming feeding schedules.
- **Dual Power Supply:** Operates via AC adapter with a D battery backup system (3 x D batteries, not included) for uninterrupted feeding.
- **Stable Anti-Tip System:** Designed for stability to prevent accidental tipping by pets.

4. Setup

4.1 Assembly

1. Unpack all components from the packaging.
2. Attach the dual feeding bowls to the main unit by sliding them into the designated slots until they click into place.

3. Place the stainless steel inner bowls into the plastic feeding bowls.

4.2 Power Connection

1. Connect the power adapter to the feeder's power input port.
2. Plug the adapter into a standard wall outlet.
3. For backup power, open the battery compartment on the bottom of the unit and insert 3 new D-size batteries (not included), ensuring correct polarity. Close the compartment securely.



Image: The feeder connected to a wall outlet, illustrating the battery backup feature. Batteries are not included.

4.3 Filling the Food Reservoir

1. Open the lid of the food storage container.
2. Ensure the desiccant bag is properly placed in the lid to keep food fresh. Replace the desiccant bag every 1-2 months.
3. Pour dry pet food into the container. Do not overfill.

4. Close the lid securely to maintain food freshness.



Image: A hand pouring dry kibble into the transparent food reservoir of the oneisall H1 feeder, demonstrating its large capacity.

5. Operating Instructions

5.1 Setting the Current Time

Refer to the feeder's display and control knob. Rotate the knob to adjust the hour and minute, then press to confirm.

5.2 Programming Feeding Schedule

The feeder allows for up to 6 meals per day. Each meal can be programmed with 1 to 12 portions. One portion is approximately 8 grams or 1/16 cup.



Image: A hand interacting with the control knob on the feeder, indicating ease of setting.

1. Press the 'PLAN' button (or equivalent on the knob) to enter programming mode.
2. Use the knob to set the desired feeding time for the first meal. Press the knob to confirm.
3. Use the knob to set the number of portions for the first meal (1-12). Press the knob to confirm.
4. Repeat steps 2 and 3 for additional meals (up to 6).
5. Exit programming mode once all desired meals are set. The feeder will now dispense food at the scheduled times.

5.3 Manual Feeding

To dispense food manually, press and hold the manual feed button (refer to your feeder's specific button layout, often integrated with the knob) for a few seconds. Food will be dispensed immediately according to the default portion size or the last set manual portion.

5.4 Kibble Size and Type

The feeder is compatible with dry kibble and snacks up to 0.7 inches (18 mm) in diameter. Using kibble larger than this may cause blockages.



Image: A visual representation of different kibble sizes (0.3, 0.5, 0.7 inches) that are compatible with the feeder's dispensing mechanism.

6. Cleaning and Maintenance

Regular cleaning ensures hygiene and proper functioning of the feeder.

1. **Disconnect Power:** Always unplug the feeder from the power outlet and remove backup batteries before cleaning.
2. **Disassemble:** Remove the food storage container, lid, and feeding bowls from the main unit.

3. **Washable Parts:** The food storage container, lid, and feeding bowls (including stainless steel inserts) can be washed with mild soap and water. Rinse thoroughly.
4. **Main Unit:** Wipe the main unit with a soft, damp cloth. Do not immerse the main unit in water or allow water to enter electronic components.
5. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling and refilling with food.
6. **Desiccant Bag:** Replace the desiccant bag in the lid every 1-2 months to maintain food freshness.



Image: Detachable components of the feeder, including the food container, lid, and bowls, shown being cleaned under running water in a sink.

7. Troubleshooting

- **Feeder not dispensing food:**
  - Check if the feeder is powered on and connected to a power source.
  - Ensure batteries are installed correctly and have sufficient charge if using backup power.
  - Verify that the food reservoir is not empty.
  - Check for kibble blockages in the dispenser chute. Clear any obstructions.
  - Ensure kibble size is within the compatible range (less than 0.7 inches).
- **Incorrect portion sizes:**
  - Re-program the desired portion sizes according to the operating instructions.
  - Ensure the feeder is placed on a level surface.
- **Feeder not turning on:**
  - Check the power adapter connection to both the feeder and the wall outlet.
  - If using batteries, ensure they are new and inserted with correct polarity.
- **Display not working:**
  - Ensure the feeder has power.
  - Try unplugging and re-plugging the power adapter, or removing and reinserting batteries.

8. Specifications

Feature	Detail
Model Name	H1
Item Weight	4.51 pounds (2.05 Kilograms)
Product Dimensions (LxWxH)	17.5 x 8.3 x 13.3 inches
Food Capacity	5 Liters / 20 Cups
Material	Plastic, Stainless Steel
Power Supply	AC Adapter (5V/1A), 3 x D Batteries (backup)
Compatible Kibble Size	Less than 0.7 inches (18 mm)
Target Species	Cat

9. Warranty and Support

The oneisall H1 Automatic Cat Feeder comes with a**2-year warranty** from the date of purchase.

For technical assistance, troubleshooting, or warranty claims, please contact oneisall customer service. Our customer support team is available for **24-hour customer service** to assist you.

Please retain your proof of purchase for warranty validation.

© 2025 oneisall. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question