Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RM-014S+

User Manual for XINFUTE RM-014S+ Universal TV Remote Control

Model: RM-014S+

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your XINFUTE RM-014S+ Universal TV Remote Control. This remote is designed to be compatible with a wide range of LCD TVs from brands such as Samsung, Sony, Sharp, LG, and AOC, offering a convenient replacement for your original remote.



Image: The XINFUTE RM-014S+ Universal TV Remote Control, shown in its clear retail packaging, highlighting its universal compatibility.

Setup

Battery Installation

The RM-014S+ remote control requires two (2) AAA batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.

3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: The rear view of the RM-014S+ remote control with the battery compartment cover removed, showing the slots for two AAA batteries.

Initial Use

This universal remote control is designed to work immediately with most compatible TVs without requiring any programming. Simply insert the batteries and point the remote towards your television.

Operating Instructions

The RM-014S+ remote control features a standard layout for easy navigation and control of your television. Below are common functions:



Image: Front and back views of the RM-014S+ remote control, displaying the button layout on the front and the smooth ergonomic design on the back.

- **Power Button:** Located at the top left, used to turn the TV on or off.
- **Mute Button:** Located at the top right, used to mute or unmute the TV audio.
- **Number Buttons (0-9):** For direct channel selection.
- **Volume Up/Down (+/-):** Adjusts the volume level.
- **Channel Up/Down (CH +/-):** Changes the TV channel.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.

- **Menu Button:** Accesses the TV's main menu.
- **Source/Input Button:** Switches between different input sources (HDMI, AV, etc.).
- **Return/Exit Buttons:** Navigates back or exits current menus.
- **Special Function Buttons:** Includes buttons for P.MODE, GUIDE, S.MODE, DISPLAY, SLEEP, and various media playback controls (Play, Pause, Stop, Fast Forward, Rewind).

For specific functions related to your TV model, refer to your television's original user manual.

Maintenance

Cleaning the Remote

To maintain the remote control's appearance and functionality, clean it regularly:

- Use a soft, dry cloth to wipe the surface of the remote.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not spray cleaner directly onto the remote.
- Avoid using harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or internal components.

Battery Replacement

Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AAA). Dispose of used batteries responsibly according to local regulations.

Troubleshooting

If you experience issues with your RM-014S+ remote control, please refer to the following common solutions:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared receiver.
  - Make sure you are within the effective range of the TV's IR receiver.
- **Certain Buttons Not Working:**
  - This remote is a universal replacement. While it supports many functions, some highly specific or smart TV features might not be directly mapped or supported.
  - Ensure the remote is pointed directly at the TV.
- **Interference:**
  - Bright light sources, especially fluorescent lights or direct sunlight, can sometimes interfere with infrared signals. Try operating the remote in different lighting conditions.

If the issue persists after trying these steps, please refer to the Support section.

Specifications

Model Number	RM-014S+
Brand	XINFUTE
Material	ABS Material
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Batteries Required	2 AAA batteries (not included)
Connectivity Technology	Infrared
Compatible Devices	Television (Universal fit for Samsung, Sony, Sharp, LG, AOC LCD TVs)
Special Feature	Ergonomic, No Programming Required

Warranty Information

The XINFUTE RM-014S+ Universal TV Remote Control comes with a**one-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product will work as described. Please retain your proof of purchase for warranty claims.

Support

For further assistance, technical support, or if you are not satisfied with your purchase, please contact the manufacturer or seller directly. All goods are inspected before shipment. If you are not satisfied with the purchase, you can contact us within 24 hours of the receipt of your purchase.
Please have your model number (RM-014S+) and purchase details ready when contacting support.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZCHQ67D

More documents and user manuals: **https://manuals.plus/**