ChooChoo ST2201-MH

ChooChoo Farmhouse Console Table User Manual

Model: ST2201-MH

Introduction

Thank you for choosing the ChooChoo Farmhouse Console Table. This manual provides essential information for the safe and proper assembly, use, and maintenance of your new furniture. Please read it thoroughly before beginning assembly and retain it for future reference.

Important Safety Information

Always assemble the table according to the provided instructions. Use the included anti-tip bracket to secure the table to the wall to prevent tipping. Do not place heavy items on the table that could cause it to tip over. Always supervise children when they are near the table.

Product Overview

The ChooChoo Farmhouse Console Table is designed to add a vintage aesthetic to your living space, offering both style and practical storage solutions.



The ChooChoo Farmhouse Console Table, featuring a rustic oak top and black X-supports, styled in an entryway with a lamp and decorative items.



Detailed dimensions of the console table: 39.37 inches wide, 11.81 inches deep, and 31.5 inches high.

Key Features:

- **Farmhouse Aesthetic:** White and natural wood grain finish for a vintage look.
- **Large Storage Space:** Features a wide drawer for concealed storage and a slatted bottom shelf for additional items or decorations.
- **Sturdy & Durable Structure:** Constructed from strong MDF board with stable X-Frame supports for long-lasting use.



Close-up view highlighting the retro handle, classic X-design supports, and the spacious drawer of the console table.

SPECIFICATIONS

Attribute	Detail
Brand	ChooChoo
Model Name	ST2201-MH
Product Dimensions	11.81"D x 39.37"W x 31.5"H
Maximum Weight Recommendation	30 Kilograms (approx. 66 lbs)
Color	Rustic Oak & Black
Material Type	Engineered Wood
Included Components	1 x Accessory Kit, 1 x Anti-Tip Bracket, 1 x Console Table, Assembly Guide

Number of Drawers	1 (full-width)

Setup and Assembly

The ChooChoo Farmhouse Console Table is designed for straightforward assembly. An Assembly Guide is included with your product, along with all necessary parts and an accessory kit.

Assembly Steps:

1. Unpack all components and verify against the parts list in the Assembly Guide.
2. Follow the step-by-step instructions provided in the Assembly Guide. All parts are numbered for easy identification.
3. Use the included assembly tool. Additional tools recommended are a hammer and screwdriver.
4. Ensure all connections are secure before use.
5. Install the anti-tip bracket as instructed to secure the table to a wall, enhancing stability and safety.

Assembly typically takes approximately 30 minutes.

Operating Instructions

This console table is designed for indoor use as a decorative and functional piece of furniture in entryways, living rooms, or hallways.

- **Weight Distribution:** Distribute weight evenly across the tabletop and bottom shelf. Do not exceed the maximum weight recommendation of 30 kg (66 lbs).
- **Drawer Use:** The table features one full-width drawer for storing small items like keys, remotes, or personal accessories. Ensure the drawer slides smoothly and is not overloaded.
- **Shelf Use:** The slatted bottom shelf is suitable for baskets, books, or decorative items.

Care and Maintenance

Proper care will ensure the longevity and appearance of your ChooChoo Farmhouse Console Table.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean spills immediately to prevent staining. The table is not stain resistant.
- **Sunlight & Heat:** Avoid prolonged exposure to direct sunlight or extreme heat, which can cause fading or warping.
- **Stability Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.

Troubleshooting

Problem	Possible Cause	Solution
Table is wobbly/unstable.	Loose fasteners; uneven floor.	Ensure all screws are tightened. Use shims under legs if floor is uneven. Verify anti-tip bracket is installed correctly.
Drawer does not slide smoothly.	Improper rail alignment; overloaded drawer.	Check assembly instructions for correct drawer rail installation. Reduce weight in the drawer.

Missing parts during assembly.	Packaging error.	Contact ChooChoo customer service immediately with your purchase details.

Warranty and Customer Support

ChooChoo is committed to 100% customer satisfaction. If you encounter any issues with your product, or have questions regarding assembly, parts, or general use, please do not hesitate to contact our customer service team.
For support, please visit the ChooChoo Store on Amazon or refer to your purchase documentation for direct contact information.

© 2025 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question