Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RM-L1768

XINFUTE RM-L1768 Universal Remote Control Instruction Manual

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your XINFUTE RM-L1768 Universal Remote Control. This remote is designed to be compatible with various TCL LED TV models, including RC902V FMR1 and RC902V FAR1. Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.



Figure 1: Front view of the XINFUTE RM-L1768 Universal Remote Control, showing all buttons and the model number at the bottom.

Setup

1. Battery Installation

The XINFUTE RM-L1768 remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards and lift it off to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

4. Replace the battery cover by sliding it back into place until it clicks securely.



Figure 2: Back view of the remote control with the battery compartment open, illustrating the correct orientation for AAA battery insertion.

2. Initial Pairing/Programming

This remote control is designed as a replacement and is generally ready to use with compatible TCL LED TV models (RC902V FMR1, RC902V FAR1) without complex programming. If the remote does not respond immediately, ensure:

- Batteries are correctly installed and have sufficient charge.
- There are no obstructions between the remote control and the TV's infrared receiver.
- The TV is powered on.

For specific pairing instructions for your TCL TV model, refer to your television's original user manual or the manufacturer's support website. Some smart TVs may require a simple pairing process in their settings menu for full functionality, especially for voice control features (if applicable to your TV model).

Operating Instructions

The RM-L1768 remote control features a standard layout for easy navigation and control of your TCL TV. Below is a general guide to its functions:

- **Power Button ( ):** Turns the TV on or off.
- **Mute Button ( ):** Mutes or unmutes the TV audio.
- **Volume Up/Down (+/-):** Adjusts the TV volume.
- **Channel Up/Down (P+/-):** Changes TV channels.
- **Navigation Pad (Circular buttons):** Used to navigate menus and select options. The central button acts as 'OK' or 'Enter'.
- **Back Button (↩):** Returns to the previous screen or menu.
- **Home Button ( ):** Accesses the TV's home screen or smart TV interface.
- **Settings Button (⚙):** Opens the TV's settings menu.
- **Input/Source Button ( ):** Cycles through available input sources (HDMI, AV, etc.).
- **Quick Access Buttons:** Dedicated buttons for popular streaming services such as **Netflix**, **Prime Video**, **YouTube**, and **TCL Channel** for direct access.



Figure 3: Angled view of the remote control, highlighting the ergonomic design and button layout.

Maintenance

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA). Do not mix old and new batteries, or different types of batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can cause damage. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops and Impacts:** The remote control contains delicate electronic components. Avoid dropping it or subjecting it to strong impacts.

Troubleshooting

If you encounter issues with your remote control, try the following troubleshooting steps:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote and the TV's infrared sensor.
  - Point the remote directly at the TV's sensor.
- **Limited Functionality:**
  - If certain smart features or voice commands are not working, your TV might require a specific pairing process. Consult your TV's user manual.
  - Verify that your TV model is listed as compatible (RC902V FMR1, RC902V FAR1).
- **Buttons Sticking:**
  - Clean around the buttons with a dry, soft cloth to remove any dust or debris.

Specifications

Feature	Detail
Model Number	RM-L1768
Compatible Models	RC902V FMR1, RC902V FAR1 (TCL LED TVs)
Power Source	2 x AAA Batteries (not included)
Material	ABS Material
Product Dimensions	6 x 3 x 1 inches (approximately)
Item Weight	2.82 ounces (without batteries)
Special Feature	Ergonomic Design
Max Number of Supported Devices	1 (Television)

Warranty and Support

Warranty Information

Your XINFUTE RM-L1768 Universal Remote Control comes with a**one-year warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.

Customer Support

If you experience any issues that cannot be resolved using the troubleshooting guide, or if you have questions regarding your remote control, please contact XINFUTE customer support. You can typically find contact information on the product packaging or through the retailer where the product was purchased. For purchases made on Amazon, you may contact the seller directly within 24 hours of receipt if you are not satisfied with your purchase.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZHBLBCT

More documents and user manuals: **https://manuals.plus/**