Enegg AF180-Airfryer-Silicone

Enegg Silicone Air Fryer Liners Instruction Manual

Model: AF180-Airfryer-Silicone

Introduction

Thank you for choosing Enegg Silicone Air Fryer Liners. These reusable liners are designed to simplify your cooking and cleaning experience with compatible air fryers, ovens, and microwaves. Made from high-quality, food-grade silicone, they offer a non-stick surface and are heat-resistant, providing a convenient and eco-friendly alternative to disposable parchment papers.



Image: A single black silicone air fryer liner, showcasing its square shape and corrugated sides.

Setup and Compatibility

Before first use, please follow these steps:

1. **Unpack:** Carefully remove the silicone liners from their packaging.
2. **Initial Cleaning:** Wash the liners thoroughly with warm soapy water or place them in a dishwasher before their first use to remove any manufacturing residues. Rinse well and dry completely.
3. **Compatibility Check:** Ensure the liners fit properly into your appliance. These liners are specifically designed for Ninja Foodi Air Fryer models AF140, AF180, AF141, AF181, as well as Philips NA230 and COSORI 5.5L air fryers.



Image: Two black silicone air fryer liners shown with a compatible air fryer, indicating suitability for various models.

Operating Instructions

Using your Enegg Silicone Air Fryer Liners is straightforward:

1. **Placement:** Place the silicone liner directly into the air fryer basket, oven tray, or microwave-safe dish. Ensure it sits flat and does not obstruct air circulation vents if applicable.
2. **Add Food:** Place your food directly into the silicone liner. Do not overfill the liner; leave adequate space for even cooking and air circulation.
3. **Cooking:** Cook your food as per your recipe's instructions. The liners are heat-resistant up to 450°F (232°C), making them suitable for most air frying, baking, and roasting tasks.
4. **Removal:** Use heat-resistant gloves or tongs to carefully remove the liner and cooked food from the appliance after cooking.



Image: A whole roasted chicken prepared within an Enegg silicone liner, placed inside an air fryer, demonstrating its use for various dishes.



Image: A collage showing different types of food such as fried chicken, french fries, hot dogs, and pizza, illustrating the versatility of the silicone liner for various cooking applications.

Care and Maintenance

Proper care ensures the longevity of your silicone liners:

- **Cool Down:** Always allow the liner to cool down completely before attempting to clean it.
- **Hand Washing:** Wash with warm water and mild dish soap. Use a soft sponge or cloth to remove food residues.
- **Dishwasher Safe:** The silicone liners are dishwasher safe. For best results, place them on the top rack. Ensure they are oriented to allow water to drain properly.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or sharp objects, as these can damage the silicone surface.
- **Drying and Storage:** Ensure the liners are completely dry before storing them to prevent moisture buildup. They can be stacked or folded for compact storage.



Image: A silicone air fryer liner being rinsed under running water in a sink and another liner placed inside a dishwasher, demonstrating its ease of cleaning.



Image: A visual comparison showing a dirty air fryer basket (labeled 'Before') next to a clean air fryer basket with a silicone liner (labeled 'After'), highlighting the benefit of reduced cleanup.

Troubleshooting

- **Food Sticking:** While the liners are non-stick, some foods, especially those with high sugar content, may stick slightly. A light spray of cooking oil on the liner before adding food can help prevent this.
- **Liner Deformation:** Ensure the liner is not exposed to temperatures exceeding 450°F (232°C). Prolonged exposure to extreme heat or direct flame can cause deformation.
- **Odor Retention:** Silicone can sometimes absorb odors from strong-smelling foods. To minimize this, soak the liner in a mixture of warm water and baking soda for a few hours, then wash as usual.

Product Specifications

Material	Silicone
Size	Large
Color	Black
Shape	Square
Item Weight	0.41 Kilograms (14.4 ounces)
Heat Resistance	Up to 450°F (232°C)
Dishwasher Safe	Yes

Compatible Models	Ninja Foodi AF140, AF180, AF141, AF181, Philips NA230, COSORI 5.5L

Customer Support

For any questions, concerns, or assistance with your Enegg Silicone Air Fryer Liners, please contact our customer support team. Refer to your purchase documentation for specific contact details or visit the Enegg official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question