Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WALKINGPAD C2

WALKINGPAD C2 Foldable Walking Pad Treadmill User Manual

Model: C2 | WPS1F

1. Introduction

Thank you for choosing the WALKINGPAD C2 Foldable Walking Pad Treadmill. This compact and innovative fitness device is designed for convenient daily walking and light jogging in your home or office. Its unique 180° folding design allows for easy storage, making it an ideal solution for space-saving. This manual provides essential information for safe operation, setup, maintenance, and troubleshooting to ensure you get the most out of your WALKINGPAD C2.

2. Important Safety Information

Please read all instructions carefully before using the WALKINGPAD C2. Keep this manual for future reference.

- **User Weight Limit:** Do not exceed the maximum user weight of 100 kg (220 lbs).
- **Clearance:** Ensure a clear area of at least 0.6 meters (2 feet) behind and on each side of the treadmill during operation.
- **Footwear:** Always wear appropriate athletic footwear while using the treadmill.
- **Children and Pets:** Keep children and pets away from the treadmill at all times, especially during operation.
- **Stable Surface:** Place the treadmill on a flat, stable, and level surface. Do not place it on thick carpets or uneven ground.
- **Power Cord:** Ensure the power cord is not pinched or damaged. Do not operate if the cord or plug is damaged.
- **Emergency Stop:** Familiarize yourself with the remote control's stop function for immediate halting of the belt.
- **Medical Conditions:** Consult a physician before starting any exercise program, especially if you have pre-existing medical conditions.
- **Unplug When Not in Use:** Always unplug the treadmill from the power outlet when not in use, before cleaning, or before performing maintenance.

3. What's in the Box

Carefully unpack all components and ensure you have received the following items:

- WALKINGPAD C2 Treadmill
- Power Cord
- Remote Control
- Tool Kit
- User Manual (this document)

If any items are missing or damaged, please contact customer support.

4. Setup Guide

4.1 Unpacking and Placement

1. Remove the treadmill and all accessories from the packaging.
2. Place the treadmill on a firm, level surface. Ensure there is adequate space around the unit for safe operation, as described in the safety section.

4.2 Unfolding the Treadmill

The WALKINGPAD C2 features a unique 180° folding design for compact storage. To unfold it for use:

1. Gently lift the rear section of the treadmill.
2. Unfold it until the platform is fully extended and flat on the floor. Ensure the locking mechanism (if any visible) is securely engaged.



Figure 4.2.1: Unfolding the WalkingPad C2 for use. The treadmill folds completely flat for easy storage under furniture.

4.3 Power Connection

1. Connect the power cord to the treadmill's power input port.
2. Plug the other end of the power cord into a grounded electrical outlet.

3. Ensure the power switch (usually located near the power input) is in the 'ON' position. The LED display should illuminate.

Your browser does not support the video tag.

Video 4.3.1: Official demonstration of the WalkingPad C2's compact design and ease of setup, highlighting its portability and quick deployment for exercise.

5. Operating Instructions

5.1 Power On/Off

After connecting to power, press the power button on the treadmill or the remote control to turn the unit on. The LED display will light up. Press again to turn off.

5.2 Remote Control Functions

The included remote control is your primary interface for operating the WALKINGPAD C2:

- **Start/Stop Button:** Press to start or stop the treadmill belt.
- **Speed Up (+):** Increases the belt speed.
- **Speed Down (-):** Decreases the belt speed.

5.3 Speed Adjustment and Usage

The WALKINGPAD C2 offers a speed range suitable for walking and light jogging:

- **Minimum Speed:** 1 mph
- **Maximum Speed:** 4 mph

Adjust the speed gradually using the remote control to find a comfortable pace. Always start at a lower speed and increase as you become accustomed to the movement.



Figure 5.3.1: The WalkingPad C2 supports speeds from 1 mph to 4 mph, suitable for both walking and light jogging.

5.4 LED Display

The integrated LED display provides real-time feedback on your workout progress:

- **Time:** Duration of your workout.

- **Speed:** Current belt speed in miles per hour (mph).
- **Distance:** Total distance covered during your session.
- **Calories:** Estimated calories burned.
- **Steps:** Number of steps taken.



Figure 5.4.1: The LED display provides essential workout data including steps, time, calories, speed, and distance.

5.5 Under-Desk Use

The compact design and quiet motor of the WALKINGPAD C2 make it ideal for use under a standing desk, allowing you to stay active while working.



Figure 5.5.1: The quiet brushless motor allows for discreet use in home or office environments, such as under a standing desk.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your WALKINGPAD C2.

6.1 Cleaning

- Always unplug the treadmill before cleaning.
- Wipe down the treadmill surface, including the belt and frame, with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Keep the area around the treadmill clean and free of dust and debris.

6.2 Running Belt Lubrication

The running belt requires periodic lubrication to reduce friction and extend its lifespan. Refer to the specific instructions in your included tool kit or contact customer support for recommended lubricant type and application frequency.

6.3 Running Belt Adjustment

Over time, the running belt may shift to one side or become loose. If the belt is not centered or feels loose, it may require adjustment. Refer to the detailed instructions in your tool kit or contact customer support for guidance on how to center and tension the running belt.



Figure 6.3.1: The 8-layer composite running belt is designed for durability and comfort, requiring proper maintenance.

7. Troubleshooting

If you encounter any issues with your WALKINGPAD C2, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Treadmill does not power on.	Power cord not properly connected; Power switch off; Outlet not working.	Check power cord connection; Ensure power switch is ON; Test outlet with another device.
Belt does not move.	Treadmill is paused; Remote control battery low; Safety key not engaged (if applicable).	Press Start on remote; Replace remote battery; Ensure safety key is in place.
Belt slips or hesitates.	Belt too loose; Belt needs lubrication; Overload.	Adjust belt tension; Lubricate belt; Reduce user weight or speed.
Unusual noise during operation.	Loose parts; Belt rubbing; Motor issue.	Check for loose screws and tighten; Adjust belt centering; Contact customer support if noise persists.
LED display not working correctly.	Loose connection; Malfunction.	Power cycle the treadmill; Contact customer support.

If the problem persists after trying these solutions, please contact WALKINGPAD customer support.

8. Specifications

Feature	Specification
Brand	WALKINGPAD
Model Name	WALKINGPAD C2
Model Number	WPS1F
Product Dimensions (Unfolded)	56.9"D x 20.4"W x 4.9"H (144.5 cm x 51.8 cm x 12.4 cm)
Folded Size	32.5" x 20.4" x 5.4" (82.5 cm x 51.8 cm x 13.7 cm)
Item Weight	25 kg (55 lbs)
Material	Aluminum
Maximum Speed	4 miles_per_hour (6.4 km/h)
Minimum Speed	1 miles_per_hour (1.6 km/h)
Maximum Horsepower	2 hp
Maximum Weight Recommendation	100 kg (220 lbs)
Display Type	LED
Metrics Measured	Calories Burned, Distance, Speed, Time, Steps
Power Source	Corded Electric

Feature	Specification
Special Feature	Foldable Design

9. Warranty and Support

9.1 Warranty Information

The WALKINGPAD C2 Foldable Walking Pad Treadmill comes with a**one-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or improper maintenance.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your WALKINGPAD C2, please visit the official WALKINGPAD store or contact their customer service department. You can find more information and support resources at the WALKINGPAD Amazon Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZK3LFK6

More documents and user manuals: **https://manuals.plus/**