Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok N2QAYC000109

Azwok N2QAYC000109 Replacement Remote Control User Manual

For Panasonic Soundbar Models SCHTB485 and SC-HTB485GN

Introduction

This manual provides instructions for the Azwok N2QAYC000109 replacement remote control, designed for use with Panasonic Soundbar models SCHTB485 and SC-HTB485GN. This remote offers the primary functions of the original remote control, ensuring seamless operation of your soundbar.

No programming is required; simply insert batteries, and the remote is ready for use.

Product Overview





Image: Front view of the Azwok N2QAYC000109 replacement remote control, displaying all buttons.

Button Functions:

- **Power Button ( )**: Turns the soundbar on or off.
- **INPUT**: Selects the audio input source (e.g., TV, HDMI, Optical).
- **Bluetooth Pairing (♫ -PAIRING)**: Activates Bluetooth pairing mode for connecting devices.
- **Volume Up/Down (+ VOL -)**: Adjusts the soundbar's volume level.
- **MUTE**: Silences or restores the sound.
- **SETUP**: Accesses the soundbar's setup menu.
- **SOUND (-MUSIC)**: Cycles through various sound modes or activates music mode.
- **Navigation Buttons (▼, ▲)**: Used for navigating menus and options.
- **OK**: Confirms selections in menus.

Setup

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries (not included), ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

The remote control is ready for immediate use with your Panasonic Soundbar SCHTB485 or SC-HTB485GN; no additional programming is required.

Operating Instructions

Point the remote control directly at the Panasonic Soundbar for optimal performance.

- **Power On/Off**: Press the button to turn the soundbar on or off.
- **Selecting Input**: Press the **INPUT** button repeatedly to cycle through available input sources (e.g., TV, HDMI, Optical, Bluetooth).
- **Adjusting Volume**: Use the **+ VOL -** buttons to increase or decrease the sound volume.
- **Muting Sound**: Press the **MUTE** button to temporarily silence the audio. Press it again to restore sound.
- **Bluetooth Pairing**: Press the ♫ **-PAIRING** button to initiate or manage Bluetooth connections with compatible devices. Refer to your soundbar's original manual for detailed Bluetooth pairing procedures.
- **Sound Modes**: Press the **SOUND -MUSIC** button to switch between different audio presets or activate music mode, if supported by your soundbar.
- **Menu Navigation**: Use the ▼ and ▲ buttons to navigate through menus after pressing **SETUP**. Press **OK** to confirm selections.

Maintenance

- **Battery Replacement**: Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Cleaning**: Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage**: If the remote will not be used for an extended period, remove the batteries to prevent leakage.

Troubleshooting

- **Remote not responding**:
  - Ensure batteries are inserted correctly and are not depleted. Replace if necessary.
  - Check for any obstructions between the remote control and the soundbar's infrared receiver.
  - Ensure you are within the effective range and pointing the remote directly at the soundbar.
- **Specific functions not working**:
  - Verify that your soundbar model (SCHTB485 or SC-HTB485GN) is compatible with this remote.
  - Some advanced functions might require specific soundbar settings or may not be fully supported by a replacement remote. Refer to your soundbar's original manual.

Specifications

Model Number	N2QAYC000109
Compatible Devices	Panasonic Soundbar SCHTB485, SC-HTB485GN
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Dimensions	Approximately 3.54 x 1.97 x 0.39 inches
Weight	Approximately 1.06 ounces (without batteries)

Warranty and Support

This Azwok replacement remote control comes with a 12-month warranty from the date of purchase. This warranty covers manufacturing defects and ensures the remote functions as described.

For support, troubleshooting assistance, or warranty claims, please contact your retailer or the manufacturer directly. When contacting support, please provide your purchase details and the model number of the remote control (N2QAYC000109).

© 2025 Azwok. All rights reserved. Panasonic is a registered trademark of Panasonic Corporation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZP8WTTT

More documents and user manuals: **https://manuals.plus/**