

Manuals.plus /
› [OLEVS](#) /
› OLEVS Men's Automatic Watch User Manual

OLEVS SLD-S-G6701-BL

OLEVS Men's Automatic Watch User Manual

Model: SLD-S-G6701-BL

INTRODUCTION

This manual provides comprehensive instructions for the OLEVS Men's Automatic Watch, model SLD-S-G6701-BL. Please read this manual carefully to ensure proper use, maintenance, and longevity of your timepiece.



Image: Front view of the OLEVS Men's Automatic Watch, showcasing its blue skeletonized dial, tourbillon, and stainless steel bracelet.

PRODUCT OVERVIEW

The OLEVS Automatic Watch is a sophisticated timepiece featuring a self-winding mechanical movement with a visible tourbillon. It combines luxury design with practical functionalities.

Key Features:

- Automatic movement with skeletonized tourbillon (45 hours power reserve).

- Visible tourbillon and skeletonized dial with cubic zirconia and Roman numerals.
- No batteries required; powered by wrist movement.
- Durable 316 stainless steel bracelet, wear-resistant and water/sweat-proof.
- Multifunctional display: integrated calendar function (date, weekday, month).
- Luminous hands for low-light visibility.
- 30M water resistance (suitable for rain/swimming, not for sauna/diving).

Confident Style, Promising Young

| Multi-functional dial design, and fashionable both, minute by minute |



Day subdial

Multi-function



Date subdial

Multi-function



Year/month window

Multi-function



▼ Side Show

Monthly Adjustment Dark Knob

Pull out to adjust the time
Press firmly to wind clockwise

Date adjustment knob

Concealed knob function on the left side:

- ① Dark Button Adjustment Year
- ② Dark Button Adjustment Week

Image: Detailed view of the watch dial highlighting the day, date, and year/month subdials, along with an illustration of the crown and concealed adjustment buttons.

SETUP AND INITIAL OPERATION

Winding the Watch

As an automatic mechanical watch, it requires initial winding if it has stopped.

1. Pull out the crown to position 1 (time setting position).
2. Rotate the crown clockwise approximately 30-40 times to build up power reserve.
3. Push the crown back in. The watch will then continue to wind itself with wrist movement.

Setting the Time

1. Pull the crown out to position 1.
2. Rotate the crown to set the hour and minute hands.
3. Push the crown back to its original position.

Setting the Calendar Functions

The watch features day, date, and month/year displays.

Day Subdial Adjustment

The day subdial (e.g., SUN, MON) is typically adjusted by a concealed button on the left side of the watch case. Use a small, pointed tool (like the included watch adjuster pin) to gently press this button until the correct day is displayed.

Date Subdial Adjustment

The date subdial (1-31) is adjusted using the main crown. Pull the crown out to position 1 and rotate it counter-clockwise to advance the date.

Month/Year Window Adjustment

The month/year window (e.g., JUN 2023) is also adjusted by a concealed button, usually located on the left side of the watch case, similar to the day adjustment. Press gently with a pointed tool to advance the month and year.

Important: Avoid adjusting the date or day between 9 PM and 3 AM, as this can damage the movement. If adjustment is needed during this period, first set the time outside this window, adjust the date/day, then reset the time.

MAINTENANCE AND CARE

Water Resistance

Your OLEVS watch is rated for 30 meters (3 ATM) water resistance. This means it is suitable for daily use, such as hand washing, rain, and accidental splashes. It is also suitable for short periods of swimming.

Caution: Do not operate the crown or buttons while the watch is wet or submerged. Not suitable for hot water activities like showering or sauna, or for diving. Prolonged exposure to water or steam can compromise the seals.



Image: The OLEVS watch with water droplets, emphasizing its 30-meter water resistance.

Cleaning

To clean your watch, wipe the case and bracelet with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using chemical cleaners or abrasive materials.

Storage

When not wearing the watch, store it in a cool, dry place away from direct sunlight and strong magnetic fields.

Bracelet Adjustment

The stainless steel bracelet can be adjusted by adding or removing links. It is recommended to have this done by a professional watchmaker or use the included watch adjuster tool carefully.



Image: The OLEVS watch presented in its white gift box, highlighting its suitability as a gift.

TROUBLESHOOTING

Watch Not Running or Stopping Frequently

- Ensure the watch is fully wound. If it has stopped, manually wind it by rotating the crown 30-40 times.
- Wear the watch regularly. Automatic watches rely on wrist movement to stay wound. If worn infrequently, it may stop.
- If the issue persists after winding and wearing, there might be an internal mechanical problem. Contact customer service.

Time is Inaccurate

- Mechanical watches may have slight variations in accuracy. A deviation of +/- 20-40 seconds per day is generally considered acceptable for automatic watches.
- Ensure the watch is fully wound. Low power reserve can affect accuracy.
- Avoid exposing the watch to strong magnetic fields (e.g., speakers, refrigerators, certain electronic devices), as magnetism can affect the movement's accuracy.

Calendar Not Changing Correctly

- Ensure you are not attempting to adjust the calendar between 9 PM and 3 AM.
- Verify that the crown is fully pushed in after setting the time.
- If the issue persists, contact customer service.

SPECIFICATIONS

Feature	Detail
Model Number	SLD-S-G6701-BL
Movement	Automatic Mechanical with Tourbillon
Case Material	Stainless Steel
Bracelet Material	361 Stainless Steel
Water Resistance	30 Meters (3 ATM)
Clasp Type	Double Locking Foldover Clasp
Package Dimensions	4.53 x 4.33 x 2.95 inches
Item Weight	14.96 ounces

WARRANTY AND SUPPORT

OLEVS offers a 30-day free return period for this product.

For any questions or assistance during use, please contact OLEVS customer service.

You can reach customer service via email atcustomerservice@olvs.com.

Please provide your model number (SLD-S-G6701-BL) and a detailed description of your issue when contacting support.

Kenntnisse in der Wartung mechanische Uhr

Wie ziehe ich eine mechanische Uhr auf?




Achtung, mechanische Uhren sollten mindestens wöchentlich aufgezogen werden, auch wenn sie eingelagert sind:

- Drücken Sie die Krone ganz in Richtung des Gehäuses. (Wenn sich die Krone auf der rechten Seite der Uhr befindet, drücken Sie sie ganz nach links).
- Drehen Sie die Krone nach vorne (auf die Krone gerichtet im Uhrzeigersinn drehen). Sie sollten einen leichten „Widerstand“ spüren. Das ist normal. Sie ziehen die Zugfeder an und aktivieren die Zahnräder der Uhr, also ist es natürlich, dies zu spüren.
- Drehen Sie die Krone 30-40 Mal. Die meisten Uhren erreichen ihre maximale Leistung durch 30- bis 40-maliges Aufziehen der Krone, dies kann jedoch variieren. Sobald Sie einen Widerstand spüren, ist die Uhr vollständig aufgezogen. Wenn Ihre Uhr neu ist und Sie sich unsicher fühlen, versuchen Sie, die Krone zu Beginn 30 Mal aufzuziehen und arbeiten Sie sich von dort aus nach oben.
- Eine Automatikuhr hat einen Mechanismus, der die Zugfeder automatisch für Sie aufzieht. Die Bewegung Ihres Arms und Handgelenks sowie der gewichtete Rotor im Inneren der Uhr treiben diesen Prozess an. Eine Automatikuhr gibt Ihnen etwa 45 Stunden Energie, vorausgesetzt, Sie tragen sie den ganzen Tag und nehmen sie nur nachts ab.

Wie passt man die Bandlänge einer mechanischen Uhr an?

Tipp: 1. Vermeiden Sie es, zu viel Kraft anzuwenden, um die Nadel leicht zu brechen. 2. Der Rhythmus der Drehung des Griffs sollte gleichmäßig sein und sofort aufhören, wenn Sie ihn abnormal finden. 3. Finden Sie einen Fachmann, wenn Sie sich nicht sicher sind, wie Sie damit umgehen:

- Suchen Sie das runde Ende der Stifte.
- Legen Sie das Armband in den Schlitz des Einstellwerkzeugs, richten Sie die Nadel mit dem runden Ende aus.
- Drehen Sie den Griff des Einstellwerkzeugs im Uhrzeigersinn, um den Stift herauszudrücken.
- Ziehen Sie den gedrückten Stift heraus und nehmen Sie den zweiten Stift auf die gleiche Weise heraus.
- Achten Sie beim Zurücksetzen des Stifts darauf, dass das runde Ende in das Loch passt.
- Richten Sie die Nadel am gespaltenen Ende aus und drehen Sie den Griff, um das gespalten Ende einzudrücken.
- Hier ist das YouTube-Video zum Anpassen der Bandlänge an DUPINKE-Uhren:
<https://youtu.be/0B9E5Fh5o>
- Hier ist das YouTube-Video zum Anpassen der Bandlänge an OLEVS-Uhren:
<https://youtu.be/M6qZRI9AIE>



1. Find the round end of the pins.



2. Put the bracket into the slot of the adjuster. Align the needle with the round end.



3. Turn the handle of the adjuster clockwise to push out the pin.



4. Pull out the pushed pin, and take out the second pin in the same way.



5. When putting the pin back, make sure the round end goes into the hole.



6. Align the needle with the split end and turn the handle to push the split end in.

- 1 -

VERSCHIEDENES

WASSERFESTIGKEIT

Bei traditionellen Uhren ist die Angabe zur Wasserdichtigkeit in den Gehäuseboden eingraviert.

Die Angaben zur Wasserdichtigkeit stellen Richtlinien zur angemessenen Verwendung der Uhr in Kontakt mit Wasser dar, um Schäden an deren internen Bauteilen zu vermeiden. Bitte sehen Sie sich die Tabelle mit den empfohlenen Benutzungshinweisen an.

Um sicherzustellen, dass das Wasser nicht in die Uhr eindringt und ihr Schaden zufügt, befolgen Sie bitte die unten aufgeführten Anweisungen:

- Benutzen Sie die Krone nicht, solange der Zeitmesser sich in Kontakt mit Wasser befindet.
- Achten Sie darauf, dass die Krone geschlossen ist, bevor die Uhr in Kontakt mit Wasser kommt. Bei Zeitmessern mit Schraubkronen, passen Sie bitte darauf auf, dass die Krone vollständig festgedreht wurde, bevor die Uhr in Berührung mit Wasser gelangt.
- Für Zeitmesser mit Funktionsknöpfen, nutzen Sie die Funktionen bitte nicht unter Wasser.
- Setzen Sie die Uhr bitte nicht extremen Umgebungen aus (d. h. heißem Wasser, Saunen oder Schwitzstuben).
- Vermeiden Sie den Kontakt mit druckvollem Wasser (d. h. Wasser aus der Leitung, Meereswellen oder Wasserfällen).
- Verhindern Sie eine längere Berührung mit Salzwasser. Nach Kontakt mit Salzwasser spülen Sie die Uhr sanft unter Leitungswasser ab und reiben sie dann mit einem weichen Tuch trocken. Dies gilt nur für Uhren mit einem Prüfdruck ab 5 ATM.

EMPFEHLUNGEN FÜR DEN KONTAKT MIT WASSER				
ANGABE	SPRITZWASSERGEWÜTZT  (Hände waschen)	TAUCHFÄHIG  (Schwimmen)	FLACHWASSER- TAUCHFÄHIG  (Schnorcheln)	GERÄTETAUCHEN  (Nicht Tauchen)
(KEINE)				
3 ATM • 3 BAR • 30 Meter	✓			
5 ATM • 5 BAR • 50 Meter	✓	✓		
10 ATM • 10 BAR • 100 Meter	✓	✓	✓	
20 ATM • 20 BAR • 200 Meter	✓	✓	✓	✓

- 3 -

Wie stelle ich Uhrzeit, Tag und Datum einer mechanischen Uhr ein?

Es ist wichtig, daran zu denken, dass Datum und Uhrzeit nicht während des auf dem Zifferblatt angezeigten Zeitraums von 21:00 Uhr bis 5:00 Uhr eingestellt werden sollten. Denn in dieser Zeit laufen die Zahnräder, die das Datum umstellen. Jede manuelle Anpassung von Datum und Uhrzeit, während sich die Zahnräder bewegen, kann eines der Zahnräder beschädigen, was zu langfristigen Problemen im Uhrwerk der Uhr führt.

Bevor Sie versuchen, das Datum und die Uhrzeit einer Uhr zu ändern, wird empfohlen, dass die Uhr über kinetische Energie verfügt, daher ist es am besten, die Uhr aufzuziehen. Die beste Zeit zum Einstellen von Datum und Uhrzeit auf einer Uhr ist entweder 6:30 Uhr oder 18:30 Uhr. Denn zu diesen Zeiten laufen die Zahnräder nicht.

Die Uhr ist 24 Stunden System. Wenn sich das Datum um 12 Uhr ändert, bedeutet dies, dass die Uhr jetzt 0:00 Uhr anzeigt und Sie sie nur 12 Stunden vorstellen müssen, damit sie die richtige Zeit anzeigt.

Tag/Uhrzeit-Einstellung

Tageseinstellung

1. Ziehen Sie die Krone bis auf Position 1 heraus.
2. Drehen Sie die Krone gegen den Uhrzeigersinn, um Stunden- und Minutenzeiger vorzustellen.
3. Bringen Sie die Krone in die ursprüngliche Position zurück.

Zeiteinstellung

1. Ziehen Sie die Krone bis auf Position 2 heraus.
2. Drehen Sie die Krone gegen den Uhrzeigersinn, um Stunden- und Minutenzeiger vorzustellen.
3. Bringen Sie die Krone in die ursprüngliche Position zurück.



3-Zeiger-Doppelzeit

Zeiteinstellung

1. Ziehen Sie die Krone bis auf Position 1 heraus.
2. Drehen Sie die Krone gegen den Uhrzeigersinn, um Stunden- und Minutenzeiger vorzustellen.
3. Bringen Sie die Krone in die ursprüngliche Position zurück.

Woche/Datum/Jahr-Einstellung

Gemäß den im Bild beschriebenen „Frühjahrseinstellungen“ müssen Sie die Woche und den Monat manuell einstellen, indem Sie die „Wochen-Einstellstange“ und die „Datum-Einstellstange“ drücken.



2-Zeiger-Doppelzeit

Zeiteinstellung

1. Ziehen Sie die Krone bis auf Position 1 heraus.
2. Drehen Sie die Krone gegen den Uhrzeigersinn, um Stunden- und Minutenzeiger vorzustellen.
3. Bringen Sie die Krone in die ursprüngliche Position zurück.

Woche/Datum Setting

Gemäß den im Bild beschriebenen „Frühjahrseinstellungen“ müssen Sie die Woche und den Monat manuell einstellen, indem Sie die „Wochen-Einstellstange“ und die „Datum-Einstellstange“ drücken.



- 2 -

EU

REP

SUCCESS COURIER SL
CALLE RIO TORMES NUM. 1, PLANTA 1, DERECHA,
OFICINA 3, Fuenlabrada, Madrid, 28947 Spain
OST_EU_20231007000042successservice2@hotmail.com
We simply act as EU representative for cross-border sellers, and are not manufacturers/importers/distributors for the product, nor involved in the manufacture/import/sale of the product. Therefore, we are not responsible for any after-sales services related to the product. In case of any product quality or infringement issues, the manufacturer/importer/seller shall be solely held responsible.



Bitte beachten Sie!

Die Uhr ist wasserfest, aber es wird trotzdem nicht empfohlen, sie in nasser Umgebung oder beim Schwimmen zu benutzen. Außerdem sollten Sie versuchen, Kollisionen und Magnetismus zu vermeiden, da dies die Lebensdauer der Uhr beeinträchtigt. Uhren sind Präzisionswerkzeuge und eine regelmäßige Wartung wird empfohlen.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F1378C1R>

More documents and user manuals: <https://manuals.plus/>