Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KOKEBREN 01

KOKEBREN 24-inch Single Wall Oven Instruction Manual

Model: 01

Safety Information Product Overview Setup & Installation Operating Instructions Maintenance & Cleaning Troubleshooting Specifications Warranty & Support

Introduction

Thank you for choosing the KOKEBREN 24-inch Single Wall Oven. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new appliance. Please read these instructions thoroughly before using the oven and retain them for future reference.

Important Safety Information

To reduce the risk of fire, electric shock, injury to persons, or damage when using the oven, follow basic precautions, including the following:

- **Proper Installation:** Ensure the oven is correctly installed and grounded by a qualified technician in accordance with the provided installation instructions.
- **Electrical Requirements:** Connect the oven only to a 240V, 3000W dedicated circuit as specified in the electrical requirements section.
- **Child Safety Lock:** Utilize the integrated child safety lock feature to prevent accidental operation by children.
- **Hot Surfaces:** The oven interior, door, and surrounding surfaces can become very hot during operation. Use oven mitts and avoid contact with hot surfaces.
- **Double-Layered Glass Door:** The oven features a double-layered glass door designed for effective heat insulation and anti-scalding protection. However, caution is still advised.
- **Open Door Automatic Power Off:** The oven is equipped with an automatic power-off feature if the door is left open for an extended period during certain operations.
- **Water Shortage Autochirp:** For steam functions, the oven will emit an autochirp sound if there is a water shortage. Refill the water tank promptly.
- **Flammable Materials:** Do not store or use flammable materials near the oven.
- **Cleaning:** Always disconnect power before cleaning. Use non-abrasive cleaners.

Product Overview

The KOKEBREN 24-inch Single Wall Oven is a versatile appliance designed for modern kitchens, offering a range of cooking functions and safety features.

Key Features:

- **Spacious 2.5 Cu.ft Capacity:** Accommodates multiple dishes simultaneously.
- **3000W High Power with Convection Fan:** Ensures rapid preheating and even cooking with 360° hot air circulation.
- **Multi-Functional Cooking Modes:** Supports steaming, baking, braising, grilling, and air explosion modes.
- **Enhanced 3D Surround Heating:** Provides consistent results for various cooking methods.
- **Touch Control Panel:** Intuitive interface for easy operation.
- **Safety Features:** Includes Child Safety Lock, Open Door Automatic Power Off, and Water Shortage Autochirp.
- **Cleaning Functions:** Steam cleaning, steam sterilization, and drying functions for easy maintenance.
- **Durable Interior:** Food-grade enamel inner cavity with laser welding process, resistant to high temperature, acid, and oxidation.



Image: Front view of the KOKEBREN 24-inch Single Wall Oven with key dimensions (23.4 inches height, 23.4 inches width, 22.2 inches

depth) highlighted, illustrating its compact design suitable for built-in installation.



Image: A visual representation of the KOKEBREN 24-inch Electric Wall Oven highlighting features such as Self-Cleaning, Temperature Probe, Broil Element, Hidden Bake Element, Delay Start, Child Safety Lock, Kitchen Timer, and Warming mode.

Setup & Installation

Unpacking

Carefully remove all packaging materials from the oven. Inspect the oven for any shipping damage. Do not discard packaging until the oven has been installed and is operating correctly.

What's in the Box

- 1 × Single oven unit
- User Manual
- Installation hardware (if applicable)

Dimensions and Clearances

The overall dimensions of the oven are approximately 23.42" (W) x 22.16" (D) x 23.42" (H). Ensure your cabinet cutout meets these requirements for a proper built-in installation. Refer to the detailed specification image for precise measurements.



Image: The KOKEBREN 24-inch Single Wall Oven with its exterior dimensions clearly marked, showing a width of 23.4 inches, a height of 23.4 inches, and a depth of 22.2 inches, essential for proper cabinet fitting.

Electrical Connection

This oven requires a 240V electrical supply with a wattage of 3000W. Installation must be performed by a qualified electrician in compliance with all local codes and ordinances.

Installation Steps (General Guidelines)

1. Prepare the cabinet opening according to the specified dimensions.
2. Ensure the electrical supply is turned off at the circuit breaker.
3. Connect the oven's electrical wiring to the household supply according to the wiring diagram provided with the oven and local electrical codes.
4. Carefully slide the oven into the cabinet opening.
5. Secure the oven to the cabinet using the provided screws and mounting brackets.
6. Restore power and test the oven's functions.

Operating Instructions

Control Panel Overview

The oven features an intuitive touch control panel. Familiarize yourself with the icons and their functions before operation.



Image: Close-up view of the KOKEBREN oven's touch control panel, displaying icons for Lamp, Power, Steam mode, Grill mode, Combined mode, Air explosion, Recipes, Time/Temp, Decrease, Increase, and Start/Pause functions.

Basic Operation

1. **Power On:** Touch the **Power** icon to turn on the oven.
2. **Select Mode:** Choose your desired cooking mode (e.g., Steam mode, Grill mode, Combined mode, Air explosion) by touching the corresponding icon.
3. **Set Temperature/Time:** Use the **Time/Temp** icon and the **Decrease** / **Increase** arrows to adjust settings.

4. **Start Cooking:** Press the **Start/Pause** icon to begin the cooking process.
5. **Preheating:** The oven will typically preheat to the set temperature. A signal will sound when preheating is complete.
6. **Child Safety Lock:** To activate or deactivate the child lock, refer to the specific instructions in the full manual. This feature prevents unintended operation.

Cooking Modes

The oven offers 8 baking modes, including steaming, baking, and braising, along with a convection fan for even heat distribution. The 3D surround heating technology ensures consistent cooking results.



Image: The KOKEBREN oven interior with steam visibly circulating around food items on multiple racks, demonstrating the direct injection large steam feature for locking in fresh and original flavors.

Recommended Cooking Presets

The following table provides general guidelines for various food types. Adjustments may be necessary based on specific recipes and desired doneness.



Image: A table displaying recommended cooking presets for various food items including Hamburger, Pizza, Beef, Biscuit, Sandwich, Apple pie, Toast, Chicken, and Sponge cake, with default temperatures and times.

Cooking Presets Guide

Food Item	Default Temperature	Default Time
Hamburger	240°C	10-20 mins
Pizza	200°C	7-10 mins
Beef	200°C	10-15 mins
Biscuit	200°C	10-15 mins
Sandwich	180°C	15-20 mins
Apple pie	185°C	50-60 mins
Toast	240°C	1-2 mins
Chicken	200°C	50-60 mins
Sponge cake	150°C	30-35 mins

Maintenance & Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your oven.

Interior Cleaning

The oven features a food-grade enamel inner cavity, which is designed to be easy to clean. It is resistant to high temperatures, acid, and oxidation.



Image: Close-up view of the KOKEBREN oven's interior, highlighting the food-grade enamel inner cavity and the laser welding process, along with icons indicating high temperature resistance, acid resistance, ultra-smooth surface, anti-oxidation, and high humidity resistance.

Steam Cleaning Function

Utilize the built-in steam cleaning, steam sterilization, and drying functions for effortless cleaning. Follow these general steps:

1. Ensure the water tank is filled.
2. Select the steam cleaning or sterilization mode from the control panel.
3. Allow the cycle to complete.
4. Once the oven has cooled, wipe down the interior with a soft cloth to remove loosened residue.



Image: The KOKEBREN oven interior with steam visible, illustrating the steam cleaning, steam sterilization, and drying functions for hygiene and ease of maintenance.

Exterior Cleaning

Wipe the exterior surfaces with a soft, damp cloth and mild detergent. Avoid abrasive cleaners or scouring pads that could scratch the stainless steel finish.

Troubleshooting

Before contacting customer support, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Oven does not turn on	No power supply; circuit breaker tripped	Check power connection; reset circuit breaker.

Problem	Possible Cause	Solution
Oven not heating properly	Incorrect mode/temperature setting; door not closed properly	Verify settings; ensure door is fully closed.
Water shortage autochirp during steam function	Water tank is empty or low	Refill the water tank.
Child lock activated	Controls are locked	Refer to the operating instructions to deactivate the child lock.
Oven automatically powers off	Door left open too long; safety feature activated	Close the oven door; restart the cooking cycle if necessary.

Specifications

Detailed technical specifications for the KOKEBREN 24-inch Single Wall Oven, Model 01.



Image: A detailed table outlining the technical specifications of the KOKEBREN oven, including volume, water tank capacity, control method, steam mode temperature range, grill mode temperature range, power ratings, and individual heating element wattages.

Feature	Specification
Model Name	J4xUkePn3moVqKHW1Opg4QGeGuicM
Model Number	01
Capacity	2.5 cubic feet (70L)
Water Tank Capacity	1.3L
Wattage	3000W

Feature	Specification
Voltage	240V
Heating Method	Radiant, 3D Surround Heating
Fuel Type	Electric
Installation Type	Built-In
Control Method	Touch Control
Steam Mode Temperature	60-110°C
Grill Mode Temperature	100-250°C
Steam & Grill Mode Temperature	100-250°C
Upper and Inner Heat Pipe Power	2000W
Upper and External Heat Pipe Power	950W
The Heat Pipe Power	1000W
Back Heat Pipe Power	1800W
Steam Generator Power	1200W
Furnace Lamp Power	25W
Rear Circulating Fan Power	14W
Top Cross Fan Power	10W
Item Dimensions (D x W x H)	26.89"D x 25.87"W x 25.87"H
Item Weight	45 Pounds
Material Type	Stainless Steel
Finish Type	Polished
Color	Black
Defrost System Type	Auto Defrost
Door Orientation	Front
Additional Features	Temperature Control, Timer Function Available

Warranty & Support

Warranty Information

Please note that this product does not come with a manufacturer's warranty. Any warranty claims or issues should be directed to the retailer or seller from whom the product was purchased, subject to their return and refund policies.

Customer Support

For technical assistance, troubleshooting not covered in this manual, or inquiries regarding your KOKEBREN 24-inch Single Wall

Oven, please contact your retailer or the KOKEBREN customer support team through their official channels. Please have your model number (01) and purchase information ready when contacting support.

© 2024 KOKEBREN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F138WCCF

More documents and user manuals: **https://manuals.plus/**