Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CALANDIS ELY68030859

CALANDIS Smart Remote Control User Manual

For MXQ Pro, M9C, T95M, T95N, H96 Pro+ Android TV Boxes

1. Introduction

This manual provides instructions for the CALANDIS Smart Remote Control, designed for use with various Android TV boxes. This remote offers a simple and efficient way to control your compatible device, featuring low power consumption for extended battery life.

Compatible Models:

- MXQ / MXQ Pro
- H96 / H96 Pro / H96 Pro+
- T95 / T95M / T95N / T95X
- M8 / M8N / M8C (*Note: Does not fit M8S Plus*)
- Other compatible Android TV Boxes

2. Package Contents

Please check the package for the following items:

- 1x CALANDIS Smart Remote Control
- *Note: AAA batteries are not included and must be purchased separately.*

3. Setup

3.1. Battery Installation

The remote control requires two (2) AAA batteries for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Gently slide the cover downwards or press the latch (if present) and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Back of the remote control with the battery compartment. Slide the cover to open and insert two AAA batteries.

Once batteries are installed, the remote is ready for use with your compatible Android TV box. No additional pairing or setup is typically required for basic functions.

4. Operating Instructions

The CALANDIS Smart Remote Control provides intuitive buttons for navigating and controlling your Android TV box. Below is a general overview of the remote's layout and common functions.



Figure 2: Front view of the remote control, displaying power, navigation, volume, and numeric buttons.

4.1. Button Functions Overview

- **Power Button (●):** Turns the Android TV box on or off.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and select items. The "OK" button confirms selections.
- **Back Button (↶):** Returns to the previous screen or menu.
- **Home Button (⌂):** Returns to the main home screen of the Android TV box.
- **Volume Buttons (VOL-, VOL+):** Adjusts the volume level.
- **Mute Button ( ):** Mutes or unmutes the audio.
- **Numeric Keypad (0-9):** For direct input of channels or other numerical data.
- **TV Control Section (SET, TV IN, VOL-, VOL+):** These buttons are typically for controlling a television directly. Refer to your TV's manual for programming instructions if this feature is supported by your TV and the remote.
- **APP Button:** May launch a specific application or app drawer, depending on your Android TV box's configuration.
- **SETUP Button:** May be used for advanced settings or programming, depending on the specific Android TV box

model.

Point the remote control directly at your Android TV box for optimal signal transmission. The effective transmission distance is approximately 10 meters (393.7 inches).

5. Maintenance

To ensure the longevity and proper functioning of your CALANDIS Smart Remote Control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can cause damage. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

6. Troubleshooting

If you experience issues with your remote control, refer to the following troubleshooting steps:

Problem	Possible Cause	Solution
Remote not responding.	• Dead or incorrectly inserted batteries. • Obstruction between remote and TV box. • Remote out of range.	• Replace batteries with new AAA batteries, ensuring correct polarity. • Remove any objects blocking the line of sight to the TV box. • Ensure you are within 10 meters (393.7 inches) of the TV box.
Buttons are unresponsive or sticky.	• Dirt or debris under buttons. • Low battery power.	• Clean the remote surface with a soft, dry cloth. • Replace batteries.
Remote controls TV box intermittently.	• Weak batteries. • Interference from other electronic devices.	• Replace batteries. • Move other electronic devices away from the TV box or remote.

7. Specifications

Feature	Detail
Model Number	ELY68030859
Brand	CALANDIS
Material	PC (Polycarbonate)
Power Source	2 x AAA Batteries (not included)

Feature	Detail
Transmission Distance	Approximately 10 meters (393.7 inches)
Dimensions (L x W x H)	Approx. 15 x 5 x 2.5 cm (5.9 x 2.0 x 1.0 inches)
Color	Black

8. Warranty Information

Specific warranty details for this product are not provided in the available information. Please refer to your purchase documentation or contact the retailer for warranty terms and conditions.

9. Support

For technical assistance or inquiries regarding your CALANDIS Smart Remote Control, please contact the manufacturer or importer:

- **Manufacturer:** Elyssion Designs
- **Contact Email:** elyssiondesigns@creationist.in
- **Contact Phone:** 9311494800
- **Importer Address:** Elyssion Designs, Plot No 225, Udyog Vihar Phase 4, Sector 18, Gurugram Haryana 122015

© 2025 CALANDIS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1413N36

More documents and user manuals: **https://manuals.plus/**