Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Psisuvry FU

Psisuvry 3.3 Cubic Feet Digital Security Safe Box

User Instruction Manual

Introduction

Thank you for choosing the Psisuvry 3.3 Cubic Feet Digital Security Safe Box. This safe is designed to provide secure storage for your valuables, documents, and other important items, offering protection against fire, water, and theft. Please read this manual thoroughly before operating your safe to ensure proper use and to maximize its security features.



Image: The Psisuvry safe with its door open, revealing a spacious interior suitable for various valuables.

Safety Information

Always adhere to the following safety guidelines:

- Keep the emergency keys in a secure location away from the safe. Do not store them inside the safe.
- Ensure the safe is placed on a stable, level surface or securely mounted to prevent tipping.
- Do not attempt to force the safe open if the digital lock malfunctions. Use the emergency key or contact customer support.
- Keep children away from the safe and its contents.
- Regularly check the battery level to ensure continuous operation of the digital keypad.

Package Contents

Verify that all items are present in the package:

- Psisuvry Digital Security Safe Box (1)
- Emergency Keys (2)
- Expansion Screws (4)
- User Manual (1)
- Protective Mat (1)



Image: The safe displayed alongside its accessories, including mounting hardware and spare keys.

Setup

1. Unboxing and Initial Inspection

1. Carefully remove the safe from its packaging.
2. Inspect the safe for any signs of damage during transit. If damaged, contact customer support immediately.
3. Remove any protective films or packaging materials from the safe's exterior.



Image: The safe secured within its packaging, highlighting the corner guards and panel cover for protection during transport.

2. Battery Installation

The digital keypad requires batteries for operation. Locate the battery compartment, typically on the inside of the safe door or behind the keypad. Insert the required batteries (not included) according to the polarity markings.

3. Mounting the Safe

For enhanced security, it is highly recommended to mount the safe to a floor, wall, or cabinet using the provided expansion screws.

1. Choose a suitable location for the safe. Consider discreet placement for added security.
2. Using the pre-drilled holes on the back or bottom of the safe as a template, mark the drilling points on the desired surface.
3. Drill pilot holes into the surface using an appropriate drill bit.
4. Align the safe with the drilled holes and secure it using the expansion screws. Ensure the safe is firmly attached.



Image: Examples of safe placement, including freestanding in a living room, inside a wardrobe, and wall-mounted.

Operating Instructions

1. Opening the Safe with Digital Keypad

1. Enter your personal password (factory default or previously set).
2. Press the '#' key to confirm.
3. Within 5 seconds, turn the knob clockwise to open the safe door.

2. Setting/Changing User Code

1. With the safe door open, press the red reset button located on the inside of the door.
2. The indicator light on the keypad will flash, indicating it's ready for a new code.
3. Enter your new 3-8 digit code.
4. Press the '#' key to confirm. The light will stop flashing, confirming the new code is set.

3. Opening with Emergency Key

In case of battery failure or forgotten password, the safe can be opened using the emergency key.

1. Locate the emergency keyhole, usually concealed behind a cover on the keypad panel.
2. Insert the emergency key and turn it counter-clockwise.
3. Simultaneously turn the knob clockwise to open the safe door.



Image: Visual guide demonstrating both digital code and emergency key access methods for the safe.

4. Smart Alarm System

The safe is equipped with a smart alarm system. If three consecutive incorrect passcodes are entered, the safe will activate an audible alarm to deter unauthorized access. The alarm will sound for a set period and then reset. To silence the alarm immediately, enter the correct password or use the emergency key.



Image: The safe's alarm system is activated after multiple incorrect attempts, indicated by a flashing light.

Features and Protection

The Psisuvry safe offers robust protection for your valuables:

- **Fire Protection:** Engineered with advanced fire-resistant materials to safeguard documents and valuables during fire emergencies.
- **Water Resistance:** Features water-resistant seals and construction to protect contents from water damage and flooding.
- **Anti-Theft Design:** Includes anti-drilling, anti-prying, and anti-collision features with solid steel construction and robust locking bolts.
- **Spacious Interior:** 3.3 cubic feet capacity provides ample room for documents, jewelry, cash, and other valuable items.
- **Removable Shelf:** An adjustable or removable shelf allows for flexible organization of the safe's interior, accommodating items of various sizes.



Image: Visual representation of the safe's fireproof and waterproof capabilities, along with resistance to physical attacks.



Image: A cutaway view illustrating the multi-layered, wear-resistant, rust-proof, and scratch-proof construction, emphasizing the 30mm locking bolts.



Image: The safe's interior shown with the removable shelf installed for organized storage, and without the shelf for larger items.

Maintenance

- **Cleaning:** Wipe the exterior of the safe with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish or keypad.
- **Battery Replacement:** Replace batteries annually or when the low battery indicator appears. Always use new, high-quality batteries of the specified type.
- **Key Care:** Keep emergency keys clean and dry. Do not expose them to extreme temperatures or corrosive substances.
- **Door Mechanism:** Periodically check the door hinges and locking bolts for smooth operation. Do not lubricate the digital keypad or lock mechanism unless specifically instructed by customer support.

Troubleshooting

Problem	Possible Cause	Solution
Safe does not open with digital code.	Incorrect code entered; low batteries; keypad malfunction.	Re-enter code carefully. Replace batteries. Use emergency key.
Alarm sounds unexpectedly.	Multiple incorrect code entries; tampering attempt.	Enter correct code to silence. Inspect safe for tampering.
Door does not close properly.	Obstruction in door frame; misaligned locking bolts.	Check for obstructions. Gently adjust door alignment if possible.
Emergency key does not work.	Key not fully inserted; lock mechanism jammed.	Ensure key is fully inserted and turned correctly. Do not force.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact Psisuvry customer support.

Specifications

- **Brand:** Psisuvry
- **Model:** FU
- **Capacity:** 3.3 Cubic Feet
- **Product Dimensions:** 9.85"D x 13"W x 9.85"H
- **Lock Type:** Electronic Combination Lock, Key
- **Color:** Black
- **Material:** Metal
- **Item Weight:** 37.7 pounds
- **Special Features:** Alarm System, Sensor Light, Fire Resistant, Water Resistant, Anti-Theft, Combination Lock, Removable Shelf, Scratch Resistant
- **Mounting Type:** Floor, Wall, Cabinet (pre-drilled holes)
- **Control Type:** COMBINATION LOCK BOX
- **Water Resistance Level:** Waterproof

Warranty and Support

Psisuvry stands behind the quality of its products. For warranty information, technical support, or any inquiries regarding your safe, please refer to the contact information provided on the product packaging or visit the official Psisuvry website. Please have your model number and purchase date available when contacting support.

© 2025 Psisuvry. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F14246KM

More documents and user manuals: **https://manuals.plus/**