Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE A75C07360

Instruction Manual for XINFUTE Replacement Air Conditioner Remote

Model: A75C07360

1. Introduction

This manual provides comprehensive instructions for the XINFUTE A75C07360 replacement remote control, designed for use with Panasonic Inverter Air Conditioners, including models featuring Nanoe-G and Nanoe-X technology. This remote functions as a direct replacement for the original unit, ensuring seamless operation of your air conditioning system.

2. Safety Information

Please read and understand the following safety precautions before using the remote control:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Ensure batteries are inserted with correct polarity (+ and -). Incorrect insertion can cause damage.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Keep batteries out of reach of children.
- Do not expose the remote control to direct sunlight, heat sources, or excessive moisture.

3. Product Overview

The XINFUTE A75C07360 remote control is designed for intuitive operation of your Panasonic air conditioner. Below are images illustrating the front and back of the remote, followed by a description of its key components and buttons.



Front view of the remote control, showing the display screen and all operational buttons.

This image displays the front of the XINFUTE A75C07360 remote control. It features a rectangular LCD screen at the top, displaying current settings. Below the screen are various control buttons, including 'OFF/ON' (yellow), 'POWERFUL', 'MODE', 'SLEEP', 'ON TIMER', 'OFF TIMER', 'TEMP' adjustment arrows, 'FAN SPEED/QUIET', 'AIR SWING', 'SET', 'CANCEL', 'CLOCK', and 'RESET'. The remote is white with clearly labeled grey and yellow buttons.



Back view of the remote control, showing the battery compartment cover.

This image shows the back of the XINFUTE A75C07360 remote control. It is a plain white surface with a sliding cover for the battery compartment located towards the bottom. A small 'OPEN' indicator is visible on the cover, and a symbol indicating proper disposal of electronic waste is present above the cover.

Button Functions:

OFF/ON: Powers the air conditioner on or off.

POWERFUL: Activates or deactivates the powerful cooling/heating mode for rapid temperature change.

MODE: Cycles through operating modes (e.g., Auto, Cool, Dry, Fan, Heat).

TEMP ▲ / ▼: Adjusts the temperature setting up or down.

FAN SPEED / QUIET: Adjusts fan speed or activates quiet operation mode.

SLEEP: Activates or deactivates sleep mode for comfortable overnight operation.

AIR SWING: Controls the direction of the air flow (louvers).

ON TIMER: Sets the time for the air conditioner to turn on automatically.

OFF TIMER: Sets the time for the air conditioner to turn off automatically.

SET: Confirms timer settings or other selections.

CANCEL: Cancels current timer settings.

CLOCK: Sets the current time on the remote's display.

RESET: Resets the remote control to factory default settings (often a small recessed button requiring a pointed object).

4. Setup

Installing Batteries:

The remote control requires two (2) AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) ends match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image showing the open battery compartment and the correct orientation for AAA batteries.

This image illustrates the open battery compartment on the back of the remote control. It shows two slots for AAA batteries, with springs at one end and contact points at the other, indicating the correct polarity for battery insertion. A detached battery compartment cover is also shown next to the remote.

Once batteries are installed, the remote's LCD screen should illuminate, indicating it is ready for use.

5. Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating.

Basic Operation:

- **Turning On/Off:** Press the **OFF/ON** button to power the unit on or off.
- **Selecting Mode:** Press the **MODE** button repeatedly to cycle through available operating modes (e.g., Auto, Cool, Dry, Fan, Heat). The selected mode will be displayed on the remote's screen.
- **Adjusting Temperature:** Use the **TEMP ▲** button to increase the temperature and the **TEMP ▼** button to decrease it.
- **Adjusting Fan Speed:** Press the **FAN SPEED** / **QUIET** button to cycle through different fan speeds (e.g., Low, Medium, High, Auto) or to activate a quiet fan setting.
- **Air Swing Control:** Press the **AIR SWING** button to activate or adjust the vertical louver swing. Press again to stop at the desired position.

Advanced Functions:

- **POWERFUL Mode:** Press **POWERFUL** to quickly reach the desired temperature. This mode typically operates at maximum fan speed and cooling/heating capacity. Press again to deactivate.
- **SLEEP Mode:** Press **SLEEP** to activate a comfortable sleep mode, which often adjusts temperature and fan speed gradually throughout the night. Press again to deactivate.
- **Setting Timers (ON/OFF):**
  a. Press **ON TIMER** or **OFF TIMER**.
  b. Use the **TEMP ▲ / ▼** buttons to adjust the desired time.
  c. Press **SET** to confirm the timer. The timer indicator will appear on the display.
  d. To cancel a timer, press **CANCEL**.
- **Setting Clock:**
  a. Press the **CLOCK** button.
  b. Use the **TEMP ▲ / ▼** buttons to set the current time.
  c. Press **SET** to confirm the time.
- **RESET:** If the remote control is unresponsive or behaving erratically, gently press the recessed **RESET** button using a thin, pointed object (e.g., a paperclip). This will restore the remote to its default settings.

6. Maintenance

Cleaning the Remote Control:

Wipe the surface of the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical sprays, as these can damage the remote's finish or internal components.

Battery Replacement:

Replace batteries when the remote's display becomes dim or the remote becomes unresponsive. Always replace both batteries at the same time with new AAA batteries. Dispose of used batteries according to local regulations.

7. Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries. Obstruction between remote and AC unit. Remote out of range.	Replace batteries, ensuring correct polarity. Remove any obstructions. Move closer to the AC unit.
Display is dim or blank.	Low battery power.	Replace batteries.
Air conditioner not responding to commands.	Remote not pointed correctly. AC unit receiver blocked. AC unit power issue.	Ensure remote is pointed directly at the AC unit. Check for obstructions on the AC unit's receiver. Verify AC unit has power.
Remote functions erratically.	Temporary software glitch.	Perform a **RESET** using a pointed object.

8. Specifications

Model:	A75C07360
Type:	Replacement Air Conditioner Remote Control
Material:	ABS Material
Color:	As Shown (White)
Dimensions:	Approximately 4 x 3 x 1 inches (10.16 x 7.62 x 2.54 cm)
Item Weight:	Approximately 2.4 ounces (68 grams)
Batteries Required:	2 x AAA (not included)
Supplied with models:	A75C07360

9. Warranty and Support

Warranty Information:

This product comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures the remote control functions as intended under normal use.

Customer Support:

If you encounter any issues with your XINFUTE A75C07360 remote control or have questions not covered in this manual, please contact the seller or manufacturer's customer support. All goods are inspected before shipment. If you are not satisfied with your purchase, you may contact us within 24 hours of receipt.
For further assistance, please refer to the contact information provided by your retailer or visit the official XINFUTE brand store online.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F18D25MW

More documents and user manuals: **https://manuals.plus/**