PKSTVB RGB-OBW

PKSTVB RGB-OBW Dueling Lightsaber User Manual

Model: RGB-OBW

1. Introduction

This manual provides essential information for the safe and effective use of your PKSTVB RGB-OBW Dueling Lightsaber. Please read these instructions thoroughly before operating the device and retain them for future reference.

2. Safety Information

Warning:

- Recommended age for use is 14 years and up.
- Always use a 5V1A adapter for charging. Using adapters with higher voltage or amperage can damage the battery and shorten the lifespan of the lightsaber.
- Avoid direct impact to sensitive areas of the body during dueling.
- Do not expose the lightsaber to extreme temperatures or moisture.
- Keep out of reach of small children due to small parts and electronic components.

3. Package Contents

Verify that all items listed below are included in your package:

- 1 x Metal Hilt
- 1 x Sturdy Blade (92cm/36in high-impact PC)
- 1 x Charging Cable (Type-C)
- 1 x User Manual (this document)
- 1 x Screw Tool Kit (includes screws and Allen key)



Image: Illustration of the PKSTVB Lightsaber package contents, showing the metal hilt, sturdy blade, Type-C charging cable, user manual, and screw tool kit.

4. Setup

4.1. Assembly

1. Carefully unbox all components.
2. Insert the sturdy PC blade into the hilt opening. Ensure it is fully seated.
3. Use the provided screw tool kit to tighten the retention screws on the hilt, securing the blade firmly in place. Do not overtighten.



Image: An assembled PKSTVB Lightsaber with a green illuminated blade, demonstrating the complete product.

4.2. Charging the Battery

The lightsaber is equipped with a removable and replaceable 3000mAh rechargeable lithium-ion battery. For optimal performance and longevity, follow these charging instructions:

1. Locate the charging port on the hilt. Some models may require partial disassembly to access the battery or charging port directly.
2. Connect the provided Type-C charging cable to the lightsaber's charging port.
3. Connect the other end of the charging cable to a 5V1A USB power adapter (not included).
4. Allow the lightsaber to charge fully. The charging indicator (if present) will change or turn off when charging is complete.

Important:

- Only use a 5V1A power adapter. Higher voltage/amperage adapters can damage the battery.
- The battery is designed to be easily disassembled and replaced if needed. Replacement components are available from the manufacturer.



Image: Diagram illustrating the charging process for the PKSTVB Lightsaber, highlighting the removable circuit board for direct charging and the Type-C charging cable.

5. Operating Instructions

5.1. Basic Controls (Hilt Button)

Your lightsaber features a primary control button on the hilt for basic functions:

- **Power On/Off:** Press and hold the button for approximately 2 seconds to power on or power off the lightsaber. A voice prompt will confirm "POWER ON" or "POWER OFF".
- **Activate Blade:** After powering on, a short press of the button will ignite the blade. Another short press will retract the blade.
- **Change Sound Font:** While the blade is active, press and hold the button for 1 second, then release. The lightsaber will cycle through 16 different sound fonts.
- **Change Light Effect:** While the blade is active, double-press the button to cycle through 3 light effects: Steady, Pulse, and Unstable.
- **Adjust Volume:** While the blade is active, triple-press the button to cycle through 3 volume settings: High,

Low, and Mute.

- **Change Color:** While the blade is active, press and hold the button for 2 seconds, then release. The blade will cycle through 16 fixed colors. Release the button on your desired color.

5.2. Advanced Features and Effects

- **Smooth Swing:** The lightsaber is equipped with a sensitive motion sensor that produces realistic sound effects corresponding to your swinging movements.
- **Flash on Clash (FOC):** When the blade makes contact, it will emit a bright flash and a clash sound effect.
- **Lock-up Effect:** Simulate a blade lock-up by holding the button and striking another object. The blade will flicker and emit a continuous lock-up sound. Release the button to end the effect.
- **Blaster Deflection:** A quick tap of the button while the blade is active will produce a blaster deflection sound and light effect.
- **Force Light Effect:** Specific motion gestures can activate a "Force" sound and light effect. Refer to the app for detailed gesture controls.



Image: An exploded view of the PKSTVB Lightsaber hilt, surrounded by text bubbles indicating various features such as App Control, 16 Sound Effects, 3 Light Effects, Smooth Swing, and Heavy Dueling capabilities.

5.3. App Control

The PKSTVB RGB-OBW Lightsaber can be controlled via a dedicated smartphone application for enhanced customization and functionality.

1. **Download the App:** Search for the "XENO" app (or specified app name in packaging) on your smartphone's app store (iOS or Android).
2. **Connect to Lightsaber:** Ensure your lightsaber is powered on and Bluetooth is enabled on your smartphone. Open the app and follow the on-screen instructions to connect to your lightsaber.
3. **App Features:** Through the app, you can control and monitor various aspects of your lightsaber, including:
    - Battery status and remaining time.
    - Volume adjustment.
    - Selection from 16 sound fonts.
    - Selection of lock-up, drag, Flash on Clash (FOC), and Force light effects.
    - Infinite color selection or quick selection of 16 preset colors.
    - Blade brightness adjustment.
    - Motion control turn on/off.
    - Sensitivity adjustment for motion and clash detection.



Image: A smartphone screen displaying the app control interface for the lightsaber, with options to adjust battery status, volume, sound fonts, light effects, color, brightness, motion control, and sensitivity.



Image: A series of smartphone screens demonstrating the comprehensive app control features, including settings for blade effects, motion control, color selection, and firmware updates.

Your browser does not support the video tag.

Video: Demonstration of the lightsaber's app control features, showing how to change colors, sound fonts, and light effects directly from a smartphone.

6. Maintenance

6.1. Cleaning

- Wipe the hilt with a soft, dry cloth to remove dust and fingerprints.
- For the blade, use a damp cloth with mild soap if necessary, then wipe dry immediately. Avoid abrasive cleaners.

6.2. Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- If storing the lightsaber for an extended period, charge the battery to approximately 50% before storage.
- Recharge the battery every few months during storage to prevent deep discharge.

6.3. Component Replacement

The lightsaber is designed with a high-end structure allowing for easy disassembly and replacement of damaged components. This ensures the longevity of your product.

- Refer to the manufacturer's website or contact customer support for information on purchasing replacement parts.
- Use the provided screw tool kit for disassembly and reassembly.

7. Troubleshooting

Problem	Possible Cause	Solution
Lightsaber does not power on.	Battery is depleted or not properly connected.	Charge the battery fully. Ensure the battery is correctly inserted.
Blade does not light up.	Lightsaber is not powered on, or blade is not properly seated.	Ensure the lightsaber is powered on (voice prompt "POWER ON"). Check blade connection and retention screws.
No sound or distorted sound.	Volume is muted or set too low. Speaker issue.	Adjust volume settings via the hilt button or app. If problem persists, contact support.
App cannot connect to lightsaber.	Bluetooth is off, lightsaber is off, or app issue.	Ensure lightsaber is powered on and Bluetooth is enabled on your phone. Restart the app and try again.
Lightsaber turns on unexpectedly when set down.	Motion sensor sensitivity is too high.	Adjust motion sensor sensitivity via the app.

8. Specifications

- **Model:** RGB-OBW
- **Brand:** PKSTVB

- **Product Dimensions:** 36 x 1.5 x 1.5 inches (Blade length: 36 inches)
- **Item Weight:** 1.36 pounds
- **Battery:** 1 x 3000mAh D-type rechargeable lithium-ion battery (included)
- **Charging:** Type-C USB, requires 5V1A adapter
- **Sound Effects:** 16 sound fonts
- **Light Effects:** 3 modes (Steady, Pulse, Unstable)
- **Colors:** 16 fixed colors + infinite RGB change
- **Control:** Hilt button, Smartphone App (Bluetooth)
- **Material:** Metal aluminum hilt, high-impact PC blade
- **Recommended Age:** 14 years and up



Image: A visual representation of the PKSTVB Lightsaber's dimensions, showing a total length of 46.8 inches with a 36-inch blade and a 10.8-inch hilt. Weight information for RGB and PIXEL models is also provided.

9. Warranty and Support

PKSTVB provides comprehensive after-sales service. If you encounter any issues or require professional

assistance, please contact our customer support team.

- **Warranty:** Please refer to your purchase documentation for specific warranty terms and conditions.
- **Customer Support:** For technical support, troubleshooting, or replacement parts, please visit the PKSTVB store on Amazon or contact us directly through the provided contact information in your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question