esonstyle S21

esonstyle Kids Cat Ear Headphones (Model S21)

User Manual

Introduction Setup Operation Maintenance Troubleshooting Specifications Support

1. Introduction

Thank you for choosing the esonstyle Kids Cat Ear Headphones. These headphones are designed to provide a safe, comfortable, and enjoyable audio experience for children, featuring a unique cat ear design with LED lights, Bluetooth 5.4 connectivity, and an 85dB safe volume limit. Please read this manual carefully before use to ensure proper operation and to maximize the lifespan of your product.

Package Contents:

- esonstyle Kids Cat Ear Headphones (Pink)
- USB-C Charging Cable
- 3.5mm Audio Cable
- User Manual

2. Setup

2.1 Charging the Headphones

Before first use, fully charge the headphones. Connect the provided USB-C charging cable to the charging port on the headphones and the other end to a USB power adapter (not included) or a computer's USB port.
Note: *The LED indicator will show charging status and turn off or change color when fully charged.*



Image: The pink cat ear headphones with a USB-C cable plugged into the charging port, illustrating how to charge the device.

2.2 Powering On/Off

To power on the headphones, press and hold the Power button for approximately 2 seconds until the LED lights illuminate. To power off, press and hold the Power button again for 2 seconds.



Image: A detailed view of the headphone's control panel, highlighting the power button and other function buttons for user interaction.

3. Operation

3.1 Bluetooth Connection (Wireless Mode)

1. Ensure the headphones are charged and powered on.
2. The headphones will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
3. On your device (e.g., smartphone, tablet, laptop), go to Bluetooth settings and enable Bluetooth.
4. Search for "S21" or "esonstyle Headphones" in the list of available devices and select it to connect.
5. Once connected, the LED indicator will stop flashing and remain solid.



Image: The headphones are shown alongside a mobile phone displaying its Bluetooth settings, illustrating the wireless connection process.

3.2 Wired Connection (3.5mm Audio Cable)

To use the headphones in wired mode, simply plug the provided 3.5mm audio cable into the audio jack on the headphones and the other end into your audio device's 3.5mm port. This mode works even if the headphone battery is depleted.



Image: The pink cat ear headphones are depicted with a 3.5mm audio cable connected, demonstrating the wired usage option.

3.3 Button Functions

Button/Action	Function
Power Button (Press & hold 2s)	Power On/Off
Power Button (Press 3 times quickly)	Enable/Disable Children's Mode
Power Button (Press 2 times quickly)	Turn LED lights on/off
Play/Pause Button (Press 1 time)	Play/Pause music
Play/Pause Button (Press 2 times quickly)	Next Song
Play/Pause Button (Press 3 times quickly)	Previous Song
Play/Pause Button (Press & hold 1s)	Activate Voice Assistant

Button/Action	Function
Volume + Button (Press & hold)	Increase Volume
Volume - Button (Press & hold)	Decrease Volume



Image: A visual guide detailing the various functions assigned to each button on the headphone's control panel.

3.4 Child Mode (85dB Safe Volume Limit)

The headphones feature a built-in Child Mode that limits the maximum volume to 85dB to protect young ears. This mode is enabled by default. To toggle Child Mode on or off, quickly press the Power button three times.



Image: A child wearing the pink cat ear headphones, with an overlay indicating the 85dB safe volume limit feature for hearing protection.

3.5 LED Lights

The cat ears and earcups feature vibrant RGB LED lighting. To turn the LED lights on or off, quickly press the Power button two times.



Image: The pink cat ear headphones displaying their illuminated LED lights, with examples of different lighting effects and colors.

4. Maintenance

4.1 Cleaning

- Wipe the headphones with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Avoid getting moisture into any openings.

4.2 Storage

When not in use, store the headphones in a cool, dry place away from direct sunlight and extreme temperatures. The headphones feature multi-axis rotating hinges for compact folding, making them easy to store in backpacks or travel bags.



Image: The headphones are shown in a folded position, demonstrating their compact design for easy storage and portability.

5. Troubleshooting

5.1 No Sound

- Ensure the headphones are powered on and charged.
- Check the volume level on both the headphones and the connected device.
- If using Bluetooth, ensure the headphones are properly paired and connected to your device. Try re-pairing.
- If using wired mode, ensure the 3.5mm audio cable is securely plugged into both the headphones and the audio source.
- Test with a different audio source or device.

5.2 Cannot Pair via Bluetooth

- Make sure the headphones are in pairing mode (flashing LED).

- Ensure Bluetooth is enabled on your device and it is within 10 meters (33 feet) of the headphones.
- Turn off and on the headphones and your device's Bluetooth.
- Clear the Bluetooth pairing list on your device and try pairing again.
- Ensure no other Bluetooth devices are interfering.

5.3 LED Lights Not Working

- Ensure the headphones are powered on.
- Quickly press the Power button two times to toggle the LED lights on/off.
- Check battery level; low battery might affect LED functionality.

6. Specifications

Feature	Detail
Model Name	S21
Connectivity Technology	Wired, Wireless (Bluetooth 5.4)
Bluetooth Version	5.4
Bluetooth Range	15 Meters
Audio Driver Size	40 Millimeters
Frequency Range	20 Hz - 20 KHz
Impedance	32 Ohm
Noise Control	Passive Noise Cancellation
Safe Volume Limit	85dB (Child Mode)
Headphones Jack	Type-C (Charging), 3.5mm (Audio)
Material	Acrylonitrile Butadiene Styrene (ABS), Leather
Item Weight	13.4 ounces
Color	Pink
Manufacturer	esonstyle

7. Customer Support

For any questions, concerns, or technical assistance regarding your esonstyle Kids Cat Ear Headphones, please do not hesitate to contact our customer service team. Your satisfaction is our priority.
Please refer to the contact information provided with your purchase or visit the official esonstyle website for support details.
Note: *The product comes with a standard manufacturer's warranty. Please retain your proof of purchase for warranty claims.*

© 2025 esonstyle. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question