Peg Perego Living

Peg Perego Living High Chair & Recliner Instruction Manual

Model: Living

1. Introduction

Thank you for choosing the Peg Perego Living High Chair & Recliner. This multifunctional product is designed to grow with your child from birth, offering comfort and versatility. Please read this manual carefully before assembly and use to ensure safe operation and proper maintenance.

Important Safety Information

- Always secure your child with the five-point harness.
- Never leave your child unattended in the high chair or recliner.
- Ensure the high chair is on a flat, stable surface before placing your child in it.
- Keep children away from moving parts during adjustment.
- Do not use accessories or replacement parts other than those approved by Peg Perego.



Figure 1: Peg Perego Living High Chair in True Black, showcasing its modern design with the tray attached.

2. Setup and Assembly

The Peg Perego Living High Chair & Recliner comes largely pre-assembled. Follow these steps for initial setup:

1. **Unfolding the Frame:** Place the folded high chair on a flat surface. Release the folding locks (refer to diagram in your product box for exact location). Gently pull the legs apart until the frame locks into an open position. Ensure all locking mechanisms are engaged.
2. **Attaching the Seat Unit:** The seat unit is typically pre-attached. If not, align the seat unit with the frame attachment points and push firmly until it clicks into place.
3. **Tray Installation:** Slide the double removable tray onto the armrests until it clicks securely. The tray can be adjusted forward or backward to fit your child.



Figure 2: The Peg Perego Living High Chair in its compact folded state, demonstrating its space-saving design.

3. Operating Instructions

Height Adjustment

The seat adjusts to 8 different heights with one hand. Locate the height adjustment buttons on the side of the frame (usually near the top of the legs). Press these buttons simultaneously and raise or lower the seat to the desired height. Release the buttons to lock the seat in position. Ensure both sides are locked evenly.

Recline Positions

The high chair offers multiple recline positions for dining, living, and cozy moments, approved from birth. Locate the recline lever at the back of the seat. Pull the lever and adjust the seat back to one of the four available positions. Release the lever to lock the recline angle.



Figure 3: Side view illustrating the various recline positions of the Peg Perego Living High Chair, from upright to fully reclined.

Tray Usage

The high chair features a double removable tray system:

- **Pappa Tray:** This is the main meal tray, ideal for feeding. It is dishwasher safe for easy cleaning. To remove, lift the release levers on both sides and pull the tray forward. It can be stored on the frame when not in use.
- **Snack Tray:** A smaller tray perfect for snacks. It sits on top of the Pappa tray or can be used independently.



Figure 4: The Peg Perego Living High Chair with its double tray system, ready for mealtime.

Mobility and Braking

The high chair is equipped with four large, rubber-coated swivel wheels for 360-degree mobility. This allows for easy movement without damaging floors. The rear wheels feature an integrated brake for stability. To engage the brake, push down on the brake levers located on the rear wheels. To release, lift the levers.

Folding for Storage

To fold the high chair for compact storage, ensure the seat is in its most upright position and the tray is removed or stored on the frame. Locate the folding release mechanisms (refer to your product box for specific locations) and activate them. Gently push the top of the chair forward until the frame collapses. Ensure it locks into the folded position.

4. Maintenance

Cleaning the Cover

The eco-leather cover is fully removable with zippers for quick and easy cleaning. Unzip the cover and remove it from the seat frame. Wipe the eco-leather cover with a damp cloth and mild soap. Do not machine wash or tumble dry. Allow to air dry completely before reattaching.



Figure 5: Detail of the zipper on the eco-leather cover, highlighting its removable design for easy cleaning.

Cleaning the Straps

The five-point Easy Clean fabric straps are designed to resist crumbs and debris. Wipe the straps with a damp cloth and mild soap. For stubborn stains, the straps may be removed and hand-washed. Ensure straps are completely dry before re-use.

Cleaning the Tray

The Pappa tray is dishwasher safe. For the Snack tray and other plastic components, wipe with a damp cloth and mild soap.

5. Troubleshooting

- **High Chair does not fold smoothly:** Check for any obstructions in the folding mechanism. Ensure the seat is in the most upright position and the tray is removed or properly stored.
- **Seat height adjustment is difficult:** Ensure both adjustment buttons are pressed simultaneously and firmly. Check for any debris or foreign objects in the adjustment tracks.
- **Wheels are not moving freely:** Check for debris caught in the wheels. Ensure the brakes are fully disengaged.
- **Tray does not attach securely:** Ensure the tray is aligned correctly with the armrest slots and pushed firmly until it clicks into place on both sides.

6. Specifications

Product Dimensions (Open)	32.3"D x 21.7"W x 41.3"H (82 x 55 x 105 cm)
Item Weight	22 pounds (10 kg)
Maximum Weight Recommendation	45 Pounds (20.4 kg)
Material Type	Metal frame, 100% Polyurethane (eco-leather) cover
Portability	Yes, foldable design
Color	True Black

7. Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Peg Perego website. If you encounter any issues not covered in this manual or require further assistance, please contact Peg Perego customer support.

You can find contact details and additional resources on the official Peg Perego website: www.pegperego.com

© 2025 Peg Perego. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question