Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sony 1000046529

Sony PlayStation 5 Pro Digital Console User Manual

Model: 1000046529

Introduction

Welcome to the world of enhanced gaming with your new Sony PlayStation 5 Pro Digital Console. This manual provides essential information to help you set up, operate, and maintain your console for an optimal gaming experience. The PlayStation 5 Pro offers advanced features like PlayStation Spectral Super Resolution (PSSR) for sharp 4K visuals, optimized performance for higher frame rates, and enhanced ray tracing capabilities.

What's in the Box

Before you begin, please verify that all components are present:

- PlayStation 5 Pro 2TB SSD Console x 1
- Horizontal Stand Feet x 2
- PlayStation DualSense Controller (White) x 1
- PlayStation DualSense Controller (Chroma Pearl) x 1
- DualSense USB Charging Cable x 1
- HDMI Cable x 1
- AC Power Cord x 1
- Controller Charger x 1



Image: The retail box for the Sony PlayStation 5 Pro Digital Console, showing the console and branding.

Setup

1. Console Placement

Place your PlayStation 5 Pro console in a well-ventilated area, away from direct sunlight and heat sources. Ensure there is adequate space around the console for proper airflow. The console can be positioned horizontally or vertically using the included stand feet.



Image: The PlayStation 5 Pro console shown in a horizontal position next to a DualSense controller.



Image: The PlayStation 5 Pro console shown vertically with a DualSense controller. Note: The image indicates that the stand is sold separately, but the bundle includes horizontal stand feet for horizontal placement.

2. Connecting the Console

1. **HDMI Connection:** Connect one end of the supplied HDMI cable to the HDMI OUT port on the back of your PS5 Pro console and the other end to the HDMI input on your TV or display.
2. **Power Connection:** Connect the supplied AC power cord to the AC IN connector on the back of the console, then plug the other end into a wall outlet.
3. **Internet Connection (Optional):** For wired internet, connect an Ethernet cable to the LAN port on the back of the console. For wireless, you will configure Wi-Fi during initial setup.



Image: A detailed view of the rear ports of the PlayStation 5 Pro console, including HDMI, LAN, USB, and the power input.

3. Controller Setup

Connect one of the DualSense controllers to the console using the supplied USB charging cable. This will pair the controller with your console and begin charging it.



Image: A close-up of the white DualSense wireless controller, highlighting its design and buttons.

The included controller charger allows you to charge both DualSense controllers simultaneously without connecting them directly to the console.



Image: A DualSense controller charging station, showing its design and the included USB-C cable for power.

4. Initial Power On

Press the power button on the console or the PlayStation button on your paired DualSense controller to turn on the system. Follow the on-screen instructions to complete the initial setup, including language selection, internet connection, and user profile creation.

Operating Your Console

Power On/Off

- **To Power On:** Press the power button on the console or the PlayStation button on a paired controller.
- **To Power Off:** From the control center, select the power icon, then choose "Turn Off PS5". You can also enter Rest Mode from this menu.

Navigating the User Interface

Use your DualSense controller to navigate the PS5 Pro's user interface. The main screen provides access to your game library, media apps, and system settings. The Control Center (accessed by pressing the PlayStation button)

offers quick access to frequently used functions.



Image: The DualSense controller with visual cues indicating its advanced haptic feedback and adaptive trigger features.

Playing Games

As a digital console, games are downloaded and stored on the internal 2TB SSD. Access your game library from the home screen to launch installed titles. Ensure you have an active internet connection for downloading new games and updates.

Connecting to the Internet

The PS5 Pro supports both wired (Ethernet) and wireless (Wi-Fi) internet connections. To configure Wi-Fi, go to **Settings > Network > Settings > Set Up Internet Connection**and follow the prompts. The console supports IEEE 802.11be for enhanced wireless connectivity.

System Updates

Regularly update your console's system software to ensure optimal performance, security, and access to new features. Updates can be configured to download automatically via **Settings > System > System Software > System Software Update and Settings**.

Maintenance

Cleaning Your Console

To maintain optimal performance and prevent overheating, regularly clean your PS5 Pro console. Use a soft, dry cloth to wipe down the exterior. For vents, use a can of compressed air to gently remove dust buildup. Ensure the console is powered off and unplugged before cleaning.

Software Updates

Keep your system software updated. These updates often include performance improvements, bug fixes, and new features that enhance your gaming experience. You can check for updates manually via **Settings > System > System Software > System Software Update and Settings**.

Troubleshooting

If you encounter issues with your PlayStation 5 Pro, refer to the following common solutions:

- **No Power:**
  - Ensure the AC power cord is securely connected to both the console and a working wall outlet.
  - Try a different power outlet.
- **No Display or Poor Picture Quality:**
  - Verify the HDMI cable is securely connected to both the console and your TV/display.
  - Try a different HDMI cable or HDMI port on your TV.
  - Check your TV's input source.
  - Adjust display settings on the PS5 Pro (if accessible) or your TV.
- **Controller Not Connecting or Responding:**
  - Connect the DualSense controller to the console with the USB charging cable to re-pair it.
  - Ensure the controller is charged.
  - Reset the controller by pressing the small reset button on the back with a thin object.
- **Network Connectivity Issues:**
  - For Wi-Fi, ensure your router is on and within range. Re-enter Wi-Fi password in console settings.
  - For wired connection, check the Ethernet cable and router connection.
  - Restart your router and modem.

For more detailed troubleshooting, please visit the official Sony PlayStation support website.

Specifications

Sony PlayStation 5 Pro Digital Console Key Specifications

Feature	Detail
Platform	PlayStation 5
Model Name	PS5

Feature	Detail
Model Number	1000046529
Memory Storage Capacity	2 TB SSD (portion reserved for system software)
Resolution	Up to 8K, AI enhanced 4K with PSSR
Connectivity Technology	Bluetooth, HDMI, USB, Wi-Fi (IEEE 802.11be)
Input Device	Gamepad (DualSense)
Color	White / Chroma Pearl (controllers)
Item Weight	Approximately 13 pounds
Backwards Compatibility	Supports over 8,500 PS4 games

Warranty Information

Your Sony PlayStation 5 Pro Digital Console is covered by a manufacturer's limited warranty. Please refer to the warranty card included with your product or visit the official Sony PlayStation website for detailed terms and conditions, including warranty period and coverage specifics. Keep your proof of purchase for warranty claims.

Support

For further assistance, technical support, or to register your product, please visit the official Sony PlayStation Support website:

PlayStation Official Support

You can also find FAQs, community forums, and contact information for customer service on the support portal.

© 2024 Sony Interactive Entertainment Inc. All rights reserved. PlayStation and DualSense are registered trademarks or trademarks of Sony Interactive Entertainment Inc.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1H9TF2X

More documents and user manuals: **https://manuals.plus/**