Powkey R180

Powkey R180 Portable Power Bank Bag Instruction Manual

Model: **R180**

1. Product Overview

This manual provides instructions for the proper use and care of your **Powkey R180 Portable Power Bank Bag**. This bag is specifically designed to protect and transport the **Powkey 200W Rated Portable Power Station R180**, offering convenience for home use, camping, and outdoor adventures.

Key Features:

- **Compatibility:** Designed for the **Powkey R180** portable power station with an internal dimension of *7.87 x 7.87 x 4.3 inches*. Please verify your power station's dimensions for proper fit if using with other models.
- **Durability:** Constructed from premium fabric with a sturdy metal zipper, ensuring long-lasting protection for your device.
- **Portability:** Features a padded handle and an adjustable, removable shoulder strap for versatile and comfortable carrying options.



Image 1.1: The **Powkey R180 Portable Power Bank Bag**, showcasing its compact design and carrying handles.

2. Setup Instructions

To set up your **Powkey R180 Portable Power Bank Bag**, simply open the main zipper and carefully place your **Powkey R180** portable power station inside. Ensure the power station fits snugly within the bag's dimensions (*7.87 x 7.87 x 4.3 inches*) to provide optimal protection. Close the zipper securely.



Image 2.1: Detail of the bag's sturdy zipper and handle, indicating the opening for device insertion.

3. Usage Guidelines

The **Powkey R180 Portable Power Bank Bag** offers multiple carrying options. Use the reinforced padded handle for hand-carrying. For hands-free transport, attach the adjustable and removable shoulder strap (not included with the bag, but compatible with its D-rings) to the metal D-rings located on the sides of the bag. Adjust the strap length for comfortable carrying over your shoulder or across your body. Always ensure the zipper is fully closed when transporting the power station to prevent accidental opening.

4. Care and Maintenance

To maintain the condition of your **Powkey R180 Portable Power Bank Bag**, made from durable nylon material, wipe it clean with a damp cloth as needed. For stubborn dirt, a mild soap solution can be used, followed by wiping with a clean, damp cloth. Allow the bag to air dry completely before storing or reusing. Do not machine wash, bleach, or tumble dry. Avoid exposing the bag to extreme temperatures or harsh chemicals.

5. Troubleshooting

If you encounter any issues with your **Powkey R180 Portable Power Bank Bag**, such as a stuck zipper or damaged strap attachment point, inspect the component for any obstructions or visible wear. For minor zipper issues, ensure the zipper teeth are aligned and free of debris. If the bag sustains significant damage that compromises its protective function, consider replacing it. For further assistance, refer to the Warranty and Customer Support section.

6. Product Specifications

Feature	Detail
Model Number	R180
Product Dimensions	6.3 x 3.7 x 7.3 inches
Internal Dimensions	7.87 x 7.87 x 4.3 inches (for power station)
Item Weight	9.9 ounces
Color	Black+Red (zipper accent)
Material	Nylon
Special Features	Portable
Included Components	1 x Bag for Portable Power Station

7. Warranty and Customer Support

Warranty Description: Powkey provides a **1-year warranty** from the purchase date for all products. This warranty covers manufacturing defects and ensures your product performs as expected under normal use.

Customer Support: For any unexpected issues, questions, or warranty claims, please contact Powkey customer support. We are committed to providing 24-hour friendly customer service to assist you.

For the most current contact information, please visit the official Powkey website or refer to your purchase documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question