Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sonance MAGO6V3

Sonance MAGO6V3 6.5" All Weather Outdoor Speaker (Pair) Instruction Manual

Model: MAGO6V3

1. Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Sonance MAGO6V3 6.5" All Weather Outdoor Speakers. Please read this manual thoroughly before use to ensure proper setup and optimal performance.

2. What's in the Box

- 2 x Sonance MAGO6V3 6.5" All Weather Outdoor Speakers
- Mounting hardware (brackets, screws)
- Instruction Manual

3. Specifications

Brand	Sonance
Model Name	MAGO6V3
Speaker Type	Outdoor
Speaker Size	6.5 Inches
Audio Driver Type	Dynamic Driver
Audio Driver Size	6.5 Inches
Audio Output Mode	Stereo
Surround Sound Channel Configuration	2.0
Power Source	Corded Electric

Control Method	Touch
Mounting Type	Marine, Door
Compatible Devices	Desktop, Laptop, MP3 Player, Projector, Tablet, Television
Is Waterproof	False

4. Setup and Installation

Proper installation is crucial for optimal sound performance and speaker longevity. These speakers are designed for outdoor use but are not waterproof. Ensure they are installed in a location protected from direct heavy rain or submersion.

4.1 Mounting the Speakers

The Sonance MAGO6V3 speakers come with adjustable mounting brackets for flexible placement. They can be mounted on marine surfaces or doors. Choose a sturdy location that can support the weight of the speakers and provides the desired sound coverage.



Figure 1: Front view of the Sonance MAGO6V3 speaker, highlighting the speaker grille and driver components.



Figure 2: Rear view of the Sonance MAGO6V3 speaker, illustrating the speaker wire connection terminals and the integrated mounting points for the bracket.



Figure 3: Side view of the Sonance MAGO6V3 speaker, showcasing its curved profile and the attached mounting bracket.

4.2 Wiring Connections

Connect the speakers to your amplifier or receiver using appropriate speaker wire. Ensure correct polarity (positive to positive, negative to negative) for optimal sound quality. The speakers are designed for a 2.0 stereo configuration.
Note: The product specifications indicate a "Control Method: Touch". This likely refers to touch controls on a connected device (e.g., smartphone app for a Sonos system) rather than physical touch controls on the speaker itself, as the speaker is passive.

4.3 Video: Speaker Installation Overview

Your browser does not support the video tag.

Video 1: An overview of the OSD AP Series All Weather Patio Speakers, demonstrating features like corrosion-resistant grilles, adjustable mounting, and superior components. This video provides general insights into outdoor speaker design and installation, which may be relevant to the Sonance MAGO6V3.

5. Operating Instructions

Once properly installed and connected to an amplifier or receiver, your Sonance MAGO6V3 speakers are ready for use. Power on your audio source and amplifier, then select the desired input.

- **Volume Control:** Adjust the volume directly from your connected amplifier, receiver, or source device.
- **Audio Source:** These speakers are passive and require an external amplifier or receiver. Connect devices such as desktop computers, laptops, MP3 players, projectors, tablets, or televisions to your amplifier.
- **Placement Optimization:** Experiment with the speaker's angle using the adjustable brackets to achieve the best sound dispersion for your listening area.

6. Maintenance

To ensure the longevity and performance of your outdoor speakers, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe down the speaker enclosures with a soft, damp cloth to remove dust and dirt. Avoid using harsh chemicals or abrasive cleaners.
- **Grille Care:** The grilles are corrosion-resistant. If debris accumulates, gently clean with a soft brush or vacuum with a brush attachment.
- **Environmental Protection:** While designed for all-weather use, avoid prolonged exposure to extreme weather conditions such as heavy rain, snow, or direct sunlight if possible. Ensure proper drainage around the speakers if mounted in areas prone to moisture accumulation.
- **Connection Check:** Periodically inspect speaker wire connections for corrosion or looseness. Re-tighten or clean as necessary.

7. Troubleshooting

Problem	Possible Cause	Solution
No sound from speakers	◦ Incorrect wiring ◦ Amplifier/receiver off or incorrect input selected ◦ Volume too low ◦ Damaged speaker wire	◦ Check all speaker wire connections for correct polarity and secure fit. ◦ Ensure amplifier/receiver is powered on and the correct audio input is selected. ◦ Increase volume on amplifier/receiver and source device. ◦ Inspect speaker wire for cuts or damage; replace if necessary.
Distorted sound	◦ Volume too high ◦ Loose connections ◦ Amplifier clipping	◦ Reduce volume. ◦ Check all speaker wire connections. ◦ Ensure amplifier power matches speaker requirements; avoid overdriving the amplifier.
One speaker not working	◦ Faulty speaker wire for that channel ◦ Loose connection at speaker or amplifier	◦ Swap speaker wires between channels at the amplifier to isolate the problem. ◦ Check connections for the non-working speaker.

8. Warranty and Support

The Sonance MAGO6V3 speakers come with a Limited Warranty. Please refer to the warranty card included with your product for specific terms and conditions. For technical support or service inquiries, please contact Sonance customer service or visit their official website.
Return Policy: This product has a 90-day return policy for refund or replacement, as per Amazon Renewed terms.

© 2025 Sonance. All rights reserved.
For the latest information and support, please visit the product page on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1L3LZD5

More documents and user manuals: **https://manuals.plus/**