Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl P16

Onerbl AC-DC Adapter for Proscenic P16 Cordless Stick Vacuum Cleaner User Manual

Model: P16 | Brand: Onerbl

1. Introduction

This manual provides essential information for the safe and effective use of your Onerbl AC-DC Adapter, designed specifically for the Proscenic P16 Cordless Stick Vacuum Cleaner. This adapter converts standard AC power from electrical outlets into the DC power required to operate your vacuum cleaner or charge its battery.
Please read this manual thoroughly before using the product and retain it for future reference.

2. Important Safety Instructions

- **Indoor Use Only:** This adapter is designed for indoor use in dry locations. Do not expose to rain, moisture, or extreme temperatures.
- **Correct Voltage:** Ensure the wall outlet voltage matches the adapter's input specifications (AC 100-240V).
- **Compatibility:** Use this adapter exclusively with the specified Proscenic P16 Cordless Stick Vacuum Cleaner. Using it with incompatible devices may cause damage or injury.
- **Avoid Damage:** Do not use the adapter if the cord or plug is damaged. Do not attempt to open or repair the adapter.
- **Ventilation:** Ensure adequate ventilation around the adapter during use. Do not cover it with cloths or other materials.
- **Children and Pets:** Keep the adapter and its cord out of reach of children and pets.
- **Disconnect When Not in Use:** Unplug the adapter from the power outlet when not in use for extended periods.
- **Short Circuit Protection:** This adapter features short circuit protection. However, always ensure proper connection to prevent electrical hazards.



Image 1: Front view of the Onerbl AC-DC Adapter, displaying input specifications (100-240V AC) and a clear "CAUTION INDOOR USE ONLY" label. This emphasizes the importance of using the adapter in dry, indoor environments.

3. Setup Instructions

1. **Unpack the Adapter:** Carefully remove the Onerbl AC-DC adapter from its packaging.
2. **Inspect for Damage:** Before use, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.
3. **Connect to Vacuum:** Locate the charging port on your Proscenic P16 Cordless Stick Vacuum Cleaner. Insert the barrel connector of the adapter firmly into the vacuum's charging port.
4. **Plug into Power Outlet:** Insert the AC plug of the adapter into a standard wall electrical outlet (AC 100-240V).
5. **Verify Connection:** Ensure both connections are secure. The vacuum cleaner should indicate that it is charging (refer to your vacuum cleaner's manual for specific charging indicators).



Image 2: The Onerbl AC-DC Adapter is shown plugged into a standard wall electrical outlet, demonstrating a typical setup for charging.

4. Operating Instructions

Once properly connected, the Onerbl AC-DC Adapter will supply power to your Proscenic P16 vacuum cleaner. This allows you to either operate the vacuum directly from an electrical outlet or charge its internal Li-ion battery (Model D01BAT (P16), 29.6V 2200mAh 65.12Wh).

- **Charging:** When the vacuum cleaner is off and connected to the adapter, its battery will begin to charge. The charging time will vary depending on the battery's current charge level.
- **Direct Power:** If your vacuum cleaner supports direct operation while plugged in, the adapter will provide continuous power.
- **Battery Note:** The 29.6V specification refers to the vacuum's battery voltage, not the charger's output voltage. This adapter is designed to provide the correct charging voltage for the 29.6V Li-ion battery. Rechargeable batteries have a finite lifespan, typically 1 to 3 years. An old or faulty battery may not accept a charge, which is a battery issue, not an adapter fault.

5. Care and Maintenance

- **Cleaning:** Disconnect the adapter from the power outlet and the vacuum cleaner before cleaning. Wipe the adapter with a soft, dry cloth. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid wrapping the cable too tightly around the adapter to prevent damage.
- **Cable Care:** Do not bend, twist, or pull the cable excessively. Avoid placing heavy objects on the cable.

6. Troubleshooting

Problem	Possible Cause	Solution
Adapter not supplying power / Vacuum not charging.	Loose connection. Power outlet issue. Damaged adapter or cable. Vacuum cleaner battery issue.	Ensure all connections are secure. Test the power outlet with another device. Inspect the adapter and cable for visible damage. If damaged, discontinue use and replace. If the battery is old (1-3 years), it may no longer accept a charge. This is a battery limitation, not an adapter fault. Consult your vacuum's manual for battery replacement.
Adapter feels warm during use.	Normal operation.	A slight warmth is normal. Ensure adequate ventilation around the adapter. If it becomes excessively hot or emits smoke/odor, unplug immediately and discontinue use.

7. Specifications

Brand	Onerbl
Model (Compatible)	Proscenic P16 / P-16 Cordless Stick Vacuum Cleaner
Input Voltage	AC 100-240V, 50/60Hz
Output Voltage	DC 29.6V
Compatible Battery	Li-ion Battery D01BAT (P16), 29.6V 2200mAh 65.12Wh
Connector Type	Barrel Connector
Special Feature	Short Circuit Protection
Color	Black
Included Components	1 AC-DC Adapter



Image 3: The Onerbl AC-DC Adapter displaying its physical dimensions: approximately 3.1 inches in length, 2.1 inches in width, and 1.2 inches in depth. The cable length is approximately 76 inches.

8. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the retailer where the product was acquired. You may also visit the Onerbl official website for further assistance.

© 2025 Onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1MWXHT5

More documents and user manuals: **https://manuals.plus/**