Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RM-D1078+2

XINFUTE RM-D1078+2 Replacement Remote Control User Manual

For Samsung 3D Smart LCD LED TVs

1. Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your XINFUTE RM-D1078+2 replacement remote control. This remote is designed to function with various Samsung 3D Smart LCD LED TV models, offering a direct replacement experience without the need for complex programming.
Package Contents:

- 1 x XINFUTE RM-D1078+2 Remote Control

Note: Batteries are not included and must be purchased separately.

2. Setup

2.1 Battery Installation

The XINFUTE RM-D1078+2 remote control requires two (2) AAA batteries for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Once batteries are installed, the remote is ready for use with your compatible Samsung TV. No pairing or programming is required.



Figure 2.1: Battery compartment with cover removed.

3. Operating Instructions

This remote control is designed to replicate the functionality of your original Samsung TV remote. Point the remote directly at your television's infrared receiver for optimal performance.



Figure 3.1: Front view of the remote control.

3.1 Key Functions Overview

Button	Function
POWER	Turns the TV on or off.
TV / SOURCE	Switches between TV mode and various input sources (HDMI, AV, etc.).
MENU / GUIDE	Accesses the TV's main menu or electronic program guide.
Number Buttons (0-9)	Direct channel selection.

Button	Function
VOL (+/-)	Adjusts the volume level.
CH (Up/Down)	Changes TV channels.
MUTE	Mutes or unmutes the TV audio.
NETFLIX / Prime Video	Direct access to Netflix and Amazon Prime Video applications.
SMART HUB	Opens the Samsung Smart Hub for apps and smart features.
TOOLS / INFO	Accesses quick settings/tools or displays program information.
Navigation (Up/Down/Left/Right/Enter)	Navigates through menus and confirms selections.
RETURN / EXIT	Goes back to the previous screen or exits the current menu.
Color Buttons (A, B, C, D)	Context-sensitive functions within menus or applications.
P.SIZE / HISTORY / SEARCH	Picture size adjustment, view history, or initiate search function.
E-MANUAL / SUPPORT / AD/SUBT.	Accesses electronic manual, support, or audio description/subtitle options.
Playback Controls	Controls for media playback (Play, Pause, Stop, Fast Forward, Rewind).

4. Maintenance

Proper care will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners, solvents, or abrasive materials, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

5. Troubleshooting

If you encounter issues with your remote control, please refer to the following common solutions:

- **Remote Not Responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor. Ensure you are pointing the remote directly at the TV.
- **Specific Buttons Not Working:**
  - Verify that the TV model is compatible with the RM-D1078+2 remote.

- Clean the remote's surface, especially around the unresponsive buttons, to ensure no debris is interfering.

- **Interference:**
  - Bright lights or other electronic devices can sometimes interfere with the infrared signal. Try using the remote in a different environment.

If these steps do not resolve the issue, please refer to the Warranty and Support section for further assistance.

6. Specifications

Feature	Detail
Model Number	RM-D1078+2
Brand	XINFUTE
Compatibility	Samsung 3D Smart LCD LED TVs
Power Source	2 x AAA Batteries (not included)
Material	ABS Material
Color	Black
Dimensions	6 x 3 x 1 inches (approx.)
Item Weight	2.82 ounces (approx.)
Connectivity Technology	Infrared
Special Features	Ergonomic design, No Programming Required

7. Warranty and Support

7.1 Warranty Information

Your XINFUTE RM-D1078+2 replacement remote control comes with a**one-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

We inspect all products before shipment to ensure quality. If you are not satisfied with your purchase or encounter any issues, please contact us within 24 hours of receiving your product. Our customer support team is available to assist you with troubleshooting or warranty claims.
For support, please refer to the contact information provided by your retailer or visit the official XINFUTE store page.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1SNYNXT

More documents and user manuals: **https://manuals.plus/**