Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RM-L1379

XINFUTE RM-L1379 Replacement Remote Control for LG LCD TV User Manual

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your XINFUTE RM-L1379 replacement remote control for LG LCD TVs. This remote is designed to function as a direct replacement for original LG TV remote controls, including models like AKB73975730, offering immediate functionality without complex programming.



Image: The XINFUTE RM-L1379 remote control displayed alongside its clear retail packaging, showcasing the product's design and presentation.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings

inside the compartment.

4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

2. Initial Use

The XINFUTE RM-L1379 remote control requires no pairing or complex setup. Once batteries are installed, it is ready for immediate use with compatible LG LCD TVs.



Image: Multiple views of the XINFUTE RM-L1379 remote control, showing its ergonomic design from the front, side, and rear, including the battery compartment.

Operating Instructions

This remote control provides full functionality for your LG LCD TV. Point the remote directly at your television's infrared receiver for optimal performance.



Image: A close-up view of the XINFUTE RM-L1379 remote control's front, highlighting all buttons and their labels for easy identification.

Key Functions:

- **Power Button (●)**: Turns the TV on or off.
- **Number Buttons (0-9)**: Directly select channels.
- **Volume Up/Down (▲/▼)**: Adjusts the sound volume.
- **Channel Up/Down (P ▲/▼)**: Changes TV channels sequentially.

- **Mute Button**: Silences the TV audio.
- **Navigation Pad (▲▼◄► and OK)**: Navigates menus and confirms selections.
- **Back Button**: Returns to the previous screen or menu.
- **Exit Button**: Exits the current menu or application.
- **Netflix, Amazon, Smart Buttons**: Direct access to streaming services and smart TV features.
- **Subtitle, Guide, Ratio, Input**: Access various TV functions and settings.

Maintenance

Battery Replacement:

If the remote control becomes unresponsive or its range decreases, replace the AAA batteries. Always replace both batteries at the same time with new ones.

Cleaning:

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

Storage:

Store the remote control in a dry place, away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is advisable to remove the batteries to prevent leakage.

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are correctly installed with proper polarity.
  - Replace old batteries with new ones.
  - Check for any obstructions between the remote and the TV's infrared sensor.
  - Ensure you are within the effective range of the TV's sensor.
- **Specific buttons not working:**
  - Clean the remote control surface, especially around the unresponsive buttons, to remove any dirt or debris.
  - If the issue persists after battery replacement, the remote may require replacement.

Specifications

Feature	Detail
Model Number	RM-L1379
Compatible Devices	LG LCD Televisions
Power Source	2 x AAA Batteries (not included)
Material	ABS Material
Dimensions	6 x 3 x 1 inches

Feature	Detail
Item Weight	2.82 ounces
Special Feature	Ergonomic Design

Warranty and Support

Warranty Information:

The XINFUTE RM-L1379 remote control comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects under normal use.

Customer Support:

For any questions, concerns, or issues regarding your XINFUTE RM-L1379 remote control, please contact XINFUTE customer support. If you are not satisfied with your purchase, you may contact us within 24 hours of receipt for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1T4JXYT

More documents and user manuals: **https://manuals.plus/**