Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Proscenic P11 Lite

Proscenic P11 Lite Cordless Vacuum User Manual

Model: P11 Lite

1. Important Safety Information

Please read all instructions carefully before using this appliance. Retain this manual for future reference.

- Do not use the vacuum cleaner to pick up water or other liquids.
- Do not pick up burning or smoking materials, such as cigarettes, matches, or hot ashes.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

2. Product Overview and What's in the Box

The Proscenic P11 Lite is a versatile cordless vacuum cleaner designed for efficient home cleaning. Below is an overview of the main unit and included accessories.



Image: The Proscenic P11 Lite cordless vacuum cleaner shown with its main body, extension wand, floor brush, and various attachments.

Box Contents:



Image: A detailed diagram illustrating all components included in the Proscenic P11 Lite package, such as the main body, battery, brushes, and wall mount.

1. Battery
2. 2-in-1 Dusting Brush
3. User Manual (This Document)
4. Crevice Tool
5. Floor Brush
6. Telescopic Pipe
7. Main Body
8. Air Inlet HEPA Filter (x2)
9. Wall Mount
10. Power Adapter
11. Roller Brush
12. Mopping Pad (if applicable to specific model variant)
13. Water Tank (if applicable to specific model variant)

3. Setup and Initial Use

3.1 Assembly

Assemble the main components of your Proscenic P11 Lite vacuum cleaner:

- Insert the telescopic pipe into the main body until it clicks securely.
- Attach the desired cleaning head (e.g., floor brush) to the end of the telescopic pipe.
- For handheld use, attach accessories like the 2-in-1 dusting brush or crevice tool directly to the main body.



Image: The Proscenic P11 Lite main unit, extension wand, and various cleaning attachments laid out, illustrating how they connect for different cleaning tasks.

3.2 Charging the Battery

Before first use, fully charge the battery. The P11 Lite features a removable battery for flexible charging options.

- Connect the power adapter to the charging port on the main body or directly to the removable battery.
- Plug the adapter into a power outlet.

- The LED display will indicate charging status. A full charge provides over 40 minutes of runtime.
- You can also mount the vacuum on the wall mount for convenient storage and charging.



Image: The Proscenic P11 Lite vacuum mounted on its wall dock, connected to the power adapter for charging, demonstrating a convenient storage and charging solution.

4. Operating the Vacuum Cleaner

4.1 Power On/Off and Mode Selection

To power on the vacuum, press the power button. The digital LED display will activate. You can switch between two vacuum modes, Eco and Max, for optimal cleaning performance and battery life.



Image: A close-up view of the Proscenic P11 Lite's digital LED display, showing the current battery level, remaining runtime, power mode, and indicators for brush or air duct blockages.

4.2 Cleaning Performance

The P11 Lite offers powerful suction up to 38kPa, suitable for various surfaces.

- **Floor Cleaning:** Use the main floor brush for hard floors and carpets. The LED headlight illuminates hidden debris.
- **Maneuverability:** The 180° flexible swivel and 90° up/down motion of the floor brush allow for easy navigation around furniture and into tight spaces.



Image: A person operating the Proscenic P11 Lite cordless vacuum on a tiled floor, demonstrating its effective suction power on various types of debris.



Image: The Proscenic P11 Lite vacuum's floor head shown articulating with 180-degree left/right swivel and 90-degree up/down tilt, illustrating its ability to reach under low furniture and navigate corners.

4.3 Using Attachments

Transform the vacuum into a handheld unit for versatile cleaning:

- **2-in-1 Dusting Brush:** Ideal for cleaning upholstery, car interiors, and delicate surfaces.
- **Crevice Tool:** Perfect for narrow gaps, corners, and edges.

4.4 Anti-Tangle Brush

The V-shaped anti-tangle brush design minimizes hair wrapping around the roller, ensuring consistent performance.



Image: A detailed view of the Proscenic P11 Lite's V-shaped anti-tangle brush roll, designed to prevent hair from wrapping and ensure efficient debris collection.

5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

5.1 Emptying the Dustbin

Empty the dustbin regularly, especially when it reaches the MAX fill line.

- Hold the main body over a waste bin.
- Press the one-button release mechanism to open the dustbin flap and empty contents.
- Close the flap securely after emptying.



Image: A hand holding the main unit of the Proscenic P11 Lite over a waste basket, demonstrating the one-button release for emptying the dustbin.

5.2 Cleaning Filters

The P11 Lite features a five-layer filtration system, including HEPA filters. Clean filters regularly to maintain suction power.

- Twist and pull to remove the filter assembly from the dustbin.
- Tap off loose dirt or rinse the filters under cold running water. Ensure filters are completely dry before reinserting.

- It is recommended to clean the filters monthly, or more frequently with heavy use.



Image: Hands holding and rinsing the circular HEPA filter component of the Proscenic P11 Lite under a faucet, illustrating the cleaning process.

5.3 Cleaning the Brush Roll

Periodically check the brush roll for tangled hair or debris. The anti-tangle design helps, but occasional cleaning may be necessary.

- Remove the brush roll from the floor head (refer to the diagram in the 'What's in the Box' section for brush roll location).
- Use scissors or a cleaning tool to cut and remove any tangled hair or fibers.
- Reinsert the brush roll securely.

6. Troubleshooting

If you encounter issues with your Proscenic P11 Lite, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is not charged or not properly installed.	Ensure battery is fully charged and securely inserted. Check power adapter connection.
Low suction power	Dustbin is full, filters are clogged, or brush roll is obstructed.	Empty dustbin. Clean or replace filters. Remove any obstructions from the brush roll or air ducts.
Brush roll not spinning	Brush roll is tangled with hair/debris or obstructed.	Turn off the vacuum and remove any obstructions from the brush roll. Ensure it is properly reinstalled.
LED display shows error indicator	Specific issue indicated by the display (e.g., brush blocked, air duct blocked).	Refer to the LED display section in 'Operating the Vacuum Cleaner' for specific error meanings and follow indicated solutions. Clear any blockages.
Short runtime	Battery not fully charged or battery degradation.	Ensure battery is fully charged. If runtime remains significantly short, consider replacing the battery (sold separately).

If the problem persists after attempting these solutions, please contact customer support.

7. Specifications

Feature	Detail
Brand	Proscenic
Model Number	P11 Lite
Colour	Grey
Product Dimensions	24.5 x 23.8 x 122.4 cm
Capacity (Dustbin)	550 Millilitres
Power / Wattage	450 watts
Number of Speeds	2 (Eco/Max)
Noise Level	72 dB
Runtime	Up to 40 minutes
Item Weight	2.14 kg
Filter Type	HEPA Filter (5-layer filtration system)
Included Components	Main body, telescopic pipe, floor brush, 2-in-1 dust/leak brush, crevice tool, wall mount, power adapter, roller brush, 2 HEPA filters.
Cordless	Yes

8. Warranty and Customer Support

Proscenic offers a **2-year warranty** for the P11 Lite Cordless Vacuum. For any inquiries, technical assistance, or warranty claims, please contact Proscenic customer support.

Customer support is available **7 days a week, 24 hours a day**.

Please refer to the official Proscenic website or your purchase documentation for specific contact details.

© 2024 Proscenic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1TCW4M7

More documents and user manuals: **https://manuals.plus/**