Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SoBuy OGS32-II-L-HG

SoBuy OGS32-II-L-HG 2-Person Camping Tent Instruction Manual

Model: OGS32-II-L-HG

Product Overview

The SoBuy OGS32-II-L-HG is a versatile 2-person camping tent designed for outdoor adventures. This 3-in-1 solution combines a tent, a raised cot, and convenient storage features, offering a comfortable and protected sleeping environment. It is suitable for camping, hiking, and other outdoor activities, providing protection from ground moisture and insects.

- **Integrated Design:** Features a tent, elevated camp bed, mesh windows, and a wheeled carry bag for a complete camping solution.
- **Portability:** Designed for easy transport with a wheeled bag and compact dimensions, ideal for travel by car, train, or motorcycle.
- **Quick Assembly:** The camping cot includes fastening buckles, and the tent uses connection hooks for straightforward setup.
- **Ventilation & Storage:** Equipped with a large door, three mesh windows for airflow and visibility, and four shoe pockets for organization.
- **Weather Protection:** Constructed from durable Oxford fabric with a PE coating, mesh windows, and a raised sleeping surface to protect against moisture, insects, and humidity.

Safety Warnings

WARNING: Do not exceed a load of 207 kg (456 lbs) on the cot.

This tent has a water column rating of 1500 mm. It is not recommended for use in heavy rain conditions.

Setup Instructions

Follow these steps for quick and easy assembly of your SoBuy camping tent.

1. **Unpack Components:** Remove all parts from the wheeled carry bag. Lay out the cot frame, tent fabric, and poles on a clear, flat surface.



Image: The SoBuy OGS32-II-L-HG camping tent fully assembled in a forest setting, demonstrating its elevated design.

2. **Assemble the Cot Frame:** Unfold the aluminum cot frame. Ensure all legs are fully extended and locked into place.



Image: A close-up view of the sturdy aluminum frame legs of the elevated cot, showing its stable construction on natural ground.

3. **Attach Tent to Cot:** Place the tent fabric onto the assembled cot frame. Secure the tent to the cot using the provided fastening buckles and connection hooks. Ensure the tent base is taut and evenly distributed over the cot.



Image: A detailed shot showing how the tent fabric is secured to the cot frame using a hook and loop system, ensuring a snug fit.

4. **Insert Tent Poles:** Assemble the tent poles and slide them through the designated sleeves on the tent fabric. Connect the poles to the tent base using the connection hooks. This will give the tent its dome shape.
5. **Secure Rainfly (if applicable):** If your model includes a separate rainfly, drape it over the tent and secure it according to the instructions to provide additional weather protection.
6. **Final Adjustments:** Check all connections and ensure the tent is stable. Adjust guy lines if necessary for added stability in windy conditions.



Image: An illustration of the SoBuy OGS32-II-L-HG camping tent with key dimensions (length, width, height) clearly marked for reference.

Operating Instructions

Maximize your comfort and convenience while using your SoBuy camping tent.

- **Ventilation:** Utilize the large door and three mesh windows to ensure proper airflow. Open them during warm weather to prevent condensation and maintain a comfortable internal temperature.



Image: An interior shot of the tent, looking out through a mesh window at a forest, with a person holding a mug, highlighting the tent's view and ventilation.

- **Internal Lighting:** Use the specially designed hook inside the tent to hang a lamp or lantern for nighttime illumination.



Image: A close-up of a vintage-style lantern hanging from a hook inside the tent, illustrating the integrated lighting solution.

- **Shoe Storage:** Take advantage of the four integrated shoe pockets for convenient storage of footwear and small personal items, keeping the tent interior tidy.
- **Entry and Exit:** Use the zippered door for easy entry and exit. Ensure zippers are fully closed when not in use to protect against insects and weather.

Maintenance

Proper care will extend the lifespan of your camping tent.

- **Cleaning:** Hand wash the tent fabric with mild soap and water. Do not machine wash or use harsh detergents. Rinse thoroughly and allow to air dry completely before packing.
- **Drying:** Always ensure the tent is completely dry before storing to prevent mold and mildew growth.
- **Storage:** Fold the tent neatly and store it in its original wheeled carry bag in a cool, dry place away from direct sunlight.
- **Frame Care:** Periodically check the aluminum frame for any signs of damage or wear. Clean any dirt or debris from the frame joints.

Troubleshooting

Refer to these common issues and solutions.

Problem	Possible Cause	Solution
Water leakage inside the tent	Heavy rain exceeding 1500mm water column rating; improper setup; damaged fabric.	Avoid use in heavy rain. Ensure all seams are sealed and the rainfly (if applicable) is correctly positioned. Inspect fabric for tears and repair if necessary.
Tent feels unstable	Cot frame not fully locked; tent not properly secured to cot; insufficient guying.	Verify all cot frame legs are locked. Re-check all tent-to-cot connections. Use guy lines and stakes (if included) for added stability, especially in windy conditions.
Difficulty with assembly	Incorrect pole insertion; cot frame not fully extended.	Refer to the setup instructions carefully. Ensure poles are inserted into the correct sleeves and cot frame is fully extended and locked.
Condensation inside tent	Lack of ventilation.	Open mesh windows and the door to improve airflow, especially during humid conditions or when sleeping.

Specifications

Detailed technical specifications for the SoBuy OGS32-II-L-HG camping tent.

Model Name: OGS32-II-L-HG

Product Dimensions (L x W x H): 193 x 145 x 188 cm (76 x 57 x 74 inches)

Floor Dimensions (L x W): 193 x 145 cm (76 x 57 inches)

Item Weight: 14.7 kg (32.4 lbs)

Minimum Weight: 8.5 kg (18.7 lbs) (tent only, without cot)

Occupancy: 2 Person

Seasons: 3 Season

Tent Design: Camping Tent (Dome Tent)

Color: Light Grey

Material Type: Polyester (Tent Fabric), Oxford with PE coating (Tent Floor), PE (Rainfly Material)

Pole Material Type: Aluminum

Water Resistance Technology: 1500 mm Water Column (Hydrofuge / Water Repellent)

Closure Type: Zipper

Installation Type: Freestanding

Components Included: OGS32-II-L-HG Camping Tent, Wheeled Carry Bag

Care Instructions: Hand Wash

Warranty and Support

For product support, warranty information, or to report any issues, please contact SoBuy customer service.

- **Return Policy:** This product is eligible for returns within 30 days of purchase, subject to the seller's return policy.
- **Manufacturer:** SoBuy

- **Online Support:** Visit the official SoBuy Store on Amazon for more information and contact options.

© 2024 SoBuy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F1Y7PHM9

More documents and user manuals: **https://manuals.plus/**