JELLYPIG X100

JELLYPIG X100 Cordless Vacuum Cleaner Replacement Battery Pack User Manual

Brand: JELLYPIG

Model: X100

1. Introduction

This manual provides essential instructions for the safe and effective use of your JELLYPIG X100 Cordless Vacuum Cleaner Replacement Battery Pack. This battery pack is designed exclusively for the X100 vacuum cleaner model, ensuring optimal performance and compatibility. Please read this manual thoroughly before installation and operation.

2. Product Overview

The JELLYPIG X100 Replacement Battery Pack is a crucial component for maintaining the cordless functionality of your X100 vacuum cleaner. It provides the necessary power for extended cleaning sessions.



Figure 1: JELLYPIG X100 Replacement Battery Pack. This image shows the compact design of the battery pack, ready for installation into the X100 cordless vacuum cleaner.

3. Setup and Installation

Before installing the new battery pack, ensure your X100 vacuum cleaner is turned off and disconnected from any power source. The battery pack is designed for easy installation and removal.

3.1 Installing the Battery Pack

1. Locate the battery compartment on your X100 cordless vacuum cleaner. This is typically found near the handle or main motor unit.
2. If replacing an old battery, press the release button (often red) on the existing battery pack and slide it out.
3. Align the new JELLYPIG X100 Replacement Battery Pack with the vacuum's battery slot.
4. Slide the battery pack firmly into place until you hear a click, indicating it is securely locked.
5. Ensure the battery is fully seated before operating the vacuum.

3.2 Initial Charging

For optimal performance, fully charge the new battery pack before its first use. The battery can be charged while installed in the vacuum or separately if using a compatible charging dock.



Video 1: Demonstrates the process of charging a cordless vacuum battery. This video shows how to connect the charger to the battery pack, which can be done while the battery is attached to the vacuum or removed.

4. Operating the Battery Pack

4.1 Checking Battery Status

The X100 vacuum cleaner typically features an LED display that indicates the current battery level and power settings. Refer to your vacuum's main instruction manual for specific details on interpreting these indicators.



Video 2: Shows the LED display on the vacuum cleaner, indicating battery level and power settings. This display helps users monitor battery life during operation.

4.2 Power Modes

Your X100 vacuum cleaner may offer different power modes (e.g., Eco, Standard, Turbo). Using lower power modes will extend the battery's runtime. The battery pack is designed to support these various modes efficiently.

5. Maintenance and Care

5.1 Cleaning Battery Contacts

Periodically inspect the metal contacts on the battery pack and the vacuum cleaner for dirt or debris. Clean them gently with a dry cloth to ensure a good connection and efficient power transfer.

5.2 Storage

Store the battery pack in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, it is recommended to charge the battery to approximately 50% capacity to prolong its lifespan.

6. Troubleshooting

- **Battery not charging:** Ensure the charger is properly connected to both the battery pack and a working power outlet. Check for any damage to the charger cable or battery contacts.
- **Short runtime:** This may indicate the battery needs to be fully charged, or it could be nearing the end of its lifespan. Ensure you are using the appropriate power mode for your cleaning task.
- **Vacuum not turning on:** Verify the battery pack is securely installed and fully charged. If the issue persists, consult your X100 vacuum cleaner's main manual or contact customer support.

7. Specifications

Feature	Detail
Brand	JELLYPIG
Model Name	X100

Item Weight	1.12 pounds
Package Dimensions	7.09 x 3.54 x 1.85 inches
Batteries Required	Yes (8 AAAA batteries included)
Power Source	Battery Powered
Voltage	29.6V

8. Warranty and Support

For detailed warranty information and customer support, please refer to the documentation included with your original JELLYPIG X100 Cordless Vacuum Cleaner or visit the official JELLYPIG website. Keep your purchase receipt as proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question