DGIVOVO G1541-BL

DGIVOVO Electric Pressure Washer User Manual

Model: G1541-BL

1. Introduction

Thank you for choosing the DGIVOVO Electric Pressure Washer. This powerful and efficient cleaning tool is designed for various outdoor cleaning tasks, including decks, driveways, fences, patios, cars, and more. With its robust 4200 PSI maximum pressure and 2.8 GPM maximum flow rate, combined with anti-tipping technology and versatile nozzle options, it provides a comprehensive solution for your cleaning needs. Please read this manual thoroughly before operation to ensure safe and effective use.



Image 1.1: The DGIVOVO Electric Pressure Washer with its included accessories, including the spray gun, wand, foam cannon, and four quick-connect nozzles.

2. Important Safety Information

Always follow basic safety precautions when using this product to reduce the risk of injury, electric shock, or damage. This pressure washer operates at high pressure and can cause serious injury if not used correctly.

- **Read all instructions:** Familiarize yourself with the controls and proper use.
- **Electrical Safety:** Ensure the power cord is in good condition and connected to a grounded outlet. Do not operate in wet conditions or with damaged cords.
- **Personal Protective Equipment:** Always wear appropriate eye protection (safety glasses or goggles) and protective clothing.
- **High Pressure Hazard:** Never direct the spray gun at people, pets, or electrical devices. The high-pressure stream can cause severe injury.
- **Stable Surface:** Operate the pressure washer on a stable, level surface. The anti-tipping technology enhances stability, but caution is still advised.

- **Water Supply:** Ensure a continuous and adequate water supply to prevent damage to the pump.
- **Children and Pets:** Keep children and pets away from the operating area.
- **Unplug When Not In Use:** Always unplug the unit from the power source before performing any maintenance or when not in use.

3. Package Contents

Verify that all items are present in the package:

- DGIVOVO Electric Pressure Washer Unit
- High-Pressure Hose (20 FT)
- Spray Gun
- Flushing Lance
- Quick-Connect Nozzles (0°, 15°, 25°, 40°)
- Foam Cannon / Soap Bottle
- Power Cord (35 FT)
- User Manual



Image 3.1: Labeled components of the DGIVOVO Electric Pressure Washer, including the handle, ON/OFF switch, 360° lockable wheels, power cord, pressure hose, and flushing lance & gun.

4. Setup and Assembly

1. **Attach the High-Pressure Hose:** Connect one end of the 20 FT high-pressure hose to the outlet on the pressure washer unit and the other end to the spray gun. Ensure connections are secure.
2. **Connect the Flushing Lance:** Attach the flushing lance to the spray gun.
3. **Connect Water Supply:** Connect a garden hose (not included) to the water inlet on the pressure washer. Ensure the water supply is turned on fully before starting the unit.
4. **Plug in Power Cord:** Uncoil the 35 FT power cord completely and plug it into a grounded electrical outlet.
5. **Select Nozzle:** Choose the appropriate quick-connect nozzle for your task and insert it into the end of the flushing lance until it clicks into place.
6. **Check Wheels:** Ensure the 360° lockable wheels are unlocked for movement or locked for stationary operation as

needed.



Image 4.1: Illustration of the pressure washer in use, highlighting the 20 FT pressure hose and 35 FT power cord for extended reach, and the 360° lockable wheels for easy positioning.

5. Operation

1. **Purge Air:** Before turning on the power, squeeze the trigger on the spray gun to allow water to flow through the system and purge any air. This protects the pump.
2. **Start the Unit:** Turn the ON/OFF switch on the pressure washer unit to the "ON" position. The motor will start.
3. **Begin Cleaning:** Direct the spray gun at the surface to be cleaned, maintaining a safe distance. Squeeze the trigger to activate the high-pressure spray.
4. **Adjust Spray:** Change nozzles as needed for different cleaning tasks (refer to Section 6).
5. **Stop Operation:** Release the trigger to stop the water flow. For extended breaks or when finished, turn the ON/OFF switch to "OFF" and unplug the unit.
6. **Relieve Pressure:** After turning off the unit and before disconnecting hoses, squeeze the spray gun trigger to

release any remaining pressure in the system.

6. Nozzle Usage

The DGIVOVO Pressure Washer includes four quick-connect nozzles, each designed for specific cleaning applications:

Nozzle Color/Angle	Application	Description
Red (0°)	Cracks and Stubborn Stains	Provides a concentrated, pinpoint stream for tough, localized dirt and grime. Use with extreme caution.
Yellow (15°)	Driveways and Hard Surfaces	A narrow, powerful spray for intense cleaning of hard, non-delicate surfaces.
Green (25°)	Decks and Wooden Surfaces	A wider spray for general cleaning of most surfaces, including wood, siding, and fences.
White (40°)	Vehicles and Windows	The widest and gentlest spray, ideal for delicate surfaces, rinsing, and applying soap.



Image 6.1: Visual guide to the four quick-connect nozzles (0°, 15°, 25°, 40°) and their suggested applications for various cleaning tasks.

7. Foam Cannon Usage

The included foam cannon allows for efficient application of detergent or soap, enhancing cleaning effectiveness, especially for vehicles.

1. **Fill the Foam Cannon:** Unscrew the bottle from the foam cannon attachment. Fill the bottle with an appropriate pressure washer detergent or car wash soap, diluted according to the soap manufacturer's instructions.
2. **Attach to Spray Gun:** Securely attach the filled foam cannon to the end of the spray gun, similar to how you would attach a nozzle.
3. **Apply Soap:** Turn on the pressure washer and spray the desired surface. The foam cannon will mix the soap with the high-pressure water, creating a thick foam.
4. **Rinse:** After applying soap and allowing it to dwell (if recommended by soap manufacturer), remove the foam cannon and attach a rinsing nozzle (e.g., 40° white nozzle) to rinse the surface thoroughly.



Image 7.1: Demonstrates the use of the foam cannon for car washing, showing the thick foam being applied to a vehicle's surface.

8. Maintenance

Regular maintenance ensures optimal performance and extends the life of your pressure washer.

- **After Each Use:**
  - Turn off the power and water supply.
  - Squeeze the trigger to release residual pressure.
  - Disconnect hoses and drain any remaining water from the pump and hoses.
  - Clean the exterior of the unit with a damp cloth.
- **Nozzle Cleaning:** If nozzles become clogged, use a small pin or wire to clear the opening. Rinse thoroughly.
- **Water Inlet Filter:** Periodically check and clean the water inlet filter to prevent debris from entering the pump.
- **Storage:** Store the pressure washer in a dry, frost-free area. If storing in freezing temperatures, use a pump protector or antifreeze solution to prevent damage.

9. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Unit does not start	No power supply; tripped circuit breaker; ON/OFF switch off.	Check power connection; reset circuit breaker; turn ON/OFF switch to "ON".
Low pressure	Insufficient water supply; clogged nozzle; air in pump; kinked hose.	Ensure full water flow; clean nozzle; purge air from system; straighten hose.
Water leaks	Loose connections; damaged O-rings.	Tighten all connections; inspect and replace O-rings if damaged.
Motor stops frequently	Overheating; low voltage.	Allow unit to cool; ensure stable power supply.

10. Specifications

Feature	Detail
Brand	DGIVOVO
Model Number	G1541-BL
Power Source	Corded Electric
Maximum Pressure	4200 PSI
Maximum Flow Rate	2.8 GPM
Hose Length	20 Feet
Power Cord Length	35 Feet
Product Dimensions (L x W x H)	9"L x 8"W x 15"H
Item Weight	14.72 pounds
Color	Blue



Image 10.1: Key performance specifications of the pressure washer: 4200 PSI maximum pressure and 2.8 GPM maximum flow rate.

11. Warranty and Support

The DGIVOVO Electric Pressure Washer comes with a**1-year warranty** that covers any manufacturing defects or malfunctions from the date of purchase. This warranty ensures that your product will deliver exceptional performance under normal use.

For technical support, warranty claims, or any questions regarding your product, please contact DGIVOVO customer service. Refer to your purchase documentation or the DGIVOVO official website for the most current contact information.

Please retain your proof of purchase for warranty validation.

© 2024 DGIVOVO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question