ILIFE V9 Pro

ILIFE V9 Pro Robot Vacuum Cleaner User Manual

Model: V9 Pro

1. Introduction

Thank you for choosing the ILIFE V9 Pro Robot Vacuum Cleaner. This manual provides important information on the operation, maintenance, and troubleshooting of your new robot vacuum. Please read it thoroughly before use and keep it for future reference.

2. Safety Instructions

To reduce the risk of injury or damage, read these safety instructions carefully and keep them accessible during product use. This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

- Do not operate the robot in areas with open flames or fragile objects.
- Ensure the charging dock is placed on a level surface against a wall.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without dust bin and/or filters in place.
- Only use as described in this manual. Use only manufacturer's recommended attachments.

3. Package Contents

Please check if all parts are included in the package:

- ILIFE V9 Pro Robot Vacuum Cleaner
- Self-Emptying Charging Station
- Dirt Disposal Bag
- Power Adapter

- Sponge Filter (pre-installed or spare)
- User Manual

4. Product Overview

The ILIFE V9 Pro is an advanced robotic vacuum cleaner designed for efficient floor cleaning. It features powerful suction and comes with a self-emptying charging station for convenient dirt disposal.



Image: The ILIFE V9 Pro robot vacuum cleaner positioned in front of its self-emptying charging station. A smartphone screen displays the connected status of the robot within the ILIFE app, showing "ILIFE V9 Pro" as the device name.

5. Setup

5.1 Charging Station Placement

1. Place the self-emptying charging station on a hard, level surface against a wall.

2. Ensure there is at least 1 meter (3 feet) of clear space to the front and 0.5 meters (1.5 feet) to each side of the charging station.
3. Plug the power adapter into the charging station and then into a wall outlet.

5.2 Initial Charging

1. Place the robot vacuum onto the charging station, ensuring the charging contacts align.
2. Allow the robot to fully charge before its first use. The indicator light on the robot will change when fully charged.

5.3 Connecting to the App

1. Download the ILIFE app from your smartphone's app store.
2. Open the app and follow the on-screen instructions to add your ILIFE V9 Pro.
3. Ensure your robot is powered on and near your Wi-Fi router during the connection process.
4. The app allows for remote control, scheduling, and monitoring of your robot (as shown in the product image).

6. Operating

6.1 Starting a Cleaning Cycle

1. Press the 'Clean' button on the robot or use the ILIFE app to start a cleaning cycle.
2. The robot will automatically return to the charging station when its battery is low or when cleaning is complete.

6.2 Cleaning Modes

The ILIFE V9 Pro offers various cleaning modes to suit different needs:

- **Auto Clean:** The robot automatically cleans the entire floor area.
- **Spot Clean:** Focuses on a specific dirty area.
- **Edge Clean:** Cleans along walls and corners.
- **Scheduled Clean:** Set specific times for the robot to clean automatically via the app.

7. Maintenance

Regular maintenance ensures optimal performance of your ILIFE V9 Pro.

7.1 Emptying the Dirt Disposal Bag

1. The self-emptying station will automatically transfer dirt from the robot's dustbin to the disposal bag.
2. Replace the dirt disposal bag in the charging station when it is full. Refer to the station's indicator for bag status.

7.2 Cleaning the Dustbin and Filter

1. Open the robot's top cover and remove the dustbin.
2. Empty the dustbin contents into a trash can.
3. Remove the sponge filter and tap it gently to remove dust. Rinse if necessary and allow to air dry completely before reinserting.
4. Clean the dustbin with a dry cloth or brush. Do not wash the dustbin with water unless specified.

7.3 Cleaning Brushes and Sensors

1. Regularly check and clean the main brush and side brushes for tangled hair or debris.

2. Wipe the cliff sensors and charging contacts on the robot and charging station with a clean, dry cloth.

8. Troubleshooting

Problem	Possible Cause	Solution
Robot does not turn on.	Low battery; Power switch off.	Charge the robot; Turn on the main power switch.
Robot cannot find charging station.	Charging station obstructed; Too far from station.	Clear obstacles around station; Place robot closer to station.
Suction power is weak.	Dustbin full; Filter clogged; Obstruction in suction path.	Empty dustbin; Clean/replace filter; Remove obstruction.
Robot gets stuck frequently.	Cables/rugs on floor; Cliff sensors dirty.	Remove obstacles; Clean cliff sensors.

9. Specifications

Feature	Detail
Brand	ILIFE
Model Name	V9 Pro
Special Feature	Easy-Empty Dirt Container
Color	White
Product Dimensions	12.4"L x 12.4"W x 3.66"H
Included Components	Dirt Disposal Bag
Filter Type	Sponge
Battery Life	100 minutes
Voltage	14.4 Volts
Capacity	2.5 Liters (Dustbin)
Power Source	Battery Powered
Control Method	App
Compatible Devices	Amazon Echo
Item Weight	7.5 pounds
Manufacture Year	2025

10. Warranty and Support

ILIFE provides a limited warranty for this product. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact ILIFE customer service through their official website or the contact information provided in your product packaging.
You can also visit the ILIFE Store on Amazon for more information and support resources.

© 2025 ILIFE. All rights reserved.