Freaks and Geeks 150077

Freaks and Geeks Wireless Bluetooth Controller User Manual

Model: 150077 | Compatible with PS5, PS5 Slim, PC, Android, iOS

Introduction

This manual provides detailed instructions for the Freaks and Geeks Wireless Bluetooth Controller, Model 150077. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. Please read this manual thoroughly before using the controller.
The Freaks and Geeks Wireless Bluetooth Controller is designed for a versatile gaming experience, offering compatibility across multiple platforms and featuring advanced functionalities for enhanced gameplay.

Product Features

- **Multi-Platform Compatibility:** Works with PlayStation 5, PlayStation 5 Slim, PC (Steam only), Android, and iOS devices.
- **Ergonomic Design:** Engineered for comfortable grip, anti-slip properties, and sweat resistance during extended gaming sessions.
- **Long-Lasting Battery:** Equipped with a 1000 mAh battery for extended playtime.
- **Wired Connectivity:** Includes a 2-meter Type-C to Type-C cable for charging and wired play.
- **Enhanced Visuals:** Features LED backlit strips and buttons for an immersive gaming atmosphere.
- **Precision Control:** Incorporates Magnetic Hall sensor joysticks and triggers for accurate and responsive input.
- **Customizable Gameplay:** Two programmable buttons located on the rear of the controller.
- **Integrated Sensors:** Built-in motion sensor for interactive gameplay.
- **Audio Functionality:** Includes a speaker and microphone for in-game communication and audio feedback.

Setup

1. Charging the Controller

Before initial use, fully charge the controller. Connect the provided 2-meter Type-C cable to the controller's charging port and the other end to a compatible USB power source (e.g., console, PC, USB wall adapter). The LED indicators on the controller will show charging status and turn off or change color when fully charged.



Front view of the Freaks and Geeks Wireless Bluetooth Controller, showing the main buttons and joysticks. This image illustrates the general layout for connecting the charging cable.

2. Pairing with Devices

The controller supports Bluetooth wireless connection across various platforms.

- **For PS5/PS5 Slim:** Turn on your console. Press and hold the PS button and the Share button simultaneously on the controller until the light bar flashes. Navigate to your console's Bluetooth settings and select the controller to pair.
- **For PC (Steam only):** Connect the controller to your PC using the Type-C cable or pair via Bluetooth. Ensure your PC's Bluetooth is enabled. Go to your PC's Bluetooth settings, search for new devices, and select the controller. For Steam, ensure the controller is recognized in Steam's controller settings.
- **For Android/iOS:** Enable Bluetooth on your mobile device. Press and hold the pairing button on the controller (refer to the controller diagram for exact location) until the indicator light flashes. On your device, search for Bluetooth devices and select the controller to connect.

Operating the Controller

Basic Controls

The controller features standard buttons, joysticks, and triggers for gameplay. Familiarize yourself with the layout:

- **Directional Pad (D-Pad):** For directional input.
- **Action Buttons:** (e.g., Triangle, Circle, Cross, Square for PlayStation) for in-game actions.

- **Analog Joysticks:** For precise movement and camera control.
- **Shoulder Buttons (L1, R1) and Triggers (L2, R2):**For various in-game functions.
- **PS Button:** To access the console's home menu or power on/off.
- **Share Button:** To share screenshots or video clips.
- **Options Button:** To access in-game menus or pause.



Side view of the Freaks and Geeks Wireless Bluetooth Controller, highlighting the ergonomic grip and shoulder buttons.

Advanced Features

- **LED Backlighting:** The integrated LED strips and buttons illuminate during use, enhancing the visual experience.
- **Magnetic Hall Sensor Joysticks and Triggers:**These sensors provide high precision and durability, reducing drift and improving response time.
- **Programmable Back Buttons:** The two buttons on the rear of the controller can be programmed to replicate other button inputs, offering quick access to complex commands. Refer to the controller's specific programming instructions (usually a combination of holding a program button and the desired input button).
- **Motion Sensor:** The built-in motion sensor allows for motion-controlled gameplay in supported titles.
- **Audio Function:** Use the integrated speaker for in-game audio cues and the microphone for voice chat. Ensure your device's audio settings are configured to use the controller's audio features.



Rear view of the Freaks and Geeks Wireless Bluetooth Controller, showing the two programmable back buttons and the audio jack.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the controller. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the controller frequently. Charge it regularly, even if not in constant use. Do not expose the battery to high temperatures.
- **Handling:** Avoid dropping the controller or subjecting it to strong impacts, as this can damage internal components.

Troubleshooting

Problem	Possible Cause	Solution
Controller does not turn on.	Low battery.	Charge the controller using the provided Type-C cable.

Problem	Possible Cause	Solution
Cannot pair via Bluetooth.	Controller not in pairing mode; device Bluetooth off; interference.	Ensure controller is in pairing mode (flashing light). Check device Bluetooth settings. Move closer to the device. Restart both controller and device.
Buttons or joysticks are unresponsive.	Connection issue; software glitch; physical damage.	Reconnect the controller. Restart the game/device. If problem persists, contact customer support.
Microphone or speaker not working.	Audio settings incorrect; connection issue.	Check your device's audio input/output settings. Ensure the controller is properly connected.

Specifications

- **Model Number:** 150077
- **Connectivity:** Wireless Bluetooth, Wired (Type-C)
- **Compatibility:** PS5, PS5 Slim, PC (Steam only), Android, iOS
- **Battery Capacity:** 1000 mAh
- **Cable Length:** 2 meters (Type-C to Type-C)
- **Special Features:** LED Backlit, Magnetic Hall Sensor Joysticks/Triggers, 2 Programmable Back Buttons, Motion Sensor, Integrated Speaker & Microphone
- **Country of Origin:** China

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official Freaks and Geeks website. If you encounter any issues not covered in this manual, please contact customer service for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question