Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

L.O.L. Surprise! 598756

L.O.L. Surprise! Princess Baby Sisters 3-Pack Instruction Manual

Brand: L.O.L. Surprise! | Model: 598756

1. Product Overview

The L.O.L. Surprise! Princess Baby Sisters 3-Pack includes three unique dolls, each with multiple surprises and a color-change feature. This product is designed for imaginative play and collecting.



Image: An L.O.L. Surprise! Princess Baby Sister doll next to its spherical packaging, which is pink and purple with a blue handle.

2. Setup and Unboxing

Follow these steps to unbox your L.O.L. Surprise! Princess Baby Sisters dolls and reveal their surprises:

1. **Locate the zipper strip:** Each L.O.L. Surprise! ball has an outer wrapping with a zipper-like strip. Carefully peel this strip to begin unwrapping the ball.
2. **Unwrap layers:** Continue unwrapping the layers of the ball. Each layer may contain a small accessory or a hint about the doll inside.

3. **Reveal the doll:** Once all outer layers are removed, you will find a bag containing your Baby Sister doll and her sparkly princess dress.



Image: A hand peeling back the outer layer of an L.O.L. Surprise! ball, revealing instructions for unboxing, dressing, and color change.

3. Operating Instructions

3.1 Dressing Your Doll

After revealing your Baby Sister doll, dress her in her adorable, sparkly princess dress and place her crown. The dress is designed to fit snugly.



Image: An unboxed L.O.L. Surprise! Princess Baby Sister doll, wearing a blue dress and a gold crown, next to an empty pink cup.

3.2 Color Change Feature

The Princess Baby Sisters dolls feature a magical color change. To activate this feature:

1. **Prepare cold water:** Fill a small container or the included cup with cold water. For best results, use ice-cold water.
2. **Dip the dress:** Gently dip your Baby Sister doll's dress into the cold water. Observe as the color of the dress transforms.
3. **Repeat for effect:** The color change is reversible. You can repeat the process by warming the dress (e.g., with warm hands) and then re-dipping it in cold water.



Image: A hand dipping an L.O.L. Surprise! Princess Baby Sister doll, wearing a blue dress and a gold crown, into a pink cup filled with water.

3.3 Official Product Video

Your browser does not support the video tag.

Video: An official product video demonstrating the unboxing and color change features of the L.O.L. Surprise! Princess dolls. This video is provided by MGA Entertainment.

4. Maintenance and Care

To ensure the longevity of your L.O.L. Surprise! Princess Baby Sisters dolls:

- **Cleaning:** Wipe dolls and accessories with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store dolls and accessories in a clean, dry place away from direct sunlight to prevent fading or damage.
- **Water Play:** While the dolls are designed for water play, ensure they are thoroughly dried after use to prevent mold or mildew.

5. Troubleshooting

- **Color Change Not Working:** Ensure the water used is sufficiently cold. For best results, use ice water. The effect may be less noticeable in warm environments.
- **Missing Parts:** If any parts are missing from your L.O.L. Surprise! Princess Baby Sisters 3-Pack, please refer to the support section for assistance.

6. Specifications

Feature	Detail
Brand	L.O.L. Surprise!
Model Name	L.O.L. Surprise Princess Baby Sisters 3-Pack
Model Number	598756
UPC	035051598756
Item Type	Doll
Character	Princess
Manufacturer Minimum Age	72 Months
Material Type	Plastic
Item Weight	0.2 Kilograms
Number of Pieces	3
Item Dimensions (L x W x H)	4.13" x 3" x 8.25"
Assembly Required	No
Batteries Required	No

7. Warranty Information

Specific warranty details for the L.O.L. Surprise! Princess Baby Sisters 3-Pack are not provided in the product information. Please refer to the manufacturer's official website or contact their customer support for warranty inquiries.

8. Customer Support

For further assistance, questions, or to report missing components, please contact MGA Entertainment customer support. Contact information can typically be found on the product packaging or their official website.

Note: Always retain your proof of purchase for any support or warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F23BK9RQ

More documents and user manuals: **https://manuals.plus/**