Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Powaert V80

Powaert V80 Cordless Vacuum Cleaner User Manual

Model: V80

1. Product Overview

The Powaert V80 Cordless Vacuum Cleaner is a versatile and powerful cleaning device designed for various household tasks. It features a 350W brushless digital motor providing up to 45Kpa suction, a detachable rechargeable battery offering up to 50 minutes of runtime, and an advanced 5-stage filtration system. Its lightweight design and multiple attachments make it suitable for cleaning hardwood floors, carpets, furniture, and car interiors.



Image 1.1: Powaert V80 Cordless Vacuum Cleaner with included accessories.

2. Package Contents

Upon unboxing your Powaert V80 Cordless Vacuum Cleaner, please verify that all components listed below are present. Refer to the video for a visual guide on unboxing and initial assembly.

- Main Motor (Handheld Unit)
- Retractable Metal Tube (Extension Wand)
- Motorized Brush (Floor Head with LED lights)
- 2-in-1 Brush
- Crevice Tool
- Wall Mount

- Cleaning Gadget
- Filter (Extra HEPA filter included)
- Adapter (Charger)
- User Manual

Video 2.1: Unboxing and assembly of a similar cordless stick vacuum, demonstrating component identification.

3. Setup

1. **Attach the Extension Tube:** Insert the retractable metal tube into the main motor unit until it clicks securely.
2. **Attach the Floor Head:** Connect the motorized brush head to the other end of the extension tube, ensuring it clicks into place.
3. **Install Battery:** Slide the rechargeable battery into the designated slot on the main motor unit until it locks. Ensure the battery is charged before first use.
4. **Charging:** Connect the adapter to the battery or the main unit for charging. Refer to the 'Battery and Charging' section for detailed charging methods.



Image 3.1: Visual representation of the main components for assembly.

4. Operating Instructions

4.1 Power On/Off and Suction Modes

To power on the vacuum, press the power button located on the main unit. The LED display will show the battery percentage and current suction mode. Use the mode button to cycle through the 2 available suction modes: Standard and Max. The display will indicate the selected mode.

4.2 Cleaning Different Surfaces

The motorized brush head is designed for efficient cleaning across various floor types, including hardwood, tile, marble, and low-pile carpets. The LED lights on the brush head illuminate dark areas, revealing hidden dust and debris.



Image 4.1: The motorized brush head effectively cleans various floor surfaces.

Video 4.2: Demonstration of the vacuum's operation on various surfaces and in different cleaning scenarios.

5. Attachments and Versatility

The Powaert V80 comes with a range of attachments to enhance its versatility, allowing for 6 cleaning combinations. These tools enable cleaning of sofas, car interiors, stairs, keyboards, and other hard-to-reach areas.

- **Motorized Brush:** Ideal for all floor types, featuring LED lights for improved visibility.
- **2-in-1 Brush:** Combines a soft brush and a wide nozzle for dusting and upholstery cleaning.
- **Crevice Tool:** Perfect for narrow gaps, corners, and edges.
- **Telescopic Metal Tube:** Adjusts to your preferred height for comfortable floor cleaning or reaching high areas.



Image 5.1: The vacuum configured with different attachments for versatile cleaning.

6. Battery and Charging

The vacuum is equipped with 8 high-capacity cells, providing up to 50 minutes of uninterrupted cleaning in Standard Mode. The detachable battery allows for flexible charging options and includes built-in protection against overheating and short-circuits.

6.1 Charging Methods

1. **Wall-mounted Charging:** Use the provided wall mount to store and charge the entire vacuum unit.
2. **Main Machine Charging:** Plug the adapter directly into the main motor unit while the battery is attached.
3. **Battery Charging:** Detach the battery from the main unit and plug the adapter directly into the battery for charging.



Image 6.1: Three different methods for charging the Powaert V80 battery.

7. Filtration System

The Powaert V80 features an advanced 5-stage filtration system designed to capture 99.99% of dust, allergens, and particles, ensuring cleaner air during and after cleaning. The system includes:

- 1st Cyclone Filtration
- Stainless Steel Honeycomb Filtration
- 2nd Cyclone Filtration
- Upgraded HEPA Filtration (200% more efficient)
- High-density Sponge Filtration

An extra washable HEPA filter is included for convenience.



Image 7.1: Diagram illustrating the 5-stage cyclonic filtration system.

8. Maintenance

8.1 Emptying the Dust Cup

The vacuum is equipped with a large 1L dustbin. To empty, simply press the one-touch release button. This allows for hygienic disposal of collected dirt and debris without direct contact.

8.2 Cleaning Filters

The HEPA filter and other components of the filtration system are washable. Regularly clean the filters to maintain optimal suction performance and air quality. Ensure all parts are completely dry before reassembling.



Image 8.1: Demonstration of one-click dust cup emptying and washable filter components.

9. Specifications

Feature	Specification
Brand	Powaert
Model Name	V80
Special Feature	Cordless, HEPA, High Power, Lightweight, Rechargeable
Filter Type	HEPA Filter
Included Components	Adapter, Retractable tube, 2-in-1 brush, Crevice tool, Cleaning gadget, Extra HEPA
Is Cordless?	Yes

Capacity	1 Liters
Charging Time	4.5 Hours
Battery Life	50 minutes
Motor Horsepower	350 watts
Number of Power Levels	2
Item Weight	8.29 pounds
Product Dimensions	17.52"L x 13.5"W x 7.68"H

10. Troubleshooting

- **Reduced Suction:** Check if the dust cup is full and needs emptying. Inspect filters for clogs and clean them if necessary. Ensure all attachments are securely connected.
- **Battery Not Charging:** Verify that the adapter is correctly plugged into both the power outlet and the vacuum/battery. Ensure the battery is properly seated in the main unit or charging dock.
- **Vacuum Not Turning On:** Confirm the battery is charged and correctly installed. Press the power button firmly.

11. Warranty and Support

For warranty information, product support, or to purchase replacement parts, please refer to the contact details provided in your User Manual or visit the official Powaert website. Keep your purchase receipt as proof of purchase for warranty claims.

© 2025 Powaert. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F24GT5NR

More documents and user manuals: **https://manuals.plus/**